




*Service  
Manual*

**ELECTRICAL**



**MONTERO**



# Service Manual

# MONTERO

## 1992 : Volume 2

## Electrical

### FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnosis, disassembly, repair, and installation procedures along with complete specifications and tightening references. Use of this manual will aid in properly performing any servicing necessary to maintain or restore the high levels of performance and reliability designed into these outstanding vehicles.



Mitsubishi Motors corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

### GROUP/SECTION INDEX M00AA--B

General .....	
Fusible Link and Fuse Location .....	
Inspection Terminal Location .....	
Grounding Location .....	
Diode Location .....	
Junction Block .....	
Centralized Junction .....	
Inspection of Harness Connector .....	
How to Diagnose .....	
Configuration Diagrams .....	
Circuit Diagrams .....	
Engine Electrical .....	<b>16</b>
Chassis Electrical .....	<b>54</b>

**NOTE**  
For Engine, Chassis & Body, refer to ... Volume-1 "Engine, Chassis & Body"

FUSIBLE LINK AND FUSE LOCATION




M16BA--

Name	Symbol	Name	Symbol
Dedicated fuse ②, ③, ⑤, ⑦, ⑧	B	Fusible link	A
Dedicated fuse ⑨	D	Multi-purpose fuse	C




NOTE

- (1) For details of fusible link and fuse, refer to P.9.
- (2) The "Name" column is arranged in alphabetical order.

<Engine compartment>



<Interior>




# INSPECTION TERMINAL LOCATION

Name	Symbol	Name	Symbol
Fuel pump check connector	A	Diagnosis connector	B
Ignition timing adjustment connector	A		


**NOTE**

The "Name" column is arranged in alphabetical order.


**<Engine compartment>**




16E0128



**<Interior>**




16E0275









# GROUNDING LOCATION


<Engine compartment>







16E0128





<Interior>




16E0275



<Floor, Back door>



18E0004






**DIODE LOCATION**

Name	Symbol	Name	Symbol
Diode (ABS circuit)	B	Diode (Active trac 4WD circuit)	A

NOTE  
The "Name" column is arranged in alphabetical order.


<Interior>





JUNCTION BLOCK


M16BC--



KX35-AC-01602-N

Remark  
 ● Connector numbers are keyed to the configuration diagram (dashboard panel) and each circuit diagram.

TSB Revision



**CENTRALIZED JUNCTION**


M16BB-

**FUSIBLE LINK**


No.	Circuit	Housing color	Rated capacity (A)
1	ABS circuit (hydraulic unit power source)	Yellow	60
2	ABS circuit (control unit power source)	Light blue	20
3	—	—	—
4	Junction block (Multi-purpose fuse ⑥, ⑭, ⑯, ⑰, ⑱) and A/C circuit	Yellow	60
5	Alternator circuit	Blue	100
6	MPI circuit	Light blue	20
7	Ignition switch circuit	Green	40
8	—	—	—
9	Defogger circuit	Pink	30
10	Power window circuit	Pink	30
11	—	—	—
12	Condenser fan motor circuit	Pink	30
13	Alternator, headlight and tail light circuit	Green	40

**(Connected directly to battery positive terminal)**

**<Vehicles with ABS>**



**(Relay box in engine compartment)**




16E0410


**DEDICATED FUSE**

Power supply circuit	No.	Rated capacity (A)	Housing Color	Circuit
—	1	—	—	—
Battery	2	10	Red	A/C compressor circuit
Battery	3	25	Transparent	Condenser fan motor circuit
—	4	—	—	—
Tail light relay (Battery)	5	10	Red	Tail light circuit
—	6	—	—	—
Headlight relay (Battery)	7	10	Red	Upper beam indicator circuit
Battery	8	10	Red	Hazard light circuit
Ignition switch (ACC)	9	15	Blue	Sunroof circuit

**(Relay box in engine compartment)**




**(Relay box in passenger compartment)**



**MULTI-PURPOSE FUSES**

Power supply circuit	No.	Rated capacity (A)	Load circuit	
Battery	1	20	—	
Ignition switch	(IG2)	2	—	
		3	Blower motor relay, Headlight washer relay, Defogger, Car telephone	
	(ACC)	4	Radio, Clock	
		5	Remote control mirror, Cigarette lighter, Accessory socket relay	
Battery	6	15	Door lock relay	
Ignition switch	(IG2)	7	Over drive relay, Variable shock absorber control unit, ABS relay, 4WD indicator control unit	
		8	Power window relay	
	(ACC)	9	Wiper, Washer	
		10	Horn, Auto-cruise control unit, Sunroof	
	(IG1)	11	Combination meter, Multi-meter, Motor antenna control unit	
		12	Turn-signal light, Hazard light	
Battery	13	10	—	
	14	15	Accessory socket	
	15	—	—	
	16	25	Blower motor	
	17	15	Stop light	
Ignition	(IG1)	18	10	Back-up light, Rear differential lock control unit
Battery	19	10	Engine control unit, Room light, Map light, Cargo room light, Combination meter, Clock, Door lock relay, Radio, Auto-cruise control unit, Car telephone	

(In junction block)




16EG134

**CENTRALIZED RELAY**


Classification		Name	Classification		Name
Relay box in engine compartment	A-09X	Storage connector	Relay box in passenger compartment	C-70X	Over drive relay
	A-10X	Headlight relay		C-71X	—
	A-11X	—		C-72X	Power window relay
	A-12X	Alternator relay		C-73X	Door lock relay
	A-13X	—		C-74X	Rear intermittent wiper relay
	A-14X	Tail light relay		C-75X	Turn and hazard flasher unit
	A-15X	Condenser fan motor relay			
	A-16X	A/C compressor relay			

**(Relay box in engine compartment)**




16E0410

**(Relay box in passenger compartment)**



16E0409



## INSPECTION OF HARNESS CONNECTOR

M16CAAB

### CONTINUITY AND VOLTAGE TEST FOR CONNECTOR

Following procedures shall be followed for testing continuity and voltage at connector in order to prevent improper contact and deterioration of waterproof in connector.

#### CONVENTIONAL (NON-WATERPROOF) CONNECTOR


Check shall be done by inserting a probing needle from harness side.

#### WATERPROOF CONNECTOR

1. Be sure to use the special tool (test harness) when, for a waterproof connector, checking while the circuit is conductive.


If a probe is inserted from the harness side, the waterproof capability will be lowered, thereby causing corrosion, so never do so.

2. When a connector is disconnected in order to check terminal voltage, etc., never insert a probe if the terminal to be checked is a female pin, because the forceful insertion of a probe will cause improper or incomplete contact.



### CHECK FOR IMPROPER ENGAGEMENT OF TERMINAL

When terminal stopper of connector is out of order, engagement of male and female terminals becomes improper even when connector itself is engaged perfectly and terminal sometimes slips out to rear side of connector. Ascertain, therefore, that each terminal does not come off connector by pulling each harness wire.






### ENGAGING AND DISENGAGING OF CONNECTOR TERMINAL

Connector which gives loose engagement shall be rectified by removing female terminal from connector housing and raise its lance to establish securer engagement. Removal of connector housing and raise its lance to establish securer engagement. Removal of connector terminal used for ECI and ELC 4 A/T control circuit shall be done in the following manner.

#### COMPUTER CONNECTOR

- (1) Insert screwdriver [1.4 mm (.06 in.) width] as shown in the figure, disengage front holder and remove it.
- (2) Insert harness of terminal to be rectified deep into connector from harness side and hold it there.







- (3) Insert tip of screwdriver [1.4 mm (.06 in.) width] into connector in a manner as shown in the figure, raise housing lance slightly with it and pull out harness.

**NOTE**

Tool No. 753787-1 supplied by AMP can be used instead of screwdriver.




- (4) Insert needle through a hole provided on terminal and raise contact point of male terminal.




**ROUND WATERPROOF CONNECTOR**

- (1) Remove waterproof cap by using a screwdriver.
- (2) Insert tip of screwdriver [1.4 mm (.06 in.) or 2.0 mm (.08 in.) width] into connector in a manner as shown in the figure, raise housing lance slightly with it and pull out harness.




- (3) Insert screwdriver through a hole provided on terminal and raise contact point of male terminal.




**RECTANGULAR WATERPROOF CONNECTOR**

- (1) Disengage front holder by using a screwdriver and remove it.






- (2) Insert tip of screwdriver [\*0.8 mm (.03 in.) width] into connector in a manner as shown in the figure, push it lightly to raise housing lance and pull out harness.  
\*If right size screwdriver is not available, convert a conventional driver to suit the size.




- (3) Press contact point of male terminal down by holding a screwdriver [1.4 mm (.06 in.) width] in a manner as shown in the figure.




**INJECTOR CONNECTOR**

- (1) Remove waterproof cap.



- (2) Insert tip of screwdriver [1.4 mm (.06 in.) width] into connector in a manner as shown in the figure, press in terminal lance and pull out harness.



- (3) Press contact point of male terminal down by holding a screwdriver [1.4 mm (.06 in.) width] in a manner as shown in the figure.

**Caution**

**Correct lance to be in proper condition before terminal is inserted into connector.**


## HOW TO DIAGNOSE

M16DAAD

The most important point in troubleshooting is to determine "Probable Causes". Once the probable causes are determined, parts to be checked can be limited to those associated with such probable causes. Therefore, unnecessary checks can be eliminated. The determination of the probable causes must be based on a theory and be supported by facts and must not be based on intuition only.

### TROUBLESHOOTING STEPS

If an attempt is made to solve a problem without going through correct steps for troubleshooting, the problem symptoms could become more complicated, resulting in failure to determine the causes correctly and making incorrect repairs. The four steps below should be followed in troubleshooting.




### INFORMATION FOR DIAGNOSIS

This manual contains the cable diagrams as well as the individual circuit drawings, operational explanations, and troubleshooting hints for each component required to facilitate the task of troubleshooting. The information is compiled in the following manner:

- (1) Cable diagrams show the connector positions, etc., on the actual vehicle as well as the harness path.
- (2) Circuit drawings show the configuration of the circuit with all switches in their normal positions.
- (3) Operational explanations include circuit drawings of voltage flow when the switch is operated and how the component operates in reaction.
- (4) Troubleshooting hints include numerous examples of problems which might occur, traced backward in a common-sense manner to the origin of the trouble. Problems whose origins may not be found in this manner are pursued through the various system circuits.

#### Remarks


Components of ECI, ETACS, ECS, etc. with ECU do not include 3 and 4 above. For this information, refer to a manual which includes details of these components.



**INSPECTION**


**1. Visual and aural checks**

Check relay operation, blower motor rotation, light illumination, etc. visually or aurally. The flow of current is invisible but can be checked by the operation of the parts.




**2. Simple checks**

For example, if a headlight does not come on and a faulty fuse or poor grounding is suspected, replace the fuse with a new one or ground the light to the body by a jumper wire to determine which part is responsible for the problem.



**3. Checking with instruments**

Use an appropriate instrument in an adequate range and read the indication correctly. You must have sufficient knowledge and experience to handle instruments correctly.




**INSPECTION INSTRUMENTS**

In inspection, make use of the following instruments.


**1. Test lights**

A test light consists of a 12 V bulb and lead wires. It is used to check voltages or shortcircuits.




**2. Self-power test light**

A self-power test light consists of bulb, battery and lead wires connected in series. It is used to check continuity or grounding.




**3. Jumper wire**

A jumper wire is used to close an open circuit. Never use one to connect a power supply directly to a load.



**4. Voltmeter**

A voltmeter is used to measure the circuit voltage. Normally, the positive (red lead) probe is applied to the point of voltage measurement and the negative (black lead) probe to the body ground.



**5. Ohmmeter**


An ohmmeter is used to check continuity or measure resistance of a switch or coil. If the measuring range has been changed, the zero point must be adjusted before measurement.


**CHECKING SWITCHED**

In a circuit diagram, a switch is represented by a symbol and in the idle state.

**1. Normal open or normal close switch**

Switches are classified into those which make the circuit open and those which make the circuit closed when off.






**2. SWITCH CONNECTION**

This figure illustrates a complex switch. The continuity between terminals at each position is as indicated in the table below.

Position \ Terminal No.	1	2	3	4	5	6
OFF						
1st stage	○				○	○
2nd stage	○			○		○
3rd stage	○		○			○
4th stage	○	○				○


**NOTE**

○—○ denotes continuity between terminals.




**CHECKING RELAYS**

1. When current flows through the coil of a relay, its core is magnetized to attract the iron piece, closing (ON) the contact at the tip of the iron piece. When the coil current is turned off, the iron piece is made to return to its original position by a spring, opening the contact (OFF).




2. By using a relay, a heavy current can be turned on and off by a switch of small capacity. For example, in the circuit shown here, when the switch is turned on (closed), current flows to the coil of the relay. Then, its contact is turned on (closed) and the light comes on. The current flowing at this time to the switch is the relay coil current only and is very small.



3. The relays may be classified into the normal open type and the normal close type by their contact construction.

**NOTE**

The deenergized state means that no current is flowing through the coil and the energized state means that current is flowing through the coil.





When a normal close type relay as illustrated here is checked, there should be continuity between terminals (1) and (2) and between terminals 3 and 4 when the relay is deenergized, and the continuity should be lost between terminals 3 and 4 when the battery voltage is applied to the terminals 1 and 2. A relay can be checked in this manner and it cannot be determined if a relay is okay or faulty by checking its state only when it is deenergized (or energized).

## CHECKING FUSES

A blade type fuse has test taps provided to allow checking of the fuse itself without removing it from the fuse block. The fuse is okay if the test light comes on when its one lead is connected to the test taps (one at a time) and the other lead is grounded.

(Change the ignition switch position adequately so that the fuse circuit becomes live.)



## CAUTIONS IN EVENT OF BLOWN FUSE


When a fuse is blown, there are two probable causes as follows: One is that it is blown due to flow of current exceeding its rating. The other is that it is blown due to repeated on/off current flowing through it. Which of the two causes is responsible can be easily determined by visual check as described below.


### (1) Fuse blown due to current exceeding rating

The illustration shown the state of a fuse blown due to this cause. In this case, do not replace the fuse with a new one hastily since a current heavy enough to blow the fuse has flowed through it. First, check the circuit for shorting and check for abnormal electric parts. Only after the correction of such shorting or parts, fuse of the same capacity should be used as a replacement. Never use a fuse of larger capacity than the one that has blown. If such a fuse is used, electric parts or wirings could be damaged before the fuse blows in the event an overcurrent occurs again.


### (2) Fuse blown due to repeated current on/off

The illustration shown the state of a fuse blown due to repeated current on/off. Normally, this type of problem occurs after fairly long period of use and hence is less frequent than the above type. In this case, you may simply replace with a new fuse of the same capacity.






16B0238



16B0240



16C380

## CHECKING CABLES AND WIRES


1. Check connections for looseness, rust and stains.
2. Check terminals and wires for corrosion by battery electrolyte, etc.
3. Check terminals and wires for open circuit or impending open circuit.
4. Check wire insulation and coating for damage, cracks and degrading.
5. Check conductive parts of terminals for contact with other metallic parts (vehicle body and other parts).
6. Check grounding parts to verify that there is complete continuity between attaching bolt(s) and vehicle body.
7. Check for incorrect wiring.
8. Check that wirings are so clamped as to prevent contact with sharp corners of the vehicle body, etc. or hot parts (exhaust manifold, pipe, etc.).
9. Check that wirings are clamped firmly to secure enough clearance from the fan pulley, fan belt and other rotating or moving parts.
10. Check that the wirings between the fixed parts such as the vehicle body and the vibrating parts such as the engine are made with adequate allowance for vibrations.

## HANDLING ON-VEHICLE BATTERY

When checking or servicing does not require power from the on vehicle battery, be sure to disconnect the cable from the battery (-) terminal. This is to prevent problems that could be caused by shorting of the circuit. Disconnect the (-) terminal first and reconnect it last.

### Caution

1. **Before connecting or disconnecting the negative cable, be sure to turn off the ignition switch and the lighting switch.**  
(If this is not done, there is the possibility of semiconductor parts being damaged.)
2. **After completion of the work steps [when the battery's negative (-) terminal is connected], warm up the engine and allow it to idle for approximately five minutes under the conditions described below, in order to stabilize engine control conditions, and then check to be sure that the idling is satisfactory.**  
**Engine coolant temperature: 85–95°C (185–203°F)**  
**Lights, accessories: OFF**  
**Transmission: neutral position (Automatic transmission models: "N" or "P").**  
**Steering wheel: neutral (center) position**




**TROUBLESHOOTING**

A circuit consists of the power supply, switch, relay, load, ground, etc. There are various methods to check a circuit including an overall check, voltage check, shortcircuit check and continuity check. Each of these methods is briefly described in the following.


**1. VOLTAGE CHECK**

- (1) Ground one lead wire of the test light. If a voltmeter is used instead of the test light, ground the grounding side lead wire.
- (2) Connect the other lead wire of the test light to the power side terminal of the switch connector. The test light should come on or the voltmeter should indicate a voltage.
- (3) Then, connect the test light or voltmeter to the motor connector. The test light should not come on, or the voltmeter should indicate no voltage. When the switch is turned on in this state, the test light should come on, or the voltmeter should indicate a voltage, with the motor starting to run.
- (4) The circuit illustrated here is normal but if there is any problem such as the motor failing to run, check voltages beginning at the connector nearest to the motor unit the faulty part is identified.






**2. CHECKING SHORT-CIRCUIT**

Because the fuse has blown, it is probable that there is a short-circuited circuit. Follow the procedures below to narrow down the short-circuit location.







CONTINUED FROM PREVIOUS PAGE

```

    graph TD
      A[Switch ON the switch.  
(The test light illuminates but the illumination light does not.)] --> B[Disconnect the connector of the illumination light.]
      B --> C{The test light remains illuminated.}
      C -- YES --> D[Short-circuit between the switch and the illumination light. Ⓑ]
      C -- NO --> E[Short-circuit between the connector and the illumination light. Ⓒ]
    
```

**3. CHECKING CONTINUITY**

- (1) When the switch is in the OFF position, the self power test light should come on or the ohmmeter should read 0 Ω only when the terminals 2 and 3 are interconnected.
- (2) When the switch is in the ON position, the self power test light should come on or the ohmmeter should read 0 Ω only when the terminals 1 and 4 are interconnected.



---

# CONFIGURATION DIAGRAMS

## CONTENTS


M16VA--

Back Door and Rear Under Floor .....	40	Overall Configuration Diagram .....	26
Dash Panel .....	34	Transmission .....	32
Door .....	39		
Engine Compartment .....	28		
Floor and Roof .....	38		
How to Read Configuration Diagrams .....	27		
Instrument Panel and Floor Console .....	36		



OVERALL CONFIGURATION DIAGRAM

M16VB-



Remarks

- (1) This diagram shows the main wiring harnesses.
- (2) \*: also equipped at the right side.


M16VCAK

# HOW TO READ CONFIGURATION DIAGRAMS


The wiring diagrams are prepared in such a way that the arrangement of connectors for each vehicle, and the routing of each harness, can be easily understood for each individual wiring section.

Indicates the connector number.  
 The connector number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the connector positions.  
 The alphabet letter used as the prefix represents the wiring section in which that connector is used; subsequent numerals make up the number that indicates particular characteristics of that individual connector. As a general rule, numbers are assigned clockwise around the wiring diagram.  
 Note that, if there is a concentration of connectors with the same form (same number of pins), the connectors' colors are noted in order to facilitate identification.

Example: B-01 (Black)





- A : Engine compartment
- B : Transmission
- C : Dash panel
- D : Instrument panel and floor console
- E : Floor and roof
- F : Door
- G : Back door and rear under floor



Represents the part concealed by corrugated tubing.


Indicates ground point.  
 The ground number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the ground points.  
 For detailed information concerning ground points, refer to P.4.

ENGINE COMPARTMENT





- A-01 Headlight washer motor
- A-02 Motor antenna
- A-03 } Starter
- A-04 }
- A-05 Windshield wiper motor
- A-06 Brake fluid level switch
- A-07 Windshield washer motor
- A-08 Front wiring harness and control wiring harness combination
- A-09x } Refer to centralized junction
- thru }
- A-16x }

- A-17 Battery cable (+) and front wiring harness combination
- A-18 Jumper connector
- A-19 Front combination light (LH)



- |      |                                     |      |   |
|------|-------------------------------------|------|---|
| A-20 | Headlight (LH)                      | A-32 | Speed sensor (Front: RH) <ABS>              |
| A-21 | Speed sensor (Front: LH) <ABS>      | A-33 | Shock absorber (Front: RH)                  |
| A-22 | Shock absorber (Front: LH)          |      | <Remote controlled variable shock absorber> |
| A-23 | Magnetic clutch <A/C>               | A-34 | Headlight (RH)                              |
| A-24 | Outside thermo sensor <Multi-meter> | A-35 | Front combination light (RH)                |
| A-25 | Dual pressure switch <A/C>          | A-36 | Front wheel engage switch                   |
| A-26 | Condenser fan motor <A/C>           | A-37 | Solenoid valve A                            |
| A-27 | Horn (LO)                           | A-38 | Solenoid valve B                            |
| A-28 |                                     |      |   |
| A-29 | Horn (HI)                           |      |   |
| A-30 |                                     |      |   |
| A-31 | Oil pressure switch                 |      |   |


ENGINE COMPARTMENT



- A-39 } Hydraulic unit <ABS>
- A-40 }
- A-41 Air flow sensor  
 (with built-in intake  
 air temperature sensor  
 and barometric pressure sensor)
- A-42 Power transistor
- A-43 Fuel pump check connector
- A-44 Ignition timing adjustment
- A-45 } Noise filter
- A-46 }
- A-47 Idle speed control servo
- A-48 Throttle position sensor

- A-49 Control wiring harness and  
 injection wiring harness combination
- A-50 Capacitor
- A-51 Injector No. 5
- A-52 Injector No. 6
- A-53 Injector No. 3





- A-54 Injector No. 4
- A-55 Injector No. 1
- A-56 Injector No. 2
- A-57 Auto-cruise control actuator
- A-58 Purge control solenoid valve
- A-59 Engine coolant temperature gage unit
- A-60 Distributor signal generator
- A-61 Engine coolant temperature switch <AT>
- A-62 Engine coolant temperature sensor
- A-63 Ignition coil
- A-64 Engine coolant temperature switch <A/C>
- A-65 } Alternator
- A-66 }


A-67 Power steering oil pressure switch

16E0381

## TRANSMISSION

Connector symbol

B



B-01 Battery cable and transmission wiring harness combination  
 B-02 Back-up light switch <M/T>  
 B-03 Center differential lock detection switch  
 B-04 Center differential lock operation detection switch  
 B-05 4WD operation detection switch

B-06 2WD/4WD detection switch  
 B-07 High range/low range detection switch  
 B-08 Inhibitor switch <A/T>  
 B-09 Oxygen sensor

---

NOTES




DASH PANEL



Connector Symbol



JUNCTION BLOCK  
Front side view




Rear side view



- C-01 Auto-cruise control main switch
- C-02 Remote controlled mirror switch
- C-03 Rheostat
- C-04 } Combination meter
- C-05 }
- C-06 }
- C-07 }
- C-08 Front wiring harness and body
- C-09 wiring harness combination
- C-10 }
- C-11 }
- C-12 } Combination meter
- C-13 }
- C-14 Defogger switch
- C-15 Hazard light switch
- C-16 No connection (for reed switch)
- C-17 A/C switch
- C-18 Blower motor switch

- C-19 Heater control panel illumination light
- C-20 } Radio
- C-21 }
- C-22 Body wiring harness and A/C wiring harness combination
- C-23 No connection (for diagnosis connector)
- C-24 A/C control unit
- C-25 Air thermo sensor
- C-26 Air inlet sensor
- C-27 Engine control relay
- C-28 }
- C-29 } Control wiring harness and body wiring harness combination
- C-30 }
- C-31 } Body wiring harness and door
- C-32 } wiring harness (RH) combination

- C-33 Front speaker (RH)
- C-34 Resistor
- C-35 Blower motor
- C-36 }
- C-37 } Engine control unit
- C-38 }
- C-39 Diode <ABS>
- C-40 Motor antenna control unit
- C-41 ABS power relay
- C-42 Starter relay
- C-43 4WD indicator control unit
- C-44 } Body wiring harness and
- C-45 } transmission wiring harness
- C-46 combination
- C-47 Buzzer assembly
- C-48 Rear wiper and washer switch
- C-49 Door lock switch




16E0429

- |  |  |  |
|--|--|--|
| C-50 Auto-cruise control unit or spare connector                             | C-62 Clutch switch <M/T-Auto-cruise control system>            | C-79 } Front wiring harness and junction block     |
| C-51 Auto-cruise control switch  | C-63 Front speaker (RH)  | C-80 } Front wiring harness and junction block     |
| C-52 Inside thermo sensor  | C-64 } Body wiring harness and door                            | C-81 } Front wiring harness and junction block     |
| C-53 Spare connector (for hand free microphone)                              | C-65 } wiring harness (LH) combination                         | C-82 Diagnosis connector                           |
| C-54 Stop light switch (2-pin) or no connection <Auto-cruise control system> | C-66 Defogger relay  | C-83 Blower motor relay                            |
| C-55 Stop light switch (4-pin) <Auto-cruise control system> or no connection | C-67 Headlight washer relay                                    | C-84 Accessory socket relay                        |
| C-56 Ignition switch   | C-68 Defogger timer  | C-85 } Body wiring harness and thru junction block |
| C-57 } Column switch   | C-69 Dedicated fuse No. 9 <Sunroof>                            | C-91 } Body wiring harness and thru junction block |
| C-58 } Column switch   | C-70x } Refer to centralized junction                          | C-92 Front wiring harness and junction block       |
| C-59 Key reminder switch   | C-75x } Refer to centralized junction                          |  |
| C-60 Diode <Active trac 4WD system>  | C-76 } Body wiring harness and roof wiring harness combination |  |
| C-61 Clutch switch <M/T>   | C-77 } Body wiring harness and roof wiring harness combination |  |
|  | C-78 Roof wiring harness and junction block                    |  |

# INSTRUMENT PANEL AND FLOOR CONSOLE

<M/T>

Connector symbol




16E0430

- D-01 } Body wiring harness and instrument panel wiring
- D-02 } harness combination
- D-03 Clock
- D-04 Multi-meter
- D-05 Geomagnetic sensor
- D-06 } Accessory socket
- D-07 }
- D-08 No connection
- D-09 -
- D-10 Ashtray illumination light
- D-11 Cigarette lighter illumination light
- D-12 Console wiring harness and rear console wiring harness combination

- D-13 Body wiring harness and console wiring harness combination
- D-14 No connection
- D-15 G sensor <ABS>
- D-16 No connection
- D-17 Seat belt switch
- D-18 Parking brake switch
- D-19 Shock absorber control switch
- D-20 } No connector
- D-21 }
- D-22 } Cigarette lighter
- D-23 }
- D-24 Rear differential lock switch

<A/T>



16E0431


- D-01 } Body wiring harness and instrument panel wiring
- D-02 } harness combination
- D-03 Clock
- D-04 Multi-meter
- D-05 Geomagnetic sensor
- D-06 } Accessory socket
- D-07 }
- D-08 No connection
- D-09 Overdrive switch
- D-10 Ashtray illumination light
- D-11 Cigarette lighter illumination light
- D-12 Console wiring harness and rear console wiring harness combination

- D-13 Body wiring harness and console wiring harness combination
- D-14 No connection
- D-15 G sensor <ABS>
- D-16 No connection
- D-17 Seat belt switch
- D-18 Parking brake switch
- D-19 Shock absorber control switch
- D-20 } No connector
- D-21 }
- D-22 } Cigarette lighter
- D-23 }
- D-24 Rear differential lock switch

## FLOOR AND ROOF

## Connector Symbol

E



16E0433


- |   |   |   |  |
|---|---|---|--|
| E-01  | Reading light   | E-21  | Spare connector (for telephone cable)                        |
| E-02  | Vanity mirror light   | E-22  | Spare connector (for hand free controller)                   |
| E-03  | Dome light  | E-23  | Jumper connector (or hand free controller)                   |
| E-04  | Sunroof control unit  | E-24  | Spare connector (for wireless telephone unit)                |
| E-05  | Sunroof motor   | E-25  | Rear differential lock air pump                              |
| E-06  | Roof wiring harness and sunroof wiring harness combination                | E-26  | Rear differential lock control unit                          |
| E-07  | Sunroof switch  | E-27  | Spare connector (for telephone cable)                        |
| E-08 } Accessory socket   |   | E-28 } Body wiring harness and frame wiring harness thru E-31 } combination |  |
| E-09 }  |   | E-32  | Front door switch (LH)                                       |
| E-10  | Rear door switch (RH)   | E-33  | Body wiring harness and rear door wiring harness combination |
| E-11  | Cargo space light   | E-34  | Rear door switch (LH)  |
| E-12  | Rear speaker (RH)   | E-35  | Rear speaker (LH)  |
| E-13 } ABS control unit   |   | E-36  | Front door switch (RH)                                       |
| E-14 }  |   | E-37  | Body wiring harness and rear door wiring harness combination |
| E-15 }  |   | E-38 } Body wiring harness and control wiring harness combination           |  |
| E-16 } Body wiring harness and back door wiring harness combination |   | E-39 }  |  |
| E-17 }  |   |   |  |
| E-18  | Rear combination light  |   |  |
| E-19  | Variable shock absorber control unit                                      |   |  |
| E-20  | Body wiring harness and rear combination light wiring harness combination |   |  |



**DOOR**

Connector Symbol

**F**




16E0434

- |  |   |
|--|---|
| F-01 Door speaker (RH)                   | F-09 Door lock actuator (Rear: LH)        |
| F-02 Remote control mirror (RH)          | F-10 Power window sub switch (Rear: LH)   |
| F-03 Power window motor (Front: RH)      | F-11 Power window motor (Rear: LH)        |
| F-04 Power window sub switch (Front: RH) | F-12 Door lock actuator (Front: LH)       |
| F-05 Door lock actuator (Front: RH)      | F-13 Door speaker (LH)                    |
| F-06 Power window motor (Rear: RH)       | F-14 Power window motor (Front: LH)       |
| F-07 Power window sub switch (Rear: RH)  | F-15 Power window main switch (Front: LH) |
| F-08 Door lock actuator (Rear: RH)       | F-16 Remote control mirror (LH)           |

## BACK DOOR AND REAR UNDER FLOOR

Connector symbol

G



16E0432

- |   |   |
|---|---|
| G-01 Speed sensor (Rear: RH)  | G-12 Rear combination light (RH)  |
| G-02 Shock absorber (Rear: RH)<br><Remote control variable shock absorber>    | G-13 Rear washer motor  |
| G-03 Defogger (+)   | G-14 Back-up light (RH)   |
| G-04 Back door wiring harness and defogger cable                              | G-15 License plate light  |
| G-05 Shock absorber (Rear: LH)<br><Remote controlled variable shock absorber> | G-16 Door lock actuator (Back door)   |
| G-06 Rear differential lock detection switch                                  | G-17 Fuel pump  |
| G-07 High mount stop light  | G-18 Fuel gage unit   |
| G-08 Back door switch   | G-19 Back-up light  |
| G-09 Back door window glass antenna   | G-20 Shock absorber (Rear: LH)<br><Remote controlled variable shock absorber> |
| G-10 Defogger (-)   | G-21 Speed sensor (Rear: LH) <ABS>  |
| G-11 Rear wiper motor   | G-22 Frame wiring harness and position wiring harness                         |

# CIRCUIT DIAGRAMS

## CONTENTS


M16VE-


Active Trac 4WD System .....	92	Lighting Monitor/Key Reminder/ Seat Belt Warning Buzzer .....	109
Air Conditioner .....	75	MPI System .....	54
Anti-lock Braking System .....	98	Overdrive Control System .....	65
Auto-cruise Control System .....	104	Power Distribution .....	48
Car Telephone .....	112	Power Window .....	67
Central Door Lock System .....	70	Rear Differential Lock System .....	89
Headlight Washer .....	84	Rear Wiper and Washer .....	82
Heater .....	73	Remote Controlled Mirror .....	86
How to Read Circuits Diagrams .....	42	Remote Control Variable Shock Absorbers System .....	95
		Sunroof .....	87
		Windshield Wiper and Washer .....	80

# HOW TO READ CIRCUIT DIAGRAMS

The diagrams show the circuits from the fuse (or fusible link) of each system all the way to the ground point.

These diagrams are prepared in such a way that the flow of electricity is easily understood, using a layout that shows the power source at the upper part and the ground point at the lower side.






Indicate terminal numbers.

Intermediate connectors that are the same are indicated by connecting them by a broken line.

Indicates continuation from ▽ on the preceding page.

If two or more connectors are connected at the same device, identical connectors are connected by a broken line.

Indicates the direction of flow (input or output relative to the control unit) of electricity.



Indicates flow of current (as regulated by the control unit) downward from above or upward from below.


Indicates the branching point of harnesses of different diameter and/or color.




















Indicates the chassis ground point. (The number is the same as used in "GROUNDING". (Refer to P.4.)

Indicates that there is a continuation of the harness from one page to the adjoining page.

Indicates a spare terminal if for some reason the device is not equipped.

CONNECTOR/GROUND INDICATORS



No.	Layout indications	Symbol	Description
Connector indications	① Male 		Male and female terminals are distinguished one from the other as shown in the illustration: connectors framed by a double line are male terminals, and those framed by a single line are female terminals.
	– Female 		
Connector symbol indications	Equipment  Intermediate connector  16A0333		Symbols are shown as facing in the direction indicated in the illustration. For connections to the equipment is shown, for intermediate connectors, the symbol for the connector at the male side is shown.
Connector connection indications	③ Direct-connect type 		There are two types of connection between the equipment and the connector at the harness: the type by which there is direct plug-in to the equipment (the direct-connect type), and the type by which connection is with the harness connector at the equipment (the type with harness); these are individually identified as shown in the illustration.
	④ Type with harness  16A0334		
	⑤ Intermediate connector  16A0339		
Ground indications	⑥ Chassis ground  16E0265		There are three types of grounds: the chassis ground, the equipment ground, and the ground within the control unit; these are individually identified as shown in the illustration.
	⑦ Equipment ground  16E0302		
	⑧ Ground within control unit  16E0271		

**SYMBOLS**

The various devices and equipment identified in circuit diagrams are represented by the symbols described below.


Battery 	Body ground 	Single bulb 	Resistor 	Diode 	Capacitor 
Fuse 	Equipment ground 	Dual bulb 	Variable resistor 	Zener diode 	Crossing of wires without connection 
Fusible link 	Ground within ECU 	Speaker 	Coil 	Transistor 	Crossing of wires with connection 
Connector Female side  Male side 	Motor 	Horn 	Pulse generator 	Buzzer 	Chime 
Thyristor 	Piezo-electric element 	Thermister 	Light-emitting diode 	Photo diode 	Photo transistor 

16A0252

**WIRING COLOR CODES**

Wire colors are identified by the following color codes.

Example: 1.25F-GB



Code	Wire color	Code	Wire color
B	Black	LI	Light blue
Br	Brown	O	Orange
G	Green	P	Pink
Gr	Gray	R	Red
L	Blue	Y	Yellow
Lg	Light green	W	White
Sb	Silver		

- (1) No code indicates 0.5 mm<sup>2</sup> (.0008 in.<sup>2</sup>).
- (2) Cable color code in parentheses indicates 0.3 mm<sup>2</sup> (.0005 in.<sup>2</sup>).

**NOTE**

If a cable has two colors, the first of the two color code characters indicates the basic color (color of the cable coating) and the second indicates the marking color.





---


NOTES




# POWER DISTRIBUTION









Remark  
 ·The above circuit diagram shows the current flow at the ignition key position "ACC", "ON" and "ST" combined. Be sure trace the appropriate circuit depending on the ignition key position.








# MPI SYSTEM

<M/T>





1	2	3	4	5	6
10	11	12	13	14	15
16	17	18	19	20	21


1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18


1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24














# MPI SYSTEM

<A/T>











## COMPONENTS LOCATION























Name	Symbol	Name	Symbol
Air conditioner compressor relay	A	Ignition coil (power transistor)	K
Air conditioner switch	B	Ignition timing adjustment connector	L
Air flow sensor (With intake air temperature sensor and barometric pressure sensor)	C	Injector	M
Engine control relay	D	Inhibitor switch (Vehicles with automatic transmission)	N
Crank angle sensor	E	Oxygen sensor	O
Engine control unit	F	Power steering fluid pressure switch	P
Engine coolant temperature sensor	G	Purge control solenoid valve	Q
Check engine warning light	H	Self-diagnosis connector	R
Fuel pump check connector	I	Throttle position sensor (with idle position sensor)	S
Idle speed control servo	J	Vehicle speed sensor (reed switch)	T

## NOTE


The "Name" column is arranged in alphabetical order.







# OVERDRIVE CONTROL SYSTEM



RX35-AC-00701-N


TSB Revision

ENGINE COOLANT TEMPERATURE SWITCH  
 OFF - ON : 50° C (122° F) (122° F)  
 ON - OFF : 46° C (115° F)


COMPONENTS LOCATION

Name	Symbol
Engine coolant temperature switch	A
Overdrive relay	B


NOTE  
The "Name" column is arranged in alphabetical order




16E0128



16E0275





16E0435




16E0407


**POWER WINDOW  
COMPONENTS LOCATION**

Name	Symbol
Power window relay	A




POWER WINDOW






CENTRAL DOOR LOCK SYSTEM



KK35-AC-01102-W


TSB Revision






COMPONENTS LOCATION

Name	Symbol
Door lock control relay	A




16E0275





16E0405

HEATER





## COMPONENTS LOCATION

Name	Symbol
Blower motor relay	A



**AIR CONDITIONER**














COMPONENTS LOCATION

Name	Symbol	Name	Symbol
A/C compressor relay	B	Blower motor relay	E
A/C control unit	C	Condenser fan motor relay	B
Air inlet sensor	D	Engine coolant temperature switch	A
Air thermo sensor	D		


NOTE  
The "Name" column is arranged in alphabetical order.








# WINDSHIELD WIPER AND WASHER




Remark  
\*: Vehicles with variable intermittent wiper.

**COMPONENTS LOCATION**

Name	Symbol
Intermittent wiper relay	A




16E0275





18E0223

# REAR WIPER AND WASHER




COMPONENTS LOCATION

Name	Symbol
Rear intermittent wiper relay	A




HEADLIGHT WASHER




COMPONENTS LOCATION

Name	Symbol
Headlight washer relay	A




16E0275




16E0406

# REMOTE CONTROLLED MIRROR






SUNROOF




COMPONENTS LOCATION

Name	Symbol
Sunroof control unit	A




18E0004




16W1761

# REAR DIFFERENTIAL LOCK SYSTEM COMPONENTS LOCATION

Name	Symbol
Rear differential lock control unit	A





16E0004




16E0438


# REAR DIFFERENTIAL LOCK SYSTEM





# ACTIVE TRAC 4WD SYSTEM







TSB Revision

COMPONENT LOCATION


Name	Symbol
4WD indicator control unit	A






# REMOTE CONTROL VARIABLE SHOCK ABSORBERS SYSTEM COMPONENTS LOCATION

Name	Symbol
Variable shock absorbers control unit	A





18E0004




16E0298

# REMOTE CONTROL VARIABLE SHOCK ABSORBERS SYSTEM







# ANTI-LOCK BRAKING SYSTEM





ABS CONTROL UNIT





NOTE  
\*: Applicable for some models only






COMPONENTS LOCATION


Name	Symbol	Name	Symbol
ABS control unit	C	G sensor	E
ABS motor relay	A	Speed sensor (front)	D
ABS valve relay	A	Speed sensor (rear)	F
ABS power relay	B	—	—

NOTE


The "Name" column is arranged in alphabetical order.




16E0128




14E0003




16E0275



16E0411




18E0004






16E0397








18E0003




# AUTO-CRUISE CONTROL SYSTEM












COMPONENTS LOCATION

Name	Symbol
Auto-cruise control unit	A





# LIGHTING MONITOR/KEY REMINDER/ SEAT BELT WARNING BUZZER



KX35-AC-Q1506-N

COMPONENTS LOCATION

Name	Symbol
Buzzer assembly	A







---

NOTES

CAR TELEPHONE (CIRCUIT ONLY)







# ENGINE ELECTRICAL

## CONTENTS

<b>CHARGING SYSTEM</b> .....	<b>2</b>	Inspection Using an Analyzer .....	30
<b>ALTERNATOR</b> .....	<b>11</b>	Inspection of Primary Ignition Voltage .....	34
<b>SERVICE ADJUSTMENT PROCEDURES</b> ...	<b>5</b>	Inspection of Secondary Ignition Voltage .....	30
Checking with an Analyzer .....	9	Spark Plug Cable Test .....	29
Charging System Inspection .....	5	Spark Plug Test .....	29
Output Current Test .....	6	<b>SPECIAL TOOL</b> .....	<b>26</b>
Regulated Voltage Test .....	7	<b>SPECIFICATIONS</b> .....	<b>26</b>
Voltage Drop Test of Alternator Out Put Wire .....	5	General Specifications .....	26
<b>SPECIFICATIONS</b> .....	<b>2</b>	Service Specifications .....	26
General Specifications .....	2	<b>TROUBLESHOOTING</b> .....	<b>27</b>
Service Specifications .....	2	<b>STARTING SYSTEM</b> .....	<b>16</b>
<b>TROUBLESHOOTING</b> .....	<b>3</b>	<b>SPECIFICATIONS</b> .....	<b>16</b>
<b>IGNITION SYSTEM</b> .....	<b>26</b>	General Specifications .....	16
<b>DISTRIBUTOR</b> .....	<b>40</b>	Service Specifications .....	16
<b>IGNITION SYSTEM</b> .....	<b>37</b>	<b>STARTER MOTOR</b> .....	<b>19</b>
<b>SERVICE ADJUSTMENT PROCEDURES</b> ...	<b>29</b>	<b>TROUBLESHOOTING</b> .....	<b>17</b>
Hightention Cable Spark Test .....	29		

**CHARGING SYSTEM****SPECIFICATIONS****GENERAL SPECIFICATIONS**

M16EB--

**ALTERNATOR**

Items	Specifications
Type	Battery voltage sensing
Rated output	12/75
Voltage regulator	Electronic built-in type

**SERVICE SPECIFICATIONS**

M16EC--

Items	Specifications
Alternator	
Standard values	
Regulated voltage	V
Ambient temp. at voltage regulator	
–20°C (–4°F)	14.2–15.4
20°C (68°F)	13.9–14.9
60°C (140°F)	13.4–14.6
80°C (176°C)	13.1–14.5
Slip ring O.D.	mm (in.) 22.7 (.894)
Field coil resistance	$\Omega$ 3–5
Limit	
Output current	A Min. 52.5
Slip ring O.D.	mm (in.) 22.1 (.870)

**TROUBLESHOOTING**

M16EHA

**OPERATION**

**When engine is stopped**

When the ignition switch is switched to the "ON" position, electricity flows from the "L" terminal of the alternator to the field coil, and at the same time the charging warning light illuminates.

**When engine is being started/has started**

When the engine is started, charging voltage is applied to the "L" terminal of the alternator, with the result that the charging warning light is extinguished.

In addition, because battery voltage is applied to the "S" terminal of the alternator, this battery voltage is monitored at the IC voltage regulator, thus switching ON and OFF the current to the field coil and thereby controlling the output voltage of the alternator.

Power is supplied to each load from the "B" terminal of the alternator.

**NOTE**


The alternator relay functions as a back-up for the flow of electricity to the field coil if there is a disconnection or damaged wiring of the charging warning light.

**TROUBLESHOOTING HINTS**


1. Charging warning light does not go on when the ignition switch is turned to "ON", before the engine starts.
  - Check the bulb.
2. Charging warning light fails to go off once the engine starts.
  - Check the IC voltage regulator (located within the alternator).
3. Discharged or overcharged battery.
  - Check the IC voltage regulator (located within the alternator).
4. The charging warning light illuminates dimly.
  - Check the diode (within the combination meter) for a short-circuit.

**COMPONENT LOCATION**

Name	Symbol
Alternator relay	A




**A** 16E0128



16E0400

CIRCUIT DIAGRAM





## SERVICE ADJUSTMENT PROCEDURES

### CHARGING SYSTEM INSPECTION M16E1AN

#### VOLTAGE DROP TEST OF ALTERNATOR OUTPUT WIRE

This test judges whether or not the wiring (including the fusible link) between the alternator B terminal and the battery (+) terminal is sound by the voltage drop method.


#### Preparation

- (1) Turn the ignition switch to "OFF".
- (2) Disconnect the battery ground cable.
- (3) Disconnect the alternator output lead from the alternator "B" terminal.
- (4) Connect a DC ammeter in series to the "B" terminal and the disconnected output lead. Connect the (+) lead of the ammeter to the "B" terminal and the (-) lead to the disconnected output wire.

#### NOTE

Use of a clamp type ammeter that can measure current without disconnecting the harness is preferred. The reason is that when checking a vehicle that has a low output current due to poor connection of the alternator "B" terminal, such poor connection is corrected as the "B" terminal is loosened and a test ammeter is connected in its place and as a result, causes for the trouble may not be determined.

- (5) Connect a digital voltmeter between the alternator "B" terminal and battery (+) terminal. Connect the (+) lead wire of the voltmeter to the "B" terminal and the (-) lead wire to the battery (+) terminal.
- (6) Connect the battery ground cable.
- (7) Leave the hood open.



16P0481

#### Test

- (1) Start the engine.
- (2) Turn on or off the headlights and small lights and adjust the engine speed so that the ammeter reads 20 A and read off the voltmeter indication under this condition.

#### Result

- (1) It is okay if the voltmeter indicates the standard value.

#### Standard value: 0.2 V max.

- (2) If the voltmeter indicates a value that is larger than the standard value, poor wiring is suspected, in which case check the wiring from the alternator "B" terminal to fusible link to battery (+) terminal. Check for loose connection, color change due to overheated harness, etc. and correct them before testing again.

- (3) Upon completion of the test, set the engine speed at idle. Turn off the lights and turn off the ignition switch.
- (4) Disconnect the battery ground cable.
- (5) Disconnect the ammeter and voltmeter that have been connected for the test purpose.
- (6) Connect the alternator output wire to the alternator "B" terminal.
- (7) Connect the battery ground cable.

**OUTPUT CURRENT TEST**

This test judges whether or not the alternator gives an output current that is equivalent to the nominal output.

**Preparation**

(1) Prior to the test, check the following items and correct as necessary.

- (a) Check the battery installed in the vehicle to ensure that it is in sound state\*. The battery checking method is described in "BATTERY".

**NOTE**

\*The battery that is used to test the output current should be one that has been rather discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.


- (b) Check tension of the alternator drive belt. The belt tension check method is described in "GROUP 11 – Service Adjustment Procedures."

- (2) Turn off the ignition switch.  
 (3) Disconnect the battery ground cable.  
 (4) Disconnect the alternator output wire from the alternator "B" terminal.  
 (5) Connect a DC ammeter in series between the "B" terminal and the disconnected output wire. Connect the (+) lead of the ammeter to the "B" terminal and connect the (-) lead wire to the disconnected output wire.

**NOTE**

Tighten each connection by bolt and nut securely as a heavy current will flow. Do not rely on clips.

- (6) Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a sound ground.  
 (7) Set the engine tachometer and connect the battery ground cable.  
 (8) Leave the engine hood open.



Voltmeter

Ammeter

16P0482

**Test**

- (1) Check to see that the voltmeter reads the same value as the battery voltage. If the voltmeter reads 0V, an open circuit in the wire between the alternator "B" terminal and battery (-) terminal, a blown fusible link or poor grounding is suspected.  
 (2) Turn on the headlight switch and start the engine.

- (3) Set the headlight at high beam and the heater blower switch at HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

**NOTE**

After the engine start up, the charging current quickly drops, therefore, above operation must be done quickly to read maximum current value correctly.

**Result**

- (1) The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is normal, remove the alternator from the vehicle and check it.

**Limit: 52.5A min.**

**Caution**

- (a) The nominal output current value is shown on the name plate affixed to the alternator body.
- (b) The output current value changes with the electrical load and the temperature of the alternator itself. Therefore, the nominal output current may not be obtained if the vehicle electrical load at the time of test is small.

In such a case, keep the headlights on to cause discharge of the battery or use lights of another vehicle as a load to increase the electrical load. The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high. In such a case, reduce the temperature before testing again.

- (2) Upon completion of the output current test, lower the engine speed to the idle speed and turn off the ignition switch.
- (3) Disconnect the battery ground cable.
- (4) Remove the test ammeter and voltmeter and the engine tachometer.
- (5) Connect the alternator output wire to the alternator "B" terminal.
- (6) Connect the battery ground cable.


**REGULATED VOLTAGE TEST**

The purpose of this test is to check that the electronic voltage regulator controls the voltage correctly.

**Preparation**

- (1) Prior to the test, check the following items and correct if necessary.
  - (a) Check the battery installed on the vehicle to see that it is fully charged. For battery checking method, see "BATTERY"
  - (b) Check the alternator drive belt tension. For belt tension check, see "GROUP 11 – Service Adjustment Procedures."

- (2) Turn the ignition switch to "OFF".
- (3) Disconnect the battery ground cable.
- (4) Connect a digital voltmeter between the "S" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "S" terminal of the alternator, inserting from the wire side of the 2-way connector and connect the (–) lead to sound ground or battery (–) terminal.



6EL252

- (5) Disconnect the alternator output wire from the alternator "B" terminal.
- (6) Connect a DC ammeter in series between the "B" terminal and the disconnected output wire. Connect the (+) lead of the ammeter to the "B" terminal and connect the (–) lead wire to the disconnected output wire.
- (7) Set the engine tachometer and connect the battery ground cable.

**Test**

- (1) Turn on the ignition switch and check that the voltmeter indicates the following value.

**Voltage: System voltage**

If it reads 0V, there is an open circuit in the wire between the alternator "S" terminal and the battery (+) or the fusible link is blown.

- (2) Start the engine. Keep all lights and accessories off.
- (3) Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less.


**Result**

- (1) If the voltmeter reading agrees with the value listed in the regulating voltage table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the alternator is faulty.

**Regulating voltage table**

Voltage regulator ambient temperature °C (°F)	Regulating voltage V
-20 (-4)	14.2 – 15.4
20 (68)	13.9 – 14.9
60 (140)	13.4 – 14.6
80 (176)	13.1 – 14.5

- (2) Upon completion of the test, set the engine speed at idle and turn off the ignition switch.
- (3) Disconnect the battery ground cable.
- (4) Remove the test voltmeter and ammeter and the engine tachometer.
- (5) Connect the alternator output wire to the alternator "B" terminal.
- (6) Connect the battery ground cable.



**CHECKING WITH AN ANALYZER**


**MEASUREMENT METHOD**

Connect the analyzer special patterns pick-up to the alternator B terminal.


**STANDARD WAVEFORM**

Observation Conditions

Function	Special patterns
Pattern height	Variable
Variable knob	Adjust while viewing the wave pattern
Pattern selector	Raster
Engine revolutions	Idle (700 rpm)



7EL0115



7EL0119






**NOTE**

Furthermore, the voltage waveform of the alternator B terminal can undulate as shown at left. This waveform is produced when the regulator operates according to fluctuations in the alternator load (current), and is normal for the alternator.

EXAMPLES OF ABNORMAL WAVEFORMS

NOTE


1. The size of the waveform patterns differs largely depending on the adjustment of the variable knob on the analyzer.
2. Identification of abnormal waveforms is easier when there is a large output current (regulator is not operating). (Waveforms can be observed when the headlights are illuminated.)
3. Check the conditions of the charge light (illuminated/not illuminated) also, and carry out a total check.

Abnormal waveforms	Problem cause
<p>Example 1</p>  <p style="text-align: right;">7EL0120</p>	<ul style="list-style-type: none"> <li>● Open diode</li> </ul>
<p>Example 2</p>  <p style="text-align: right;">7EL0121</p>	<ul style="list-style-type: none"> <li>● Short in diode</li> </ul>
<p>Example 3</p>  <p style="text-align: right;">7EL0122</p>	<ul style="list-style-type: none"> <li>● Broken wire in stator coil</li> </ul>
<p>Example 4</p>  <p style="text-align: right;">7EL0123</p>	<ul style="list-style-type: none"> <li>● Short in stator coil</li> </ul>
<p>Example 5</p>  <p>NOTE: At this time, the charge light is illuminated.</p> <p style="text-align: right;">7EL0124</p>	<ul style="list-style-type: none"> <li>● Open supplementary diode</li> </ul>

# ALTERNATOR

## REMOVAL AND INSTALLATION


**Post-installation Operation**  
 • Adjustment of the Drive Belt Tension (Refer to GROUP 14 – Service Adjustment Procedures.)



**Removal steps**


1. Connection for alternator connector
2. Alternator cover
3. Alternator

## DISASSEMBLY AND REASSEMBLY



**Disassembly steps**

- |                            |  |                   |  |
|----------------------------|--|-------------------|--|
| <p>↔</p> <p>↔</p> <p>↔</p> | <ol style="list-style-type: none"> <li>1. Pulley</li> <li>2. Seal</li> <li>3. Rotor assembly</li> <li>4. Rear bearing</li> <li>5. Bearing retainer</li> <li>6. Front bearing</li> <li>7. Front bracket</li> <li>8. Stator</li> <li>9. Terminal</li> <li>10. Plate</li> </ol> | <p>↔</p> <p>↔</p> | <ol style="list-style-type: none"> <li>11. Regulator and brush holder</li> <li>12. Brush</li> <li>13. Brush spring</li> <li>14. Slinger</li> <li>15. Rectifier assembly</li> <li>16. Rear bracket</li> </ol> |
|----------------------------|--|-------------------|--|




### SERVICE POINTS OF DISASSEMBLY SEPARATING THE STATOR AND FRONT BRACKET

Insert plain screwdriver between front bracket and stator core and pry downward.


#### Caution

Do not insert screwdriver too deep, as there is danger of damage to stator coil.



### 1. REMOVAL OF ALTERNATOR PULLEY

- (1) Clamp the rotor in a vise with soft jaws.
- (2) After removing the nut, remove the pulley and front bracket from the rotor.




### 8. REMOVAL OF STATOR/11. REGULATOR AND BRUSH HOLDER

- (1) When removing stator, unsolder three stator leads soldered to main diodes on rectifier.
- (2) When removing rectifier from brush holder, unsolder two soldered points to rectifier.

#### Caution

- (1) When soldering or unsoldering, use care to make sure that heat of soldering iron is not transmitted to diodes for a long period. Finish soldering or unsoldering in as short a time as possible.
- (2) Use care that no undue force is exerted to leads of diodes.






6EL115

**INSPECTION****ROTOR**


- (1) Check field coil for continuity. Check to ensure that there is continuity between slip rings. If resistance is extremely small, it means that there is a short. If there is no continuity or if there is short circuit, replace rotor assembly.

**Resistance value: Approx 3–5  $\Omega$**



6EL116


- (2) Check field coil for grounding. Check to ensure that there is no continuity between slip ring and core. If there is continuity, replace rotor assembly.



3EL010


**STATOR**

- (1) Make continuity test on stator coil. Check to ensure that there is continuity between coil leads. If there is no continuity, replace stator assembly.



3EL011


- (2) Check coil for grounding. Check to ensure that there is no continuity between coil and core. If there is continuity, replace stator assembly.




7EL0011

**RECTIFIERS****(1) Positive Rectifier Test**


Check for continuity between positive rectifier and stator coil lead connection terminal with an ohmmeter. If there is continuity in both directions, diode is shorted. Replace rectifier assembly.

**(2) Negative Rectifier Test**


Check for continuity between negative rectifier and stator coil lead connection terminal. If there is continuity in both direction, diode is shorted, and rectifier assembly must be replaced.

**(3) Diode Trio Test**


Check three diodes for continuity by connecting an ammeter to both ends of each diode. If there is no continuity in both directions, diode is faulty and heatsink assembly must be replaced.

**BRUSH REPLACEMENT**

- (1) Replace brush by the following procedures if it has been worn to limit line.




- (2) Unsolder pigtail and remove old brush and spring.



- (3) Install brush spring and new brush in brush holder.
- (4) Insert the brush to where there is a space 2 to 3 mm (.079 to .118 in.) between the limit line and the end of the brush holder.



(5) Solder pigtail to brush holder as shown in the illustration.



**SERVICE POINT OF REASSEMBLY**

**3. INSTALLATION OF ROTOR ASSEMBLY**

Before rotor is attached to rear bracket, insert wire through small hole made in rear bracket to lift brush. After rotor has been installed, remove the wire.



# STARTING SYSTEM SPECIFICATIONS

## GENERAL SPECIFICATIONS

M16FB--

### STARTER MOTOR

Items	Specifications
Type	Reduction drive
Rated output	1.2/12
No. of pinion teeth	8

## SERVICE SPECIFICATIONS

M16FC--

Items	Specifications
Starter motor	
Standard values	
Starter motor	
Free running characteristics	
Terminal voltage	V 11
Current	A 90 or less
Speed	rpm 3,000 or more
Pinion gap	mm (in.) 0.5–2.0 (.020–.079)
Commutator runout	mm (in.) 0.05 (.0020)
Commutator diameter	mm (in.) 29.4 (1.157)
Under-cut depth	mm (in.) 0.5 (.020)
Limit	
Commutator runout	mm (in.) 0.1 (.004)
Commutator diameter	mm (in.) 28.8 (1.134)

**TROUBLESHOOTING**

M16FHAH

**OPERATION**

- For models equipped with the M/T, the clutch switch contact is switched OFF when the clutch pedal is depressed; when the ignition switch is then switched to the "ST" position, electricity flows to the starter relay and the starter motor, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.

**NOTE**

If the ignition switch is switched to the "ST" position without the clutch pedal being depressed, electricity flows to the starter relay (coil), the clutch switch (contacts) and to ground, with the result that the contacts of the starter relay are switched OFF, and, because the power to the starter motor is thereby interrupted, the starter motor is not activated.

- For models equipped with the A/T, when the ignition switch is switched to the "ST" position while the selector lever is at the "P" or "N" position, the contact (magnetic switch) of the starter is switched ON and the starter motor is activated.



**TROUBLESHOOTING HINTS**

The starter motor does not operate at all.


- Check the starter (coil).
- Check for poor contact at the battery terminals and starter.
- Check inhibitor switch.
- Check clutch pedal switch.
- Check starter relay.
- Check key reminder switch.

**COMPONENTS LOCATION**

Name	Symbol
Starter relay	A



CIRCUIT DIAGRAM




KX35-AC-00201-N

**STARTER MOTOR****REMOVAL AND INSTALLATION**

M16FJAW

**Pre-removal and Post-installation Operation**

- Draining and Refilling of Automatic Transmission Fluid (Refer to GROUP 23 – Service Adjustment Procedures.)
- Removal and Installation of Oil Cooler Tube (Refer to GROUP 23 – Transmission Oil Cooler.)








16W1694

**Removal steps**

1. Connection for starter motor connector
2. Starter cover
3. Starter motor

**SERVICE POINTS OF REMOVAL****3. REMOVAL OF STARTER MOTOR**

Models with manual transmission  
Jack up the vehicle; then remove (from below the body) the starter motor mounting bolts, and separate the starter motor from the transmission assembly.



## INSPECTION

### PINION GAP ADJUSTMENT

- (1) Disconnect field coil wire from "M"-terminal of magnetic switch.
- (2) Connect a 12V battery between "S"-terminal and "M"-terminal.
- (3) Set switch to "ON", and pinion will move out.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (4) Check pinion to stopper clearance (pinion gap) with a feeler gage.

**Pinion gap: 0.5–2.0 mm (.020–.079 in.)**

- (5) If pinion gap is out of specification, adjust by adding or removing gaskets between magnetic switch and front bracket.

### PULL-IN TEST OF MAGNETIC SWITCH

- (1) Disconnect field coil wire from "M"-terminal of magnetic switch.
- (2) Connect a 12V battery between "S"-terminal and "M"-terminal.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (3) If pinion moves out, then pull-in coil is good. If it doesn't, replace magnetic switch.

### HOLD-IN TEST OF MAGNETIC SWITCH


- (1) Disconnect field coil wire from "M"-terminal of magnetic switch.
- (2) Connect a 12V battery between "S"-terminal and body.

#### Caution

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (3) If pinion remains out, everything is in order. If pinion moves in, hold-in circuit is open. Replace magnetic switch.






**FREE RUNNING TEST**

- (1) Place starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows:
- (2) Connect a test ammeter (100-ampere scale) and carbon pile rheostat in series with battery positive post and starter motor terminal.
- (3) Connect a voltmeter (15-volt scale) across starter motor.
- (4) Rotate carbon pile to full-resistance position.
- (5) Connect battery cable from battery negative post to starter motor body.
- (6) Adjust rheostat until the battery voltage shown by the voltmeter is 11V.
- (7) Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

**Current: max. 90 Amps**




**RETURN TEST OF MAGNETIC SWITCH**

- (1) Disconnect field coil wire from "M"-terminal of magnetic switch.
- (2) Connect a 12V battery between "M"-terminal and body.

**Caution**

**This test must be performed quickly (in less than 10 seconds) to prevent coil from burning.**

- (3) Pull pinion out and release. If pinion quickly returns to its original position, everything is in order. If it doesn't, replace magnetic switch.




**STARTER RELAY**

- (1) Remove the starter relay.
- (2) Connect battery to terminal 1 and check continuity between terminals with terminal 2 grounded.


Power is supplied	3-4 terminals	No continuity
Power is not supplied	3-4 terminals	Continuity
	1-2 terminals	Continuity

DISASSEMBLY AND REASSEMBLY



Disassembly steps

- 1. Screw
- 2. Magnetic switch
- 3. Screw
- 4. Screw
- 5. Rear bracket
- 6. Brush holder
- 7. Brush
- 8. Rear bearing
- ↔↔ 9. Armature
- ↔↔ 10. Yoke assembly
- 11. Ball
- 12. Packing A
- 13. Packing B
- 14. Plate
- 15. Planetary gear
- 16. Lever
- ↔↔↔↔ 17. Snap ring
- ↔↔↔↔ 18. Stop ring
- 19. Overrunning clutch
- 20. Internal gear
- 21. Planetary gear holder
- 22. Front bracket




6EL199

SERVICE POINTS OF DISASSEMBLY

9. REMOVAL OF ARMATURE / 11. BALL


Caution

When removing the armature, take care not to lose the ball (which is used as a bearing) in the armature end.



**17. REMOVAL OF SNAP RING / 18. STOP RING**

(1) Press the stop ring, by using an appropriate socket wrench, to the snap ring side.



(2) After removing the snap ring (by using snap-ring pliers), remove the stop ring and the overrunning clutch.

**CLEANING STARTER MOTOR PARTS**

1. Do not immerse parts in cleaning solvent. Immersing the yoke and field coil assembly and/or armature will damage insulation. Wipe these parts with a cloth only.
2. Do not immerse drive unit in cleaning solvent. Overrunning clutch is pre-lubricated at the factory and solvent will wash lubrication from clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.


**INSPECTION**

**CHECKING THE COMMUTATOR**

(1) Place the armature on a pair of V-blocks, and check the deflection by using a dial gage.

**Standard value: 0.05 mm (.0020 in.)**


**Limit: 0.1 mm (.0040 in.)**




(2) Check the outer diameter of the commutator.


**Standard value: 29.4 mm (1.158 in.)**

**Limit: 28.4 mm (1.118 in.)**






- (3) Check the depth of the undercut between segments.  
**Standard value: 0.5 mm (.020 in.)**



#### BRUSH HOLDER

Check for continuity between brush holder plate and brush holder.  
 The normal condition is non-continuity.




#### OVERRUNNING CLUTCH

1. While holding clutch housing, rotate the pinion. Drive pinion should rotate smoothly in one direction, but should not rotate in opposite direction. If clutch does not function properly, replace overrunning clutch assembly.
2. Inspect pinion for wear or burrs. If pinion is worn or burred, replace overrunning clutch assembly. If pinion is damaged, also inspect ring gear for wear or burrs.


#### FRONT AND REAR BRACKET BUSHING

Inspect bushing for wear or burrs. If bushing is worn or burred, replace front bracket assembly or rear bracket assembly.




#### REPLACEMENT OF BRUSHES AND SPRINGS

1. Brushes that are worn beyond wear limit line, or oil-soaked, should be replaced.
2. When replacing field coil brushes, crush worn brush with pliers, taking care not to damage pigtail.




3. Sand pigtail end with sandpaper to ensure good soldering.
4. Insert pigtail into hole provided in new brush and solder it. Make sure that pigtail and excess solder do not come out onto brush surface.
5. When replacing ground brush, slide the brush from brush holder by prying retaining spring back.



**TESTING ARMATURE**


**TESTING ARMATURE FOR SHORT-CIRCUIT**

1. Place armature in a growler.
2. Hold a thin steel blade parallel and just above while rotating armature slowly in growler. A shorted armature will cause blade to vibrate and be attracted to the core. Replace shorted armature.




**TESTING ARMATURE FOR GROUNDING**

Check the insulation between the armature coil cores and the commutator segments. They are normal if there is no continuity.



**CHECKING FOR ARMATURE COIL WIRING DAMAGE / DISCONNECTION**

Check for continuity between segments. The condition is normal if there is continuity.



**SERVICE POINTS OF REASSEMBLY**

**18. INSTALLATION OF STOP RING / 17. SNAP RING**

Using a suitable pulling tool, pull overrunning clutch stop ring over snap ring.

**IGNITION SYSTEM****SPECIFICATIONS****GENERAL SPECIFICATIONS**

M16GB--

**DISTRIBUTOR**

Items	Specifications
Identification No.	T5T42371
Part No.	MD148008
Advance mechanism	Electronic control
Firing order	1-2-3-4-5-6

**IGNITION COIL**

Items	Specifications
Type	Mold
Identification No.	F-504
Part No.	MD131711

**SPARK PLUG**

Items	Specifications
NGK	BPR5ES-11
NIPPON DENSO	W16EPR11
CHAMPION	RN11YC4


**SERVICE SPECIFICATIONS**

M16GC--

Items	Specifications
Standard value	
Ignition coil	
Primary coil resistance at 20°C (68°F)	$\Omega$ .72-.88
Secondary coil resistance at 20°C (68°F)	k $\Omega$ 10.3-13.9
Spark plug gap	mm (in.) 1.0-1.1 (.039-.043)

**SPECIAL TOOL**

M16GG--

Tool	Number	Name	Use
	MB991348	Test harness set	Inspection of ignition primary voltage (power transistor connection)

**TROUBLESHOOTING**

M16GHA0


**OPERATION**

- This action induces high voltage in the secondary winding of the ignition coil. From the ignition coil, the secondary winding current produced flows through the distributor and spark plug to ground, thus causing ignition in each cylinder.
- When the ignition switch is turned to "ON", battery voltage is applied to the ignition coil primary winding.
- As the distributor shaft rotates, ignition signals are transmitted from the multi-point injection control unit to the power transistor.
- These signals activate the power transistor to cause ignition coil primary winding current to flow through the ignition coil negative terminal through the power transistor to ground, or be interrupted, repeatedly.



**TROUBLESHOOTING HINTS**

1. Engine cranks, but does not start.
  - 1) Spark is insufficient or does not occurs at all (on spark plug)
    - Check ignition coil.
    - Check distributor.
    - Check power transistor.
    - Check spark plugs.
    - Check spark plug cable.
  - 2) Spark is good.
    - Check ignition timing.
2. Engine idles roughly or stalls.
  - Check spark plugs.
  - Check ignition timing.
  - Check ignition coil.
  - Check spark plug cable.
3. Poor acceleration
  - Check ignition timing.
4. Engine overheats or consumes excessive fuel.
  - Check ignition timing.


**COMPONENT LOCATION**






Name	Symbol
Engine control relay	B
Engine control unit	A



CIRCUIT DIAGRAM







## SERVICE ADJUSTMENT PROCEDURES

### SPARK PLUG CABLE TEST

M16GIGL

- (1) Disconnect one at a time, each of the spark plug cables while the engine is idling to check whether the engine's running performance changes or not.

#### Caution

**Wear rubber gloves while doing so.**

- (2) If the engine performance does not change, check the resistance of the spark plug cable, and check the spark plug itself.

### SPARK PLUG TEST


M16GIHH

- (1) Remove the spark plug and connect to the spark plug cable.
- (2) Ground the spark plug outer electrode (body), and crank the engine.  
Check to be sure that there is an electrical discharge between the electrodes at this time.

### HIGH TENSION CABLE SPARK TEST

M16GIKC

- (1) Disconnect the high-tension cable from the distributor cap.
- (2) Hold the high tension cable about 6–8 mm (.24–.31 in.) away from engine proper (grounding portion such as cylinder block) and crank engine to verify that sparks are produced.



## INSPECTION USING AN ANALYZER (SECONDARY AND PRIMARY IGNITION VOLTAGE WAVEFORMS)



M16GINA

### INSPECTION OF SECONDARY IGNITION VOLTAGE

#### MEASUREMENT METHOD

(1) Clamp the secondary pickup around high tension cable.

(2) Clamp the spark plug cable with the trigger pickup.  
(Basically, clamp the No. 1 cylinder spark plug cable.)




#### NOTE

The cylinder waveform taken by the trigger pickup appears from the left side of the screen.

**STANDARD WAVEFORM**

**Observation Conditions**


Function	Secondary
Pattern height	HIGH (or LOW)
Pattern selector	Raster
Engine revolutions	Idle (700 rpm)



7EL0128

**Observation Condition (Only PATTERN SELECTOR below changes from the above conditions.)**

PATTERN SELECTOR	DISPLAY
------------------	---------



7EL0129

**WAVEFORM OBSERVATION POINTS**

(Point A): The height, length and slope of the spark line (refer to abnormal waveform examples 1, 2, 3 and 4) show the following trends.

Spark line	Plug gap	Condition of electrode	Compression pressure	Concentration of air mixture	Ignition timing	Spark plug cable	
Length	Long	Small	Normal	Low	Rich	Advanced	Leak
	Short	Large	Large wear	High	Lean	Retarded	High resistance
Height	High	Large	Large wear	High	Lean	Retarded	High resistance
	Low	Small	Normal	Low	Rich	Advanced	Leak
Slope	Large	Plug is fouled	–	–	–	–	

(Point B): Number of vibrations in reduction vibration section  
(Refer to abnormal waveform example 5)

Number of vibrations	Coil and condenser
Three or more	Normal
Except above	Abnormal






(Point C): Number of vibrations at beginning of dwell section  
(Refer to abnormal waveform example 5)

Number of vibrations	Coil
5–6 or higher	Normal
Except above	Abnormal

(Point D): Ignition voltage height (deviation per each cylinder) shows the following trends.

Ignition voltage	Plug gap	Condition of electrode	Compression pressure	Concentration of air mixture	Ignition timing	Spark plug cable
High	Large	Large wear	High	Lean	Retarded	High resistance
Low	Small	Normal	Low	Rich	Advanced	Leak

EXAMPLES OF ABNORMAL WAVEFORMS

Abnormal waveform	Wave characteristics	Cause of problem
<p>Example 1</p>  <p>01P0215</p>	<p>Spark line is high and short.</p>	<p>Spark plug gap is too large.</p>
<p>Example 2</p>  <p>01P0216</p>	<p>Spark line is low and long, and is sloping. Also, the second half of the spark line is distorted. This could be a result of mis-firing.</p>	<p>Spark plug gap is too small.</p>
<p>Example 3</p>  <p>01P0217</p>	<p>Spark line is low and long, and is sloping. However, there is almost no spark line distortion.</p>	<p>Spark plug gap is fouled.</p>
<p>Example 4</p>  <p>01P0218</p>	<p>Spark line is high and short. Difficult to distinguish between this and abnormal wave pattern example 1.</p>	<p>Spark plug cable is nearly falling off. (Causing a dual ignition)</p>
<p>Example 5</p>  <p>01P0219</p>	<p>No waves in wave damping section.</p>	<p>Rare short in ignition coil.</p>

**INSPECTION OF PRIMARY IGNITION VOLTAGE**



**MEASUREMENT METHOD**

- (1) Remove the power transistor connector and connect the special tool (Harness connector: MB991348) in between. All terminals should be connected.

- (2) Connect the primary pickup of the adjuster to the power transistor connector terminal (3).
- (3) Ground the primary pickup ground terminal.
- (4) Clamp the spark plug cable with the trigger pickup.

**NOTE**


The waveform of the cylinder clamped by the trigger pickup appears from the left side of the screen.




**STANDARD WAVEFORM**

**Observation Conditions**

Function	Primary
Pattern height	HIGH (or LOW)
Pattern selector	Raster
Engine revolutions	Idle (700 rpm.)



Observation Conditions (Only PATTERN SELECTOR below changes from the above conditions.)



**WAVEFORM OBSERVATION POINTS**

(Point A): The height, length and slope of the spark line (refer to abnormal waveform examples 1, 2, 3 and 4) show the following trends.

Spark line		Plug gap	Condition of electrode	Compression pressure	Concentration of air mixture	Ignition timing	High tension cable
Length	Long	Small	Normal	Low	Rich	Advanced	Leak
	Short	Large	Large wear	High	Lean	Retarded	High resistance
Height	High	Large	Large wear	High	Lean	Retarded	High resistance
	Low	Small	Normal	Low	Rich	Advanced	Leak
Slope		Large	Plug is fouled	–	–	–	–






(Point B): Number of vibrations in reduction vibration section  
(Refer to abnormal waveform example 5)

Number of vibrations	Coil, condenser
3 or higher	Normal
Except above	Abnormal

(Point C) : Height of Zener voltage

Height of Zener voltage	Probable cause
High	Problem in Zener diode
Low	Abnormal resistance in primary coil circuit


EXAMPLES OF ABNORMAL WAVEFORMS

Abnormal waveform	Wave characteristics	Cause of problem
<p>Example 1</p>  <p>01P0210</p>	<p>Spark line is high and short.</p>	<p>Spark plug gap is too large.</p>
<p>Example 2</p>  <p>01P0211</p>	<p>Spark line is low and long, and is sloping. Also, the second half of the spark line is distorted. This could be a result of mis-firing.</p>	<p>Spark plug gap is too small.</p>
<p>Example 3</p>  <p>01P0212</p>	<p>Spark line is low and long, and is sloping. However, there is almost no spark line distortion.</p>	<p>Spark plug gap is fouled.</p>
<p>Example 4</p>  <p>01P0213</p>	<p>Spark line is high and short</p>	<p>Spark plug cable is nearly falling off. (Causing a dual ignition)</p>
<p>Example 5</p>  <p>01P0214</p>	<p>No waves in wave damping section.</p>	<p>Rare short in ignition coil.</p>





**IGNITION SYSTEM  
REMOVAL AND INSTALLATION**

M16GJBF



- ◆◆ 1. Spark plug cable
- ◆◆ 2. Spark plug
- ◆◆ 3. High tension cable
- ◆◆ 4. Distributor
- ◆◆ 5. Ignition coil assembly

7EL0061



**INSPECTION**

**SPARK PLUG**


- (1) Check the following items so see that electrodes are not burnt, and insulators and not broken, and how porcelain insulator is burnt.
  - Broken insulators
  - Worn electrodes
  - Deposited carbon

For cleaning, use a plug cleaner or wire brush. Clean porcelain insulator above shell as well.

  - Damaged or broken gasket
  - Burnt condition of porcelain insulator at spark gap.

Dark deposit of carbon indicates too rich a fuel mixture or extremely low air intake. Also, misfiring due to excessive spark gap is suspected.

White bum indicates too lean a fuel mixture of excessively advanced ignition timing. Also insufficient plug tightening is suspected.
- (2) Clean with a plug cleaner.  
Use an air gun to remove dust deposited on plug threads.
- (3) Check plug gap using a plug gap gage and adjust it if is not as specified.




**SPARK PLUG CABLE**

- (1) Check cap and coating for cracks.
- (2) Measure resistance.

Unit: kΩ

High tension cable	Spark plug cable					
	No. 1	No. 2	No. 3	No. 4	No. 5	No. 6
Approx. 3	9	8.5	10	9	12	10



**IGNITION COIL**

**Primary coil resistance**


Measure the resistance of the positive (+) terminal and negative (-) terminal of the ignition coil.

**Standard value: .72–.88 Ω**

**Secondary coil resistance**

Measure the resistance of the positive (+) terminal and the high-voltage terminal.

**Standard value: 10.3–13.9 kΩ**



**POWER TRANSISTOR**

**NOTE**

An analog-type ohmmeter should be used.


- (1) Connect the negative (-) terminal of the 1.5V power supply to terminal ② of the power transistor, then check whether there is continuity between terminal ③ and terminal ② when terminal ① and the positive (+) terminal are connected and disconnected.

**NOTE**

Connect the (-) probe of the ohmmeter to terminal ③.

Terminal 1 and (+) terminal	Terminal 3 and terminal 2
Connected	Continuity
Disconnected	No continuity

- (2) Replace the power transistor if there is a malfunction.



**SERVICE POINTS OF INSTALLATION**


**4. INSTALLATION OF DISTRIBUTOR**

- (1) Turn the crankshaft so that the No. 1 cylinder is at compression top dead center.


**Caution**

**Be careful not to turn it to the No. 4 cylinder compression top dead center by mistake.**

- (2) Align the distributor housing and gear mating marks.



- (3) Install the distributor to the engine while aligning the fine cut (groove or projection) of the distributor's installation flange with the center of the distributor installation stud.



**1. INSTALLATION OF SPARK PLUG CABLE**


Improper arrangement of spark plug cables will induce voltage between the cables, causing miss firing and developing a surge at acceleration in high-speed operation. Therefore, be careful to arrange the spark plug cables properly by the following procedure.

1. Install the spark plug cable clamps as shown in the illustration.
2. The numerals on the support and clamp indicate the spark plug cable No.
3. Pay attention to the following items when the spark plug cables are installed.
  - (1) Install the cables securely to avoid possible contact with metal parts.
  - (2) Install the cables neatly, ensuring they are not too tight, loose, twisted or kinked.

**DISTRIBUTOR**

M16GKGA

**DISASSEMBLY AND REASSEMBLY**





**Disassembly steps**

1. Distributor cap
2. O-ring
3. Contact carbon
4. Rotor
5. O-ring
6. Distributor housing assembly



7EL0083



## SERVICE POINTS OF DISASSEMBLY

### 6. REMOVAL OF DRIVEN GEAR

- (1) Make a mark (on the distributor shaft) for alignment with the gear.
- (2) Place the drive gear on a soft base (wooden block) so that the spring pin can come out.
- (3) Punch out the spring pin by using a pin punch.

## INSPECTION

Check the following points; repair or replace if a problem is found.

### CAP ROTOR

- (1) There must be no cracking in the cap.
- (2) There must be no damage to the cap's electrode or the rotor's electrode.
- (3) Clean away any dirt from the cap and rotor.

## SERVICE POINTS OF REASSEMBLY

Take out and clean the disassembled parts. Do not use cleaning oil or similar product for cleaning.

### 6. INSTALLATION OF DRIVEN GEAR

Align with the mark made at the time of disassembly, and install the driven gear to the distributor shaft.

#### Caution

Drive in the spring pin so that the slits are at a right angle relative to the shaft.

---

**NOTES**

# CHASSIS ELECTRICAL

## CONTENTS

M54AA--

ACCESSORY SOCKET .....	67	HAZARD LIGHT SWITCH .....	60
ACCESSORY SOCKET .....	68	HEADLIGHT AND FRONT COMBINATION LIGHT .....	58
TROUBLESHOOTING .....	67	HIGH MOUNTED STOP LIGHT .....	60
AUDIO SYSTEM .....	70	LICENSE PLATE LIGHT .....	59
ANTENNA AND ANTENNA FEEDER CABLE .....	99	REAR COMBINATION LIGHT .....	59
RADIO WITH CASSETTE PLAYER AND CD PLAYER .....	98	RELAY .....	60
SPEAKER .....	98	RHEOSTAT .....	61
TROUBLESHOOTING .....	70	SERVICE ADJUSTMENT PROCEDURES .....	56
BACK DOOR WINDOW DEFOGGER .....	103	SPECIFICATIONS .....	41
DEFOGGER RELAY .....	107	General Specifications .....	41
DEFOGGER SWITCH .....	106	Service Specifications .....	41
DEFOGGER TIMER .....	107	TROUBLESHOOTING .....	42
SERVICE ADJUSTMENT PROCEDURES .....	106	METERS AND GAGES .....	7
TROUBLESHOOTING .....	103	COMBINATION METER .....	34
BATTERY .....	2	GEOMAGNETIC SENSOR, INSIDE TEMPERATURE SENSOR AND OUTSIDE TEMPERATURE SENSOR .....	38
SERVICE ADJUSTMENT PROCEDURES .....	3	INDICATORS AND WARNING LIGHTS .....	39
SPECIFICATION .....	2	MULTI-METER .....	36
General Specifications .....	2	SERVICE ADJUSTMENT PROCEDURES .....	30
TROUBLESHOOTING .....	2	SPECIFICATIONS .....	7
CIGARETTE LIGHTER .....	65	General Specifications .....	7
CIGARETTE LIGHTER .....	66	Service Specifications .....	9
SPECIFICATION .....	65	SPECIAL TOOL .....	9
General Specifications .....	65	TROUBLESHOOTING .....	10
TROUBLESHOOTING .....	65	AUTO-CRUISE CONTROL SYSTEM .....	Refer to GROUP 13
CLOCK .....	69	BACK DOOR HANDLE AND LATCH (DOOR LOCKING) .....	Refer to GROUP 42
SPECIFICATION .....	69	DOOR GLASS AND REGULATOR (POWER WINDOWS) .....	Refer to GROUP 42
General Specifications .....	69	DOOR MIRROR .....	Refer to GROUP 51
TROUBLESHOOTING .....	69	DOOR HANDLE AND LATCH (DOOR LOCKING) .....	Refer to GROUP 42
COLUMN SWITCH .....	62	HEADLIGHT WASHER .....	Refer to GROUP 51
COLUMN SWITCH .....	62	RADIATOR FAN MOTOR .....	Refer to GROUP 14
SPECIFICATION .....	62	REAR WIPER AND WASHER .....	Refer to GROUP 51
General Specifications .....	62	SUNROOF .....	Refer to GROUP 42
HORN .....	64	WINDSHIELD WIPER AND WASHER .....	Refer to GROUP 51
SPECIFICATION .....	64		
General Specifications .....	64		
TROUBLESHOOTING .....	64		
IGNITION SWITCH .....	5		
IGNITION SWITCH .....	5		
LIGHTING SYSTEM .....	41		

# BATTERY

## SPECIFICATION

### GENERAL SPECIFICATIONS

M54EB

Items	Specifications
Type	75D26R-MF
Ampere hours (5HR)	Ah 52
Cranking rating [at -18°C (0°F)]	A 490
Reserve capacity	min. 123

#### NOTES

1. CRANKING RATING is the current a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2 volts or greater at a specified temperature.
2. RESERVE CAPACITY RATING is the amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5 at 27°C (80°F).

## TROUBLESHOOTING

### BATTERY TESTING PROCEDURE

M54EHAX

TEST STEP		RESULT	ACTION TO TAKE
A0	VISUAL INSPECTION		
	<ul style="list-style-type: none"> <li>Remove negative cable, then positive cable.</li> <li>Check for dirty or corroded connections.</li> </ul>	<p><del>OK</del> ► CLEAN terminals and clamps. GO to A1.</p> <p>OK ► GO to A1.</p>	
A1	LOOSE BATTERY POST		
	<ul style="list-style-type: none"> <li>Check for loose battery post.</li> </ul>	<p><del>OK</del> ► REPLACE battery.</p> <p>OK ► GO to A2.</p>	
A2	CRACKED BATTERY COVER		
	<ul style="list-style-type: none"> <li>Remove holddowns and shields.</li> <li>Check for broken/cracked case or cover.</li> </ul>	<p><del>OK</del> ► REPLACE battery.</p> <p>OK ► GO to A3.</p>	
A3	TEST INDICATOR/OPEN CIRCUIT VOLTAGE TEST		
	<ul style="list-style-type: none"> <li>Turn headlights on for 15 seconds.</li> <li>Turn headlights off for 2 minutes to allow battery voltage to stabilize.</li> <li>Disconnect cables.</li> <li>Read open circuit voltage.</li> </ul>	<p><del>OK</del> ► CHARGE battery at 5 amps, then GO to A3.</p> <p>Green dot invisible and open circuit voltage under 12.4 volts</p> <p>OK ► GO to A4.</p>	



TEST STEP		RESULT	ACTION TO TAKE																																
A4	<p><b>LOAD TEST</b></p> <ul style="list-style-type: none"> <li>• Connect a load tester to the battery.</li> <li>• Load the battery at the recommended discharge rate (See LOAD TEST RATE CHART) for 15 seconds.</li> <li>• Read voltage after 15 seconds, then remove load.</li> </ul>	<p>Voltage is less than minimum listed (white indicator).</p> <p>Voltage is more than minimum listed.</p>	<p>REPLACE battery.</p> <p>Battery OK.</p>																																
<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th colspan="3">LOAD TEST CHART</th> </tr> <tr> <th rowspan="2">Minimum voltage</th> <th colspan="2">Temperature</th> </tr> <tr> <th>°F</th> <th>°C</th> </tr> </thead> <tbody> <tr> <td>9.6</td> <td>70 and above</td> <td>21 and above</td> </tr> <tr> <td>9.5</td> <td>60</td> <td>16</td> </tr> <tr> <td>9.4</td> <td>50</td> <td>10</td> </tr> <tr> <td>9.3</td> <td>40</td> <td>4</td> </tr> <tr> <td>9.1</td> <td>30</td> <td>-1</td> </tr> <tr> <td>8.9</td> <td>20</td> <td>-7</td> </tr> <tr> <td>8.7</td> <td>10</td> <td>-12</td> </tr> <tr> <td>8.5</td> <td>0</td> <td>-18</td> </tr> </tbody> </table>				LOAD TEST CHART			Minimum voltage	Temperature		°F	°C	9.6	70 and above	21 and above	9.5	60	16	9.4	50	10	9.3	40	4	9.1	30	-1	8.9	20	-7	8.7	10	-12	8.5	0	-18
LOAD TEST CHART																																			
Minimum voltage	Temperature																																		
	°F	°C																																	
9.6	70 and above	21 and above																																	
9.5	60	16																																	
9.4	50	10																																	
9.3	40	4																																	
9.1	30	-1																																	
8.9	20	-7																																	
8.7	10	-12																																	
8.5	0	-18																																	
<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th colspan="4">LOAD TEST RATE CHART</th> </tr> <tr> <th>Load test (Amps)</th> <th>Cranking Rating 0°F</th> <th>Reserve Capacity</th> <th>Application</th> </tr> </thead> <tbody> <tr> <td>240 amps</td> <td>490 amps</td> <td>123 minutes</td> <td>75D26R-MF</td> </tr> </tbody> </table>				LOAD TEST RATE CHART				Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application	240 amps	490 amps	123 minutes	75D26R-MF																				
LOAD TEST RATE CHART																																			
Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application																																
240 amps	490 amps	123 minutes	75D26R-MF																																

## SERVICE ADJUSTMENT PROCEDURES

### BATTERY INSPECTION

M54EIBN

#### BATTERY VISUAL INSPECTION (1)

The battery contains a visual test indicator which gives blue signal when an adequate charge level exists, and white signal when charging is required.

#### BATTERY VISUAL INSPECTION (2)


Make sure ignition switch is in Off position and all battery feed accessories are Off.

1. Disconnect ground cable from battery before disconnecting (+) cable.
2. Remove battery from vehicle.

#### Caution

Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.

3. Inspect battery carrier for damage caused by loss of acid from battery. If acid damage is present, it will be necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush and wipe off with a cloth moistened with ammonia or baking soda in water.



16F0123

16Y1814

4. Clean top of battery with same solutions as described in step (3).
5. Inspect battery case and cover for cracks. If cracks are present, battery must be replaced.
6. Clean the battery post with a suitable battery post cleaning tool.
7. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
8. Install the battery in vehicle.
9. Connect (+) and (-) cables to battery in the order of mention.
10. Tighten the clamp nut securely.

LOAD TEST RATE CHART			
Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application
240 amps	490 amps	123 minutes	75D26R-MF
LOAD TEST CHART			
Minimum voltage	Temperature		
	°F	°C	
9.6	70 and above	21 and above	
9.5	60	16	
9.4	50	10	
9.3	40	4	
9.1	30	-1	
8.9	20	-7	
8.7	10	-12	
8.5	0	-18	

**NOTE**

The temperature is an ambient temperature of the battery that has been exposed to for the preceding few hours.

**BATTERY CHARGING**

M54EICM

**Caution**

**When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries on charge or which have recently been charged.**

**Do not break live circuits at the terminals of the batteries on charge. A spark will occur where the live circuit is broken.**

**Keep all open flames away from the battery.**

Battery electrolyte temperature may temporarily be allowed to rise to 55°C (131°F). Increase of electrolyte temperature above 55°C (131°F) is harmful to the battery, causing deformation of battery cell, decrease in life of battery, etc.

**CHARGE RATE**

If the test indicator is white, the battery should be charged as outlined below.

**OPEN CIRCUIT VOLTAGE TEST (3)**

1. Turn headlights on for 15 seconds.
2. Turn headlights off for 2 minutes to allow battery voltage to stabilize.
3. Disconnect cables.
4. Read open circuit voltage.
5. If the open circuit voltage is under 12.4 volts, charge the battery. (See BATTERY CHARGING)

**LOAD TEST (4)**

1. Connect a load tester to the battery.
2. Load the battery at 15 amps for 15 seconds to remove surface charge.
3. Load the battery at the recommended discharge rate. (See LOAD TEST RATE CHART.)
4. Read voltage after 15 seconds and then remove the load.
5. If the voltage is not maintained at the minimum voltage in the LOAD TEST CHART throughout the test, the battery should be replaced.

When the dot appears or when maximum charge shown below is reached, charging should be stopped.

**NOTE**

When the charging is performed at 5 amps, charging is virtually 100% three hours after the indicator's indication changes from white to green.

Use fast charging only in an emergency.

If the indicator does not turn to green even after the battery is charged, the battery should be replaced; do not overcharge.

**Charge Rate Chart**


Battery	Slow Charging		Fast Charging	
	5 amps 15 hrs.	10 amps 7.5 hrs.	20 amps 3.75 hrs.	30 amps 2.5 hrs.
75D26R-MF (490 amps)				

# IGNITION SWITCH

## IGNITION SWITCH

### REMOVAL AND INSTALLATION

M54GLBA



16E0458

#### Removal steps of key reminder switch segment

1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
6. Key reminder switch segment

#### Removal steps of buzzer assembly


- Instrument Panel  
(Refer to GROUP 52–Instrument Panel)
- 7. Buzzer assembly  
(for key reminder, lighting monitor and seat belt)

#### Removal steps of ignition switch segment

1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
3. Column cover upper
4. Ignition switch segment

#### Removal steps of steering lock cylinder

1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
5. Steering lock cylinder



16E0109

### SERVICE POINT OF REMOVAL


#### 5. REMOVAL OF STEERING LOCK CYLINDER

- (1) Insert the ignition key into the steering lock cylinder and place the key in the ACC position.
- (2) Press the lock pin down with a Phillips head screwdriver (small-size one) to remove the steering lock cylinder.

**INSPECTION**

**IGNITION SWITCH INSPECTION**

- (1) Remove the instrument under cover. (Refer to GROUP 52–Instrument Panel)
- (2) Remove the column cover lower.
- (3) Disconnect the wiring connector from the ignition switch, and connect an ohmmeter to the switch side connector.
- (4) Operate the switch, and check the continuity between the terminals.



Position	Terminal Key	Ignition switch						Key reminder switch	
		1	2	3	4	5	6	7	10
LOCK	Removed								
	Inserted								
ACC				○—○				○—○	
ON			○—○	○—○	○—○				
START		○—○			○—○	○—○			


**NOTE**

○—○ indicates that there is continuity between the terminals.

**BUZZER ASSEMBLY INSPECTION**


**Key Reminder Buzzer Inspection**

- (1) Apply the battery voltage between the terminal No. ② and No. ⑩.
- (2) Check to be sure that the buzzer sounds intermittently when the terminal No. ③ is grounded.



**Lighting Monitor Buzzer Inspection**

- (1) Apply the battery voltage between the terminal No. ②, No. ⑧ and No. ⑩.
- (2) Check to be sure that the buzzer sounds intermittently when the terminal No. ④ is grounded.



**METERS AND GAGES****SPECIFICATIONS****GENERAL SPECIFICATIONS****METERS AND GAGES**

M54HB--

Items	Specifications
Speedometer	
Type	Cross coil type
Tachometer	
Type	Cross coil type
Fuel gage	
Type	Cross coil type
Fuel gage unit	
Type	Variable resistance type
Engine coolant temperature gage	
Type	Cross coil type
Engine coolant temperature gage unit	
Type	Thermistor type
Oil pressure gage	
Type	Bimetal type
Oil pressure gage unit	
Type	Bimetal type
Inclinometer	
Type	Gravity type
Damping system	Oil-filled system
Voltage meter	
Type	Bimetal type
Altimeter	
Type	Aneroid type
Thermometer	
Type	Temperature detection type
Electronic compass	
Type	Geomagnet detection type

## INDICATORS AND WARNING LIGHTS

Unit: W

Items	Specifications
Indication lights	
Turn signal indication light	3.4 (158)
Upper beam indication light	1.12
Automatic transmission indication light	1.12
Variable shock absorber indication light	Light emitting diode (LED)
Overdrive off indication light	1.12
4WD indication light	1.12
Cruise control indication light	1.12
Warning lights	
Door-ajar warning light	1.12
Oil pressure warning light	1.12
Charge warning light	1.12
Automatic transmission oil temperature warning light	1.12
Maintenance required warning light	1.12
Low fuel warning light	3.4 (158)
Seat belt warning light	1.12
Brake warning light	1.12
Check engine warning light	1.12
Anti-lock braking system warning light	1.12

## NOTE

The values in parentheses denote SAE trade numbers.


SERVICE SPECIFICATIONS

M54HC-

Items	Specifications
Standard value	
Speedometer indication error	mph
20	19-22
40	38-44
60	57-66
80	76-88
100	94-110
Tachometer indication error	rpm
1,000	±100
3,000	±150
5,000	±250
6,000	±300
Fuel gage unit resistance	Ω
Float point "F"	3±2
Float point "E"	110±7
Fuel gage unit float height	mm (in.)
A (Float point "F")	119.3 (4.69)
B (Float point "E")	255.0 (10.03)
Fuel gage resistance	Ω
Power supply and ground	233±23.3
Power supply and fuel gage	86±8.6
Fuel gage and ground	147±14.7
Engine coolant temperature gage resistance	Ω
Power supply and engine coolant temperature gage	75±7.5
Power supply and ground	147±14.7
Engine coolant temperature gage and ground	222±22.2
Oil pressure gage resistance	Ω
	Approx. 50
Voltage meter resistance	Ω
	380-460
Inside temperature sensor and outside temperature sensor resistance	Ω
20°C (68°F)	Approx. 1,200
40°C (104°F)	Approx. 1,500



SPECIAL TOOL

M54HG-


Tool	Number	Name	Use
	MB991416	Inspection harness	Measuring the current between N-S terminals and E-W terminals of the electronic compass

## TROUBLESHOOTING

## 1. Bearing indicator is off when moving forward

**Vehicle magnetic compensation**


(1) When the vehicle magnetic compensation (Azimuth adjustment) switch is pressed for 0.5 seconds or more, the direction indicator switches off, and the forward indicator dot will move step by step to the left or right.



(2) If the vehicle is driven (slowly) in a 360° circle, compensation is automatically completed.

**NOTE**

Compensation is possible if the turn is made to either the left or right.



(3) If there is no place to turn the vehicle in a circle, turn the vehicle around by moving it backwards and forwards.

(4) After compensation is completed, a dot showing the current direction of movement will be illuminated.



# CHASSIS ELECTRICAL

## CONTENTS

M54AA--

ACCESSORY SOCKET .....	67	HAZARD LIGHT SWITCH .....	60
ACCESSORY SOCKET .....	68	HEADLIGHT AND FRONT COMBINATION LIGHT .....	58
TROUBLESHOOTING .....	67	HIGH MOUNTED STOP LIGHT .....	60
AUDIO SYSTEM .....	70	LICENSE PLATE LIGHT .....	59
ANTENNA AND ANTENNA FEEDER CABLE .....	99	REAR COMBINATION LIGHT .....	59
RADIO WITH CASSETTE PLAYER AND CD PLAYER .....	98	RELAY .....	60
SPEAKER .....	98	RHEOSTAT .....	61
TROUBLESHOOTING .....	70	SERVICE ADJUSTMENT PROCEDURES .....	56
BACK DOOR WINDOW DEFOGGER .....	103	SPECIFICATIONS .....	41
DEFOGGER RELAY .....	107	General Specifications .....	41
DEFOGGER SWITCH .....	106	Service Specifications .....	41
DEFOGGER TIMER .....	107	TROUBLESHOOTING .....	42
SERVICE ADJUSTMENT PROCEDURES .....	106	METERS AND GAGES .....	7
TROUBLESHOOTING .....	103	COMBINATION METER .....	34
BATTERY .....	2	GEOMAGNETIC SENSOR, INSIDE TEMPERATURE SENSOR AND OUTSIDE TEMPERATURE SENSOR .....	38
SERVICE ADJUSTMENT PROCEDURES .....	3	INDICATORS AND WARNING LIGHTS .....	39
SPECIFICATION .....	2	MULTI-METER .....	36
General Specifications .....	2	SERVICE ADJUSTMENT PROCEDURES .....	30
TROUBLESHOOTING .....	2	SPECIFICATIONS .....	7
CIGARETTE LIGHTER .....	65	General Specifications .....	7
CIGARETTE LIGHTER .....	66	Service Specifications .....	9
SPECIFICATION .....	65	SPECIAL TOOL .....	9
General Specifications .....	65	TROUBLESHOOTING .....	10
TROUBLESHOOTING .....	65	AUTO-CRUISE CONTROL SYSTEM .....	Refer to GROUP 13
CLOCK .....	69	BACK DOOR HANDLE AND LATCH (DOOR LOCKING) .....	Refer to GROUP 42
SPECIFICATION .....	69	DOOR GLASS AND REGULATOR (POWER WINDOWS) .....	Refer to GROUP 42
General Specifications .....	69	DOOR MIRROR .....	Refer to GROUP 51
TROUBLESHOOTING .....	69	DOOR HANDLE AND LATCH (DOOR LOCKING) .....	Refer to GROUP 42
COLUMN SWITCH .....	62	HEADLIGHT WASHER .....	Refer to GROUP 51
COLUMN SWITCH .....	62	RADIATOR FAN MOTOR .....	Refer to GROUP 14
SPECIFICATION .....	62	REAR WIPER AND WASHER .....	Refer to GROUP 51
General Specifications .....	62	SUNROOF .....	Refer to GRUOP 42
HORN .....	64	WINDSHIELD WIPER AND WASHER .....	Refer to GROUP 51
SPECIFICATION .....	64		
General Specifications .....	64		
TROUBLESHOOTING .....	64		
IGNITION SWITCH .....	5		
IGNITION SWITCH .....	5		
LIGHTING SYSTEM .....	41		

# BATTERY

## SPECIFICATION

### GENERAL SPECIFICATIONS

M54EB-

Items	Specifications
Type	75D26R-MF
Ampere hours (5HR)	Ah 52
Cranking rating [at -18°C (0°F)]	A 490
Reserve capacity	min. 123









#### NOTES

1. CRANKING RATING is the current a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2 volts or greater at a specified temperature.
2. RESERVE CAPACITY RATING is the amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5 at 27°C (80°F).

## TROUBLESHOOTING

### BATTERY TESTING PROCEDURE

M54EHAX

TEST STEP		RESULT	ACTION TO TAKE
A0	VISUAL INSPECTION		
	<ul style="list-style-type: none"> <li>Remove negative cable, then positive cable.</li> <li>Check for dirty or corroded connections.</li> </ul>	 CLEAN terminals and clamps. GO to A1.  GO to A1.	
A1	LOOSE BATTERY POST		
	<ul style="list-style-type: none"> <li>Check for loose battery post.</li> </ul>	 REPLACE battery.  GO to A2.	
A2	CRACKED BATTERY COVER		
	<ul style="list-style-type: none"> <li>Remove holddowns and shields.</li> <li>Check for broken/cracked case or cover.</li> </ul>	 REPLACE battery.  GO to A3.	
A3	TEST INDICATOR/OPEN CIRCUIT VOLTAGE TEST		
	<ul style="list-style-type: none"> <li>Turn headlights on for 15 seconds.</li> <li>Turn headlights off for 2 minutes to allow battery voltage to stabilize.</li> <li>Disconnect cables.</li> <li>Read open circuit voltage.</li> </ul>	Green dot invisible and open circuit voltage under 12.4 volts  CHARGE battery at 5 amps, then GO to A3.  GO to A4.	

TEST STEP		RESULT	ACTION TO TAKE																																
A4	<p><b>LOAD TEST</b></p> <ul style="list-style-type: none"> <li>Connect a load tester to the battery.</li> <li>Load the battery at the recommended discharge rate (See LOAD TEST RATE CHART) for 15 seconds.</li> <li>Read voltage after 15 seconds, then remove load.</li> </ul>	<p>⊗ Voltage is less than minimum listed (white indicator).</p> <p>⊙ Voltage is more than minimum listed.</p>	<p>REPLACE battery.</p> <p>Battery OK.</p>																																
<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th colspan="3">LOAD TEST CHART</th> </tr> <tr> <th rowspan="2">Minimum voltage</th> <th colspan="2">Temperature</th> </tr> <tr> <th>°F</th> <th>°C</th> </tr> </thead> <tbody> <tr> <td>9.6</td> <td>70 and above</td> <td>21 and above</td> </tr> <tr> <td>9.5</td> <td>60</td> <td>16</td> </tr> <tr> <td>9.4</td> <td>50</td> <td>10</td> </tr> <tr> <td>9.3</td> <td>40</td> <td>4</td> </tr> <tr> <td>9.1</td> <td>30</td> <td>-1</td> </tr> <tr> <td>8.9</td> <td>20</td> <td>-7</td> </tr> <tr> <td>8.7</td> <td>10</td> <td>-12</td> </tr> <tr> <td>8.5</td> <td>0</td> <td>-18</td> </tr> </tbody> </table>				LOAD TEST CHART			Minimum voltage	Temperature		°F	°C	9.6	70 and above	21 and above	9.5	60	16	9.4	50	10	9.3	40	4	9.1	30	-1	8.9	20	-7	8.7	10	-12	8.5	0	-18
LOAD TEST CHART																																			
Minimum voltage	Temperature																																		
	°F	°C																																	
9.6	70 and above	21 and above																																	
9.5	60	16																																	
9.4	50	10																																	
9.3	40	4																																	
9.1	30	-1																																	
8.9	20	-7																																	
8.7	10	-12																																	
8.5	0	-18																																	
<table border="1" style="width: 100%; text-align: center;"> <thead> <tr> <th colspan="4">LOAD TEST RATE CHART</th> </tr> <tr> <th>Load test (Amps)</th> <th>Cranking Rating 0°F</th> <th>Reserve Capacity</th> <th>Application</th> </tr> </thead> <tbody> <tr> <td>240 amps</td> <td>490 amps</td> <td>123 minutes</td> <td>75D26R-MF</td> </tr> </tbody> </table>				LOAD TEST RATE CHART				Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application	240 amps	490 amps	123 minutes	75D26R-MF																				
LOAD TEST RATE CHART																																			
Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application																																
240 amps	490 amps	123 minutes	75D26R-MF																																

## SERVICE ADJUSTMENT PROCEDURES

### BATTERY INSPECTION

M54E1BN

#### BATTERY VISUAL INSPECTION (1)

The battery contains a visual test indicator which gives blue signal when an adequate charge level exists, and white signal when charging is required.

#### BATTERY VISUAL INSPECTION (2)


Make sure ignition switch is in Off position and all battery feed accessories are Off.

1. Disconnect ground cable from battery before disconnecting (+) cable.
2. Remove battery from vehicle.

#### Caution

Care should be taken in the event battery case is cracked or leaking to protect hands from the electrolyte. A suitable pair of rubber gloves (not the household type) should be worn when removing battery by hand.

3. Inspect battery carrier for damage caused by loss of acid from battery. If acid damage is present, it will be necessary to clean area with a solution of clean warm water and baking soda. Scrub area with a stiff bristle brush and wipe off with a cloth moistened with ammonia or baking soda in water.



4. Clean top of battery with same solutions as described in step (3).
5. Inspect battery case and cover for cracks. If cracks are present, battery must be replaced.
6. Clean the battery post with a suitable battery post cleaning tool.
7. Clean the inside surfaces of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
8. Install the battery in vehicle.
9. Connect (+) and (–) cables to battery in the order of mention.
10. Tighten the clamp nut securely.

LOAD TEST RATE CHART			
Load test (Amps)	Cranking Rating 0°F	Reserve Capacity	Application
240 amps	490 amps	123 minutes	75D26R-MF
LOAD TEST CHART			
Minimum voltage	Temperature		
	°F	°C	
9.6	70 and above	21 and above	
9.5	60	16	
9.4	50	10	
9.3	40	4	
9.1	30	-1	
8.9	20	-7	
8.7	10	-12	
8.5	0	-18	

NOTE  
The temperature is an ambient temperature of the battery that has been exposed to for the preceding few hours.

## BATTERY CHARGING

M54E1CM

### Caution

**When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries on charge or which have recently been charged.**

**Do not break live circuits at the terminals of the batteries on charge. A spark will occur where the live circuit is broken.**

**Keep all open flames away from the battery.**

Battery electrolyte temperature may temporarily be allowed to rise to 55°C (131°F). Increase of electrolyte temperature above 55°C (131°F) is harmful to the battery, causing deformation of battery cell, decrease in life of battery, etc.

### CHARGE RATE

If the test indicator is white, the battery should be charged as outlined below.

### OPEN CIRCUIT VOLTAGE TEST (3)

1. Turn headlights on for 15 seconds.
2. Turn headlights off for 2 minutes to allow battery voltage to stabilize.
3. Disconnect cables.
4. Read open circuit voltage.
5. If the open circuit voltage is under 12.4 volts, charge the battery. (See BATTERY CHARGING)

### LOAD TEST (4)

1. Connect a load tester to the battery.
2. Load the battery at 15 amps for 15 seconds to remove surface charge.
3. Load the battery at the recommended discharge rate. (See LOAD TEST RATE CHART.)
4. Read voltage after 15 seconds and then remove the load.
5. If the voltage is not maintained at the minimum voltage in the LOAD TEST CHART throughout the test, the battery should be replaced.

When the dot appears or when maximum charge shown below is reached, charging should be stopped.

### NOTE

When the charging is performed at 5 amps, charging is virtually 100% three hours after the indicator's indication changes from white to green.

Use fast charging only in an emergency.

If the indicator does not turn to green even after the battery is charged, the battery should be replaced; do not overcharge.

### Charge Rate Chart


Battery	Slow Charging		Fast Charging	
	5 amps	10 amps	20 amps	30 amps
75D26R-MF (490 amps)	15 hrs.	7.5 hrs.	3.75 hrs.	2.5 hrs.

# IGNITION SWITCH

## IGNITION SWITCH

### REMOVAL AND INSTALLATION

M54GLBA



#### Removal steps of key reminder switch segment

1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
6. Key reminder switch segment

#### Removal steps of buzzer assembly


- Instrument Panel  
(Refer to GROUP 52–Instrument Panel)
- 7. Buzzer assembly  
(for key reminder, lighting monitor and seat belt)

#### Removal steps of ignition switch segment

1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
3. Column cover upper
4. Ignition switch segment

#### Removal steps of steering lock cylinder


1. Instrument under cover  
(Refer to GROUP 52–Instrument Panel)
2. Column cover lower
5. Steering lock cylinder



### SERVICE POINT OF REMOVAL

#### 5. REMOVAL OF STEERING LOCK CYLINDER

- (1) Insert the ignition key into the steering lock cylinder and place the key in the ACC position.
- (2) Press the lock pin down with a Phillips head screwdriver (small-size one) to remove the steering lock cylinder.



**INSPECTION**


**IGNITION SWITCH INSPECTION**

- (1) Remove the instrument under cover. (Refer to GROUP 52–Instrument Panel)
- (2) Remove the column cover lower.
- (3) Disconnect the wiring connector from the ignition switch, and connect an ohmmeter to the switch side connector.
- (4) Operate the switch, and check the continuity between the terminals.

Position	Terminal Key	Ignition switch						Key reminder switch		
		1	2	3	4	5	6	7	10	
LOCK	Removed									
ACC	Inserted			○	—	○		○	—	○
ON			○	—	○	—	○			
START		○	—	○	—	○	—	○	—	○

**NOTE**


○—○ indicates that there is continuity between the terminals.



**BUZZER ASSEMBLY INSPECTION**

**Key Reminder Buzzer Inspection**

- (1) Apply the battery voltage between the terminal No. ② and No. ⑩.
- (2) Check to be sure that the buzzer sounds intermittently when the terminal No. ③ is grounded.



**Lighting Monitor Buzzer Inspection**

- (1) Apply the battery voltage between the terminal No. ②, No. ⑧ and No. ⑩.
- (2) Check to be sure that the buzzer sounds intermittently when the terminal No. ④ is grounded.

**METERS AND GAGES****SPECIFICATIONS****GENERAL SPECIFICATIONS****METERS AND GAGES**

M54HB--

Items	Specifications
Speedometer	
Type	Cross coil type
Tachometer	
Type	Cross coil type
Fuel gage	
Type	Cross coil type
Fuel gage unit	
Type	Variable resistance type
Engine coolant temperature gage	
Type	Cross coil type
Engine coolant temperature gage unit	
Type	Thermistor type
Oil pressure gage	
Type	Bimetal type
Oil pressure gage unit	
Type	Bimetal type
Inclinometer	
Type	Gravity type
Damping system	Oil-filled system
Voltage meter	
Type	Bimetal type
Altimeter	
Type	Aneroid type
Thermometer	
Type	Temperature detection type
Electronic compass	
Type	Geomagnet detection type

## INDICATORS AND WARNING LIGHTS

Unit: W

Items	Specifications
Indication lights	
Turn signal indication light	3.4 (158)
Upper beam indication light	1.12
Automatic transmission indication light	1.12
Variable shock absorber indication light	Light emitting diode (LED)
Overdrive off indication light	1.12
4WD indication light	1.12
Cruise control indication light	1.12
Warning lights	
Door-ajar warning light	1.12
Oil pressure warning light	1.12
Charge warning light	1.12
Automatic transmission oil temperature warning light	1.12
Maintenance required warning light	1.12
Low fuel warning light	3.4 (158)
Seat belt warning light	1.12
Brake warning light	1.12
Check engine warning light	1.12
Anti-lock braking system warning light	1.12

## NOTE

The values in parentheses denote SAE trade numbers.




**SERVICE SPECIFICATIONS**

M54HC--

Items	Specifications
Standard value	
Speedometer indication error	mph
20	19-22
40	38-44
60	57-66
80	76-88
100	94-110
Tachometer indication error	rpm
1,000	±100
3,000	±150
5,000	±250
6,000	±300
Fuel gage unit resistance	Ω
Float point "F"	3±2
Float point "E"	110±7
Fuel gage unit float height	mm (in.)
A (Float point "F")	119.3 (4.69)
B (Float point "E")	255.0 (10.03)
Fuel gage resistance	Ω
Power supply and ground	233±23.3
Power supply and fuel gage	86±8.6
Fuel gage and ground	147±14.7
Engine coolant temperature gage resistance	Ω
Power supply and engine coolant temperature gage	75±7.5
Power supply and ground	147±14.7
Engine coolant temperature gage and ground	222±22.2
Oil pressure gage resistance	Ω
	Approx. 50
Voltage meter resistance	Ω
	380-460
Inside temperature sensor and outside temperature sensor resistance	Ω
20°C (68°F)	Approx. 1,200
40°C (104°F)	Approx. 1,500



**SPECIAL TOOL**

M54HG--

Tool	Number	Name	Use
	MB991416	Inspection harness	Measuring the current between N-S terminals and E-W terminals of the electronic compass


**TROUBLESHOOTING**

**1. Bearing indicator is off when moving forward**



**Vehicle magnetic compensation**


(1) When the vehicle magnetic compensation (Azimuth adjustment) switch is pressed for 0.5 seconds or more, the direction indicator switches off, and the forward indicator dot will move step by step to the left or right.



(2) If the vehicle is driven (slowly) in a 360° circle, compensation is automatically completed.

**NOTE**

Compensation is possible if the turn is made to either the left or right.




(3) If there is no place to turn the vehicle in a circle, turn the vehicle around by moving it backwards and forwards.

(4) After compensation is completed, a dot showing the current direction of movement will be illuminated.

2. Vehicle magnetic compensation cannot be made

When the vehicle magnetic compensation switch is pressed, does the direction indicator switch off, and the forward indicator dot move step by step to the left or right?



Forward indicator dot

Vehicle magnetic compensation switch


68E0034

No → Replace the display unit

When the initial compensation direction is changed, or the vehicle position is changed, and the compensation restarts, can compensation be achieved?

Yes → Sometimes compensation is difficult because of the magnetic direction or the vehicle direction at the time compensation begins.  
 • Compensation is difficult in places where the magnetic field is being influenced by surrounding objects.

When the geomagnetic sensor and connector are connected, does a voltage of 10V or more show between the power and the ground terminal?



Geomagnetic sensor

Ground


Power (IG)

16E0179

16E0172

No →

When the geomagnetic sensor connector assembly is disconnected, does a voltage of 10V or more show between the power and the ground terminal?



Power (IG)

Ground

16E0173

16E0178


No → Repair the harness or replace the display unit

Yes → Replace the geomagnetic sensor

Yes → To next page


From previous page

When the geomagnetic sensor and connector are connected, does a voltage of 5V show between the power and the N-S output or between the power and the E-W output?



No

When the geomagnetic sensor connector assembly is disconnected, does a voltage of 5V show between the power and the N-S output or between the power and the E-W output?



No

Repair the harness or replace the display unit


Yes

Yes

Replace the geomagnetic sensor

When using the special tool (Inspection harness: MB991416), do the maximum and minimum values for the current between the N-S terminal or the E-W terminal vary by 1mA or more when the vehicle is driven (slowly) in a circle when setting compensation?

N-S: Yellow lead wire  
E-W: Red lead wire



No

Repair the harness or replace the geomagnetic sensor

Yes

Replace the display unit

3. Display is hard to see or no display appears

When the multi-meter assembly connector is removed, does a voltage of 10V or more show between the power and the ground terminal?

16E0174

16E0171

No

Repair the harness

Yes

After reconnecting the connector, is the back light bulb illuminated?

16E0175

No

Replace the back light bulb

Yes

Replace the display unit

4. Discrepancy between the inside and outside temperatures and the display temperature

With the multi-meter connected to the connector, when the outside thermo sensor or the inside thermo sensor are showing the temperatures below, are the voltages between the outside temperature power and ground terminals, or between the inside temperature power and ground terminals, as shown in the table below?


Display temperature [°C(°F)]	Terminal voltage (V)	
	Outside temperature	Inside temperature
0 (0)	3.42	3.42
20 (68)	2.46	2.23
40 (104)	1.61	1.43

Ground for outside temperature      Ground for inside temperature



16E0174

Power supply for outside temperature      Power supply for inside temperature



16E0177

No

Are the internal resistance values of the outside temperature sensor or inside temperature sensor at the standard values? (Refer to P.54-38.)

No

Replace the outside thermo sensor or inside thermo sensor


Yes

Repair the harness between the multi-meter and the outside thermo sensor or inside thermo sensor

Yes


Replace the display unit

METER AND GAGE CIRCUIT




- REAR DIFFERENTIAL LOCK CONTROL UNIT
- AUTO-CRUISE CONTROL UNIT
- ENGINE CONTROL UNIT


NO CONNECTION







**WARNING LIGHT CIRCUIT**














INDICATOR LIGHT CIRCUIT











**COMBINATION METER****OPERATION****<Fuel gage>**

- When the ignition switch is at the "ON" position, the fuel gage is activated.
- When there is much fuel, the unit's resistance is small and the current flowing in the circuit is great, so the gage's indicator indicates in the "F" area.
- When there is little fuel, the unit's resistance is high and the current flowing in the circuit is small, so the gage's indicator indicates in the "E" area.

**<Engine coolant temperature gage>**

- When the ignition switch is at the "ON" position, the engine coolant temperature gage is activated.
- When the engine coolant temperature is high, the unit's resistance is low and there is a great flow of current in the circuit, so the gage's indicator indicates in the "H" area.
- When the engine coolant temperature is low, the unit's resistance is high and there is a small flow of current in the circuit, so the gage's indicator indicates in the "C" area.

**<Reed switch>**

- Pulses are produced in accordance with the vehicle speed, and vehicle-speed signals are input to systems (the MPI system, etc.) that regulate according to the vehicle speed.

**<Illumination light>**

- When the lighting switch is set to the "TAIL" or "HEAD" position, the tail light relay contact closes to turn the tail light relay "ON" and the illumination light illuminates via the rheostat.
- When the rheostat is operated, the voltage applied to the transistor varies, and the illumination light becomes brighter or darker.


**NOTE**

For operation of indicator and warning light, refer to P.54-39 INDICATORS AND WARNING LIGHTS.


**TROUBLESHOOTING HINTS**


1. Speedometer does not operate on its operation is incorrect.
  - Check the speedometer cable.
  - Check the speedometer. (Refer to P.54-30)
2. Tachometer does not operate or its operation is incorrect.
  - Check the tachometer. (Refer to P.54-30)
3. Fuel gage does not operate or its operation is incorrect.
  - Check the fuel gage. (Refer to P.54-31)
  - Check the fuel gage unit. (Refer to P.54-31)
4. The low fuel warning light does not illuminate even if fuel in the fuel tank is less than 11 dm<sup>3</sup> (2.9 gals).
  - Check the warning light bulb.
  - Check the fuel gage unit. (Refer to P.54-32)
5. The engine coolant temperature gage does not operate or its operation is incorrect.
  - Check the engine coolant temperature gage. (Refer to P.54-32)
  - Check the engine coolant temperature gage unit. (GROUP 14–Engine Coolant Temperature Gage Unit)
6. The illumination light does not illuminate or does not dim.
  - (1) The tail light illuminates.
    - Check the rheostat. (Refer to P.54-61)
  - (2) The tail light does not illuminate.
    - Check the dedicate fuse No. 5.
    - Check the tail light relay. (Refer to P.54-60)
    - Check the lighting switch. (Refer to P.54-63)

MULTI METER CIRCUIT <VEHICLES WITHOUT ELECTRONIC COMPASS>



**MULTI METER CIRCUIT <VEHICLES WITH ELECTRONIC COMPASS>**





**MULTI-METER****OPERATION****<Oil pressure gage>**

- When the ignition key is at the "ON" position, the oil pressure gage is activated.
- When oil pressure is high, the internal contacts of the gage unit are kept closed for a longer period of time. This causes more current to flow in the circuit, and the gage pointer swings to the high pressure side.
- When oil pressure is low, the internal contacts of the gage unit open in a shorter period of time. Therefore, there is less current flowing in the circuit and the gage pointer swings to the low pressure side.

**<Voltage meter>**

- When the ignition key is placed in the "ON" position, the voltage meter operates and indicates a battery voltage of approximately 12V.
- When the engine is started, the voltage meter indicates a battery voltage of 12 to 16V, indicating that the battery is on charge.

**<Electronic compass>**

- When the ignition switch is at the "ON" position, the DC signal output from the geomagnetic sensor (on-going vehicle direction output, lateral vehicle direction output) is converted from an analog signal to a digital signal by the A/D conversion circuit inside the multi-meter.
- This digital signal is evaluated by the calculating circuit in the CPU and the resulting value is displayed on the digital display.

**<Inside and outside thermo sensors>**

- When the ignition switch is at the "ON" position, the DC signal output from the inside thermo sensor and outside thermo sensor is converted from an analog signal to a digital signal by the A/D conversion circuit inside the multi-meter.
- This digital signal is evaluated by the calculating circuit in the CPU and the resulting value is displayed on the digital display.

**NOTE**

For operation and troubleshooting hints for the illumination light, refer to P.54-25.

**TROUBLESHOOTING HINTS**

1. The oil pressure gage does not operate or its operation is incorrect.
  - Check the oil pressure gage. (Refer to P54-33, 36)
  - Check the oil pressure gage unit.
2. The voltmeter does not operate or its operation is incorrect.
  - Check the voltage meter. (Refer to P.54-33, 36)
3. The on-going direction display deviates.
  - Refer to P.54-10, Troubleshooting.
4. Vehicle magnetic compensation cannot be made.
  - Refer to P.54-11, Troubleshooting.
5. Display is hard to see or no display appears.
  - Refer to P.54-13, Troubleshooting.
6. There is a discrepancy between the inside and outside temperatures and the display temperatures.
  - Check the outside or inside thermo sensor (Refer to P.54-38).
  - Refer to P.54-14, Troubleshooting.

**SERVICE ADJUSTMENT PROCEDURES**

M54H10A

**SPEEDOMETER INSPECTION**

- (1) Adjust the pressure of the tires to the specified level. (Refer to GROUP 31-General Specifications.)
- (2) Place the vehicle on a speedometer tester and chock the front wheels

**Caution**

**Always inspect with the transfer lever in the "2H" position.**

- (3) Check if the speedometer indication range is within the standard values.

**Caution**

**Do not operate the clutch suddenly or decrease speed rapidly while testing.**

Standard value:	Standard indication	Allowable range
	mph	mph
	20	19-22
	40	38-44
	60	57-66
	80	76-88
	100	94-110

**TACHOMETER INSPECTION**

M54H10B



- (1) Insert a paper clip in the connector from the harness side, and attach the engine speedometer.

**NOTE**

For tachometer inspection, use of a fluxmeter-type engine speedometer is recommended. (Because a fluxmeter only needs to be clipped to the high tension cable.)

- (2) Compare the readings of the engine speedometer and the tachometer at every engine speed, and check if the variations are within the standard values.

Standard value:	Engine speed	Indicated variation
	rpm	rpm
	1000	± 100
	3000	± 150
	5000	± 250
	6000	± 300




FUEL GAGE SIMPLE INSPECTION

M54HICM

Remove the fuel gage unit assembly connector

Connect a test light to the harness side connector.

Turn the ignition switch to ON.



Check the condition of the test light and the gage.


- (1) Test light is illuminated (Gage needle is not moving)
- (2) Test light is illuminated (Gage needle is moving)
- (3) Test light is not illuminated (Gage needle is not moving)

Replace the fuel gage

Replace the fuel gage unit

Repair the harness

M54HIU



FUEL GAGE UNIT INSPECTION

To check, remove fuel gage unit from fuel tank. (Refer to GROUP 13 – Fuel Tank.)

Fuel Gage Unit Resistance

(1) Check that resistance value between the fuel gage terminal and ground terminal is at standard value when fuel gage unit float is at point F (highest) and point E (lowest).

<b>Standard value:</b>	<b>Point F</b>	<b>3 ± 2 Ω</b>
	<b>Point E</b>	<b>110 ± 7 Ω</b>

(2) Check that resistance value changes smoothly when float moves slowly between point F (highest) and point E (lowest).

Fuel Gage Unit Float Height

Move float and measure the height A at point F (highest) and B at point E (lowest) with float arm touching stopper.

<b>Standard valve:</b>	<b>A</b>	<b>119.3 mm (4.69 in.)</b>
	<b>B</b>	<b>255.0 mm (10.03 in.)</b>


**FUEL LEVEL SENSOR INSPECTION**

M54HINA

Connect fuel gage unit to battery via test light (12V-3.4W). Immerse in water. Condition good if light goes off when unit termistor is in water and lights when unit is removed from water.

**Caution**

**After completing this test, wipe the unit dry and install it in the fuel tank.**




**ENGINE COOLANT TEMPERATURE GAGE SIMPLE INSPECTION**

M54HIDM

Remove the engine coolant temperature gage unit assembly connector.

Ground the harness connector by connecting it to a test light.



Turn the ignition switch to ON.

Check the condition of the test light and the gauge.

(1) Test light is illuminated (Gage needle is not moving)	Replace the engine coolant temperature gage
(2) Test light is illuminated (Gage needle is moving)	Replace the engine coolant temperature gage unit
(3) Test light is not illuminated (Gage needle is not moving)	Repair the harness

**ENGINE COOLANT TEMPERATURE GAGE UNIT INSPECTION**

M54HIKX

Refer to GROUP 14 – Engine Coolant Temperature Gage Unit.




OIL PRESSURE GAGE SIMPLE INSPECTION

M54HIFC

Remove the oil pressure gage unit coupling connector.

Connect the harness connector via a test light to the ground



Place the ignition switch in the ON position.

Check the test light and gage conditions.

① Test light lights. (Pointer of gage does not swing.)

Replace oil pressure gage.

② Test light lights. (Pointer of gage swings.)

Replace oil pressure gage unit.

③ Test light does not light. (Pointer of gage does not swing.)


Correct harness.

VOLTAGE METER SIMPLE TEST

M54HIGF

Start engine and let it idle.

Connect voltmeter to battery.



Check voltage meter for conditions.

① Voltage indicated by voltmeter differs from voltage indicated by voltage meter (position indicated by pointer).



Replace gage.

② Gage does not operate.

Correct harness or replace gage.

## COMBINATION METER REMOVAL AND INSTALLATION


M54HJAV



### SERVICE POINT OF REMOVAL

#### 4. REMOVAL OF ADAPTER


- (1) Disconnect the speedometer cable at the transmission end of the cable.
- (2) Pull the speedometer cable slightly toward the vehicles interior, release the lock by turning the adapter to the left or right, and then remove the adapter.



### INSPECTION

#### REED SWITCH

Using an ohmmeter, check that continuity and discontinuity alternates between terminals 1 and 2 four times at every rotation of the shaft of the speedometer cable connection.




**FUEL GAGE RESISTANCE**

Measure resistance between terminals with an ohmmeter.

**Standard value:**

Power supply and ground	$233 \pm 23.3 \ \Omega$
Power supply and fuel gage	$86 \pm 8.6 \ \Omega$
Fuel gage and ground	$147 \pm 14.7 \ \Omega$



**ENGINE COOLANT TEMPERATURE GAGE RESISTANCE**

Measure resistance between terminals with an ohmmeter.


**Caution**

For inspection, use an ohmmeter which uses a measurement current of 4mA or less.

**Standard value:**

Power supply and engine coolant temperature gage	$75 \pm 7.5 \ \Omega$
Power supply and ground	$147 \pm 14.7 \ \Omega$
Engine coolant temperature gage and ground	$222 \pm 22.2 \ \Omega$

**DISASSEMBLY AND REASSEMBLY**



**Disassembly steps**


1. Boot
2. Meter glass
3. Window plate
4. Prism indicator lens
5. Speedometer
6. Fuel gage and engine coolant temperature gage
7. Tachometer
8. Printed-circuit board
9. Meter case

16E0010

## MULTI-METER


## REMOVAL AND INSTALLATION

M54HJAW

**Removal steps**

1. Meter hood
2. Multi-meter assembly
3. Meter mounting bracket


16E0126



16E1354

**INSPECTION****OIL PRESSURE GAGE**

Measure the resistance between terminals with ohmmeter

**Standard value: Approx. 50Ω**

16E1355


**VOLTAGE METER**

Measure the resistance between terminals with ohmmeter

**Standard value: 380–460Ω**

**DISASSEMBLY AND REASSEMBLY**

**<OIL PRESSURE GAGE, INCLINOMETER AND VOLTAGE METER>**




**Disassembly steps**

1. Meter garnish
2. Meter glass
3. Window plate
4. Voltage meter
5. Inclinometer
6. Oil pressure gage
7. Connector bracket
8. Meter harness
9. Meter case

16E0396

**<ELECTRONIC COMPASS, INCLINOMETER AND ALTIMETER>**



**Disassembly steps**


1. Knob
2. Meter garnish
3. Meter glass
4. Window plate
5. Altimeter
6. Connector bracket
7. Inclinometer
8. Electronic compass
9. Back light bulb
10. Meter case

16E0124

# GEOMAGNETIC SENSOR, INSIDE TEMPERATURE SENSOR AND OUTSIDE TEMPERATURE SENSOR

M54HMAA

## REMOVAL AND INSTALLATION






### Removal steps of inside temperature sensor

1. Column cover lower
2. Inside temperature sensor

### Removal steps of outside temperature sensor

1. Radiator grille
2. Outside temperature sensor



## INSPECTION

### OUTSIDE TEMPERATURE SENSOR AND INSIDE TEMPERATURE SENSOR

Check that the internal resistance values of the outside temperature sensor or inside temperature sensor are at the standard values when each sensor shows temperatures of 20°C (68°F) and 40°C (104°F).





Standard value:	20°C (68°F)	Approx. 1200 Ω
	40°C (104°F)	Approx. 500 Ω




### NOTE


For inspection of the geomagnetic sensor, refer to Troubleshooting (P.54-11).

## INDICATORS AND WARNING LIGHTS

M54HKAZ

Symbol		Operation
	Turn signal indicator	This indicator flashes, as do the same side of turn-signal light flashes. If the turn-signal light is burnt out, the blinking of indicator slows down. This indicator is common with hazard light.
	High beam indicator	This indicator illuminates when the headlights are on high beam.
	Door-ajar warning light	This warning light comes on when the door is either open or not completely closed.
	Fasten seat belt indicator	This indicator goes on for four to eight seconds when the ignition key is in "ON" position, even if the driver has fastened his seat belt.
<b>BRAKE</b>	Brake warning light	This warning light comes on when the ignition key is in "ON" position, and goes off after the engine has started. This warning light comes on when the parking brake is applied or brake fluid level falls less than the specific level.
	Charging warning light	This warning light comes on when the ignition key is in "ON" position, and goes off after the engine has started. This warning light comes on when the drive belt breaks or the trouble occurs in the charging system.
<b>OD OFF</b> 68R0133	Overdrive indicator	This indicator will illuminate when the overdrive control switch is switched to the "OFF" position.
<b>A/T TEMP</b> 68W068	A/T fluid temperature warning light	This A/T fluid temperature warning light comes on when automatic transmission fluid temperature becomes abnormally high.
<b>MAINT REQD</b>	Maintenance required warning light	This light comes on when the ignition key is in "ON" position, and goes off after the engine has started. (Lights up after every 50,000 miles, 80,000 miles, 100,000 miles travelled.)
<b>CHECK ENGINE</b>	Engine warning light	This light illuminates when the ignition key is turned to the "ON" position, but should go out in a few seconds. If the light illuminates while the vehicle is moving, there is a malfunction of a component related to exhaust gases.
	Low fuel warning light	This warning light illuminates when the fuel in the fuel tank falls less than approx. 11 dm <sup>3</sup> (2.9 gals.)
	Oil pressure warning light	This warning light illuminates when the ignition key is in "ON" position, and goes off after the engine has started. This indicator comes on when the oil fails or the trouble occurs in the oil circulating system while driving.
<b>CRUISE</b>	Cruise control indicator	This indicator illuminates when the cruise control is activated.

Symbol		Operation
<b>ANTI LOCK</b>	Anti-lock braking system warning light	This warning light will go on when the ignition key is turned to the "ON" position, and goes out in a second. If warning light goes on after starting the engine or while driving, it indicates that the anti-lock braking system is not functioning and that only the standard brake system is in operation.
	2WD/4WD indicator	This indicator will light up when the transfer case shift lever is shifted to the four wheel driving position (either the "2H" "4H", "4HLc or the "4HLLc" position) and the ignition key is in the "ON" position.
	Variable shock absorber indicator	The indicator light of switch position (M: MEDIUM mode, S: SOFT mode and H: Hard mode) on the changeover switch illuminates when the ignition switch is turned to the "ON" position.
	Automatic transmission position indicator	When the ignition key is turned to the "ON" position, the indicator illuminates to indicate the position at which the selector lever is set.



### MAINTENANCE REQUIRED SYSTEM

#### RESET SWITCH

After checking is completed, use the reset switch (located at the rear of the combination meter) to switch OFF the warning light.

Note that the warning lights bulb should be removed after the 100,000 mileage.

#### NOTE

If the speedometer is to be replaced, set the new odometer to the same reading as the odometer being removed.



# LIGHTING SYSTEM

## SPECIFICATIONS

### GENERAL SPECIFICATIONS

M541B--

Items	Specifications
Exterior lights	
Headlight	W 65/45
Front combination light	W
Front turn-signal/Parking and front side marker light	27/8 (1157)
Rear combination light	cp
Turn-signal light	32 (1156)
Stop/tail light	32/2 (2057)
Rear side marker light	3 (168)
Back-up light	cp 32 (1156)
License plate light	W 10
High-mounted stop light	W 5
Interior lights	
Dome light	W 8
Reading light	W 8
Cargo space light	W 10
Vanity mirror light	W 1.5
Cigarette lighter illumination light	W 1.4 (74)
Ashtray illumination light	W 1.4 (74)

**NOTE**

The values in parentheses denote SAE grade numbers.

### SERVICE SPECIFICATION

M541C--

Items	Specifications
Limit	
Headlight intensity	cd 20,000 or more

## TROUBLESHOOTING

### HEADLIGHT CIRCUIT

#### OPERATION

##### <Low-beam and high-beam>

- When the ignition switch is at the "ACC" or "ON" position and the lighting switch is set to the "HEAD" position, the headlight relay contact closes to turn the headlight relay "ON".
- When the dimmer switch is set to the "LO" position, the low-beams illuminate, and when it is set to the "HI" position, the high-beams illuminate.

##### <Passing>


- If the passing switch is set to the "ON" position when the ignition switch is at the "ACC" or "ON" position and the lighting switch is at the "OFF" or "TAIL" position, the low-beams and high-beams will illuminate simultaneously when the dimmer switch is at the "LO" position, and the high-beams will illuminate when the dimmer switch is at the "HI" position.

##### <High-beam indicator light>

- When the high-beams are illuminated or while passing is operating, the indicator light will illuminate to inform the driver that the high-beams are illuminated.


### TROUBLESHOOTING HINTS

1. The headlights do not illuminate at all positions
  - (1) The taillights illuminate.
    - Check the headlight relay. (Refer to P.54-60)
    - Check the lighting switch. (Refer to P.54-63)
  - (2) Tail lights also do not illuminate or charging warning light does not turn off.
    - Check the fusible link No. ⑬
2. Low-beams (both) do not illuminate.
  - Check the dimmer switch. (Refer to P.54-63)
3. High-beams (both) do not illuminate but illuminate when the passing switch is turned to the "ON" position.
  - Check the dimmer switch. (Refer to P.54-63)
4. The high-beam indicator light does not illuminate but illuminates with the dimmer switch at "HI" position or the passing switch at "ON" position.
  - Check the dedicated fuse No. ⑦
  - Check the indicator light bulb.
5. The headlights do not illuminate even if passing but illuminate with the dimmer switch at "LO" or "HI" position and the lighting switch at "HEAD" position.
  - Check the passing switch. (Refer to P.54-63)




KX35-AC-90801-N

TSB Revision



**TAIL LIGHT, PARKING LIGHT, SIDE MARKER LIGHT, LICENSE PLATE LIGHT CIRCUIT**

M541HCO




KX35-AC-Q0802-N

**OPERATION**

- When the lighting switch is set to the "TAIL" or "HEAD" position, the tail light relay contact closes to turn the tail light relay "ON".
- Current flows via dedicated fuse No. ⑤ and the tail lights, parking lights, side marker lights and license plate light illuminate.

**TROUBLESHOOTING HINTS**

1. All lights do not illuminate.
  - (1) Headlights illuminate.
    - Check the dedicated fuse No. ⑤
    - Check the tail light relay. (Refer to P.54-60)
    - Check the lighting switch. (Refer to P.54-63)




(2) The headlights also do not illuminate or charging warning light does not turn off.

- Check the fusible link No. 13

2. Either light does not illuminate.


- Check the bulb.
- Check the ground circuit.

TURN-SIGNAL LIGHT AND HAZARD LIGHT CIRCUIT



KX35-AC-Q0901-N

TSB Revision





**OPERATION**

**<Turn-signal light>**

**1. In normal operating condition**

- When the ignition switch is placed in the ON position, battery voltage is applied through the hazard switch to the turn-signal and hazard flasher unit.
- When the turn-signal switch is placed in the LH (or RH) position, Tr<sub>1</sub> in the flasher unit turns ON, causing the relay contacts in the flasher unit to close. This results in the LH (or RH) turn-signal light and turn-signal indicator light lighting up.
- At the same time, the capacitor is charged through R<sub>2</sub> up to the lower limit as set by COM3.
- As soon as the capacitor is fully charged, the output from COM3 is inverted, turning OFF Tr<sub>1</sub>. This opens the relay contacts and, as a result, the LH (or RH) turn-signal light and turn-signal indicator light go out.
- At the same time when Tr<sub>1</sub> turns OFF, the capacitor starts discharging. As soon as the capacitor completes discharging, the COM3 output is inverted again causing Tr<sub>1</sub> to turn ON. This results in the LH (or RH) turn-signal light and turn-signal indicator light coming on.
- These sequences of operation repeat, which results in the LH (or RH) turn-signal light and turn-signal indicator light flashing off and on.

**2. When one bulb is burnt**

- When either one of the turn-signal light bulbs goes out, it causes the resistance of the entire light circuit to increase, hence a smaller voltage drop at R<sub>1</sub> in the flasher unit.
- This smaller voltage drop is sensed and the lower voltage limit set by COM3 is raised, thus shortening the time required by the capacitor before it is fully charged.
- As a result, the on-off cycle of Tr<sub>1</sub> becomes shorter with the resultant greater number of times the light flashes on and off.

**<Hazard light>**


- When the hazard switch is placed in the ON position, the flasher unit relay contacts repeatedly close and open, which results in the RH and LH turn-signal lights turn-signal indicator lights, and hazard warning indicator lights flashing on and off at the same time.

**Remark**

- The number of times the hazard lights flash on and off does not change even when one bulb is out.


**COMPONENT LOCATION**

Name	Symbol
Turn-signal and hazard flasher unit	A





**TROUBLESHOOTING HINTS**

1. Neither the turn-signal lights nor hazard lights operate.
  - Check hazard switch. (Refer to P.54-60)
  - Check flasher unit.
2. All LH or RH turn-signal lights do not operate.
  - (1) Hazard light is fully operational.
    - Check turn-signal switch. (Refer to P.54-63)
    - Check the hazard switch. (Refer to P.54-60)
3. Flashing cycle of turn signal lights is shorter.
  - Check the light bulb.
4. Hazard light does not operate.
  - (1) Turn-signal lights are operational.
    - Check hazard switch. (Refer to P.54-60)



## BACK-UP LIGHT CIRCUIT



## OPERATION


- When, with the ignition switch at the "ON" position, the shift lever (or the selector lever) is moved to the "R" position, the backup light switch (M/T) is switched ON (or the inhibitor switch (A/T) is switched to the "R" position), and the backup light illuminates.

## TROUBLESHOOTING HINTS

- The back-up lights do not illuminate.
- Check the back-up light switch. <M/T>
  - Check the inhibitor switch. <A/T>
  - Check the ground circuit.
  - Check the back-up light bulb.

STOP LIGHT CIRCUIT

M54IHHI




OPERATION

- The battery voltage is constantly applied to the stop light switch through the multi-purpose fuse No. ⑰.
- When the brake pedal is depressed, the stop light switch turns to "ON", and the stop lights illuminate.

TROUBLESHOOTING HINTS


1. The stop lights do not illuminate.
  - Check the stop light switch. (Refer to GROUP 35—Brake Pedal)
  - Check the multi-purpose fuse No. ⑰.
2. Either stop light does not illuminate.
  - Check the ground circuit



3. The stop lights do not illuminate.
- Check the stop light switch. (Refer to GROUP 35—Brake Pedal)

- OPERATION
- The battery voltage is constantly applied to the stop light switch through the multi-pose fuse No. 12.
  - When the brake pedal is depressed, the stop light switch turns to "ON", and the stop lights illuminate.

DOME LIGHT, CARGO SPACE LIGHT, READING LIGHT CIRCUIT



**OPERATION****<Dome light, cargo space light>**

- Battery voltage is always applied to the dome light and cargo space light.
- When the dome light switch or the cargo space light switch is set to the "ON" position, the dome light or cargo space light always illuminates. When the switch is set to the "DOOR" position, the dome light or cargo room light illuminates when any door is opened.

**<Reading light>**

- Battery voltage is always applied to the reading light.
- When the reading light switch is set to the "ON" or "OFF" position, the reading light illuminates or switches off.

**VANITY MIRROR CIRCUIT****OPERATION**

- When the lighting switch is set to the "TAIL" or "HEAD" position, the tail light relay contact closes to turn the tail light relay "ON".
- When the lid of the vanity mirror is opened, the vanity mirror light switch is set to the "ON" position, current flows via dedicated fuse No. ⑤ and the vanity mirror light illuminates.


**TROUBLESHOOTING HINTS**

1. When any of the doors are opened, the dome light or cargo space light does not illuminate for certain doors.
  - Check the front or rear door switch. (Refer to GROUP 42-Door Assembly.)
  - Check the back door switch. (Refer to GROUP 42-Back Door Handle and Latch.)
2. When the dome light switch or cargo space light switch is set to the "DOOR" position and any of the doors are opened, the dome light or cargo space light does not illuminate.
  - (1) Illuminates when the switch is at the "ON" position.
    - Check the dome light switch, cargo space light switch.
  - (2) It does not illuminate even if the switch is at "ON" position.
    - Check the light bulb.
    - Check the dome light switch, cargo space light switch.

**TROUBLESHOOTING HINTS**


The vanity mirror do not illuminated.

- (1) The tail lights illuminates.
  - Check the vanity mirror switch.
  - Check the vanity mirror light bulb.
- (2) The tail lights also do not illuminate.
  - Check the tail light relay. (Refer to P.54-60)
  - Check the dedicated fuse No. ⑤.
  - Check the lighting switch. (Refer to P.54-63)



## SERVICE ADJUSTMENT PROCEDURES

M541IAG



## HEADLIGHT AIMING

## PRE-AIMING INSTRUCTIONS


1. Test dimmer switch operation.
2. Observe operation of high beam light mounted in instrument cluster.
3. Inspect for badly rusted or faulty headlight assemblies. These conditions must be corrected before a satisfactory adjustment can be made.
4. Place vehicle on a level floor.
5. Bounce front suspension through three (3) oscillations by applying body weight to hood or bumper.
6. Inspect tire inflation.
7. Rock vehicle sideways to allow vehicle to assume its normal position.
8. If fuel tank is not full, place a weight in trunk of vehicle to simulate weight of a full tank [3 kg (6.5 lbs.) per gallon].
9. There should be no other load in the vehicle other than driver or substituted weight of approximately 70 kg (150 lbs.) placed in driver's position.
10. Thoroughly clean headlight lenses.

## VERTICAL ADJUSTING

Adjust the vertical angle by rotating the vertical adjusting screw so that the bubble in the vertical angle gage locates inside the adjusting marks.

## NOTE

The beam angle will change about  $0^{\circ}12'$  per a graduation.




## HORIZONTAL ADJUSTING

- (1) Adjust the horizontal angle by using a horizontal tester to turn the horizontal adjusting screw.
- (2) After adjusting, turn the center mark adjusting screw and check with the horizontal indicator that the center mark (red mark) on the indicator scale and the center mating mark (black mark) are aligned.

## NOTE

The beam angle will change about  $0^{\circ}23'$  per a graduation.







**LUMINOUS INTENSITY MEASUREMENT**

Measure the luminous intensity of headlights with a photometer in accordance with the instruction manual prepared by the manufacturer of the photometer and make sure that the luminous intensity is within the following limit.

**Limit: 20,000 cd or more**

**NOTE**


- (1) When measuring the luminous intensity of headlight, keep the engine at 2,000 rpm and have the battery charged.
- (2) If there are specific regulations for luminous intensity of headlights in the region where the vehicle is operated, make sure that the intensity conforms to the requirements of such regulations.




**REPLACEMENT OF REPLACEABLE BULB**

M5411GB

- (1) Remove the engine coolant reserve tank. (Left side only)
- (2) Disconnect the harness connector, and then pull out the socket cover.



- (3) Remove the locking cap by rotating it anti-clockwise and draw the socket together with bulb.



**Caution**

**Never hold the halogen light bulb with a bare hand, dirty glove, etc.**


**If the glass surface is dirty, be sure to clean it with alcohol, paint thinner, etc., and install it after drying it thoroughly.**

- (4) If the socket cover is not securely installed, the lens will be out of focus, or water will get inside the light unit, so the cover should be securely installed.

# HEADLIGHT AND FRONT COMBINATION LIGHT

M54IJAS


## REMOVAL AND INSTALLATION



### Removal steps

- ◄◄ ◄◄ 1. Front combination light
- ◄◄ 2. Radiator grille
- ◄◄ 3. Headlight

16E0456




### SERVICE POINT OF REMOVAL

#### 1. REMOVAL OF FRONT COMBINATION LIGHT

Remove the front combination light mounting screws and set spring, and remove the front combination light by pulling it towards the front of the vehicle.

#### NOTE


For the left side, before removing the front combination light, remove the engine coolant reserve tank in advance.



### SERVICE POINTS OF INSTALLATION

#### 3. INSTALLATION OF HEADLIGHT

After tightening the outside mounting bolt, tighten the inside mounting nut.




#### 1. INSTALLATION OF FRONT COMBINATION LIGHT

- (1) Align the front combination light positioning bosses with the insertion holes in the fender, and align the ribs with the headlight insertion holes.
- (2) While pushing the front combination light in towards the rear of the vehicle, pull the set spring into the engine compartment to tighten it to the vehicle body, and then tighten with the screw.

**REAR COMBINATION LIGHT  
REMOVAL AND INSTALLATION**

M54IMAM




**Removal steps**

1. Back door bumper cover
2. Rear combination light unit
3. Bulb
- Quarter trim (Refer to GROUP 52-Trim)
4. Socket assembly
5. Rear combination light bezel

16E0103

**LICENSE PLATE LIGHT  
REMOVAL AND INSTALLATION**

M54IVAD




**Removal steps**

1. Lens
2. Bulb
3. Lens gasket
- Back door trim (Refer to GROUP 42-Door Trim and Waterproof Film)
4. License plate light garnish
5. Socket assembly



16E0101



16E0071

**SERVICE POINT OF REMOVAL**

**4. REMOVAL OF LICENSE PLATE LIGHT GARNISH**


- (1) Take off the waterproof film and remove the license plate light garnish mounting nuts.
- (2) Remove the clips with a (-) screwdriver, and remove the license plate light garnish together with the socket assembly.

# HIGH MOUNTED STOP LIGHT REMOVAL AND INSTALLATION


M54IKAO

### Removal steps

1. Cover
2. Socket assembly
3. Bulb
4. High mounted stop light unit



16E0096



16E0400


## RELAY INSPECTION

M54ISAK

### Headlight Relay, Tail Light Relay

- (1) Remove the headlight relay or tail light relay from the relay box in the engine compartment.

- (2) Apply battery voltage to terminal (2), and check the continuity between the terminals when terminal (4) is grounded.




16L0301

16L0312

16W908

When power is supplied	Between terminals 1-3	Continuity
When power is not supplied	Between terminals 1-3	No continuity
	Between terminals 2-4	Continuity




16E0455

## HAZARD LIGHT SWITCH INSPECTION

M54IQAL

- (1) Remove the hazard light switch from the meter bezel.




(2) Operate the switch, and check the continuity between the terminals.

Terminal	1	2	3	4	5	6	7	8	9	10
Switch position										
OFF					○	○	○	○	○	○
ON	○	○	○	○	○	○				ILL


**NOTE**

○-○ indicates that there is continuity between the terminals.



**RHEOSTAT INSPECTION**

- (1) Instrument under cover. (Refer to GROUP 52 – Instrument Panel.)
- (2) Remove the rheostat from the instrument panel.



(3) Connect the battery and the test light (40W) as shown in the illustration.

(4) Operate the rheostat, and if the brightness changes smoothly without switching off, then the rheostat function is normal.

# COLUMN SWITCH

## SPECIFICATION

### GENERAL SPECIFICATIONS


Items	Specifications
Column switch	
Lighting switch	
Rated load	A 0.22 ± 0.05
Voltage drop	V 0.2 or less
Turn-signal switch	
Rated load	A 6.6 ± 0.5
Voltage drop	V 0.2 or less
Dimmer/passing switch	
Rated load	A
High beam	12
Low beam	10.8
Passing	22.8 ± 1.5
Voltage drop	V 0.2 or less

**NOTE**

For the windshield wiper and washer switch, refer to GROUP 51–Windshield Wiper and Washer.  
 For the headlight washer switch, refer to GROUP 51–Headlight Washer.

## COLUMN SWITCH


### REMOVAL AND INSTALLATION




**Removal steps**

1. Instrument under cover (Refer to GROUP 52–Instrument Panel)
2. Horn pad
3. Steering wheel
4. Column cover lower
5. Column cover upper
6. Column switch

16E0446



13E0030



16E0108

16E0018

16E0019

**SERVICE POINT OF REMOVAL**

**3. REMOVAL OF STEERING WHEEL**

Remove the steering wheel by using a steering wheel puller.

**Caution**

**Do not hammer on the steering wheel to remove it; doing so may damage the collapsible mechanism.**

**INSPECTION**

- (1) Remove the instrument under cover. (Refer to GROUP 52 – Instrument Panel.)
- (2) Remove the column cover lower.
- (3) Disconnect the connector at the column switch.
- (4) Operate the switch, and check the continuity between the terminals.

Switch position		Terminal																			
		1	5	6	11	14	17	18	19	20	22										
Lighting switch	OFF																				
	TAIL				○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○
	HEAD				○	—	—	○	—	—	—	—	—	—	—	—	—	—	—	—	○
Dimmer switch	LOW BEAM	○	—	○																	
	HIGH BEAM		○	○																	
Passing switch	P <sub>1</sub>	○	○	○	○	—	—	—	—												
	P <sub>2</sub>		○	○	○	—	—	—	—												
Turn-signal switch	RH													○	—	—	—	—	—	○	
	OFF																				
	LH													○	—	—	—	—	—	○	

**NOTE**


- (1) ○—○ indicates that there is continuity between the terminals.
- (2) P<sub>1</sub> represents the passing operation when the dimmer switch is in the "LOW BEAM" position, and P<sub>2</sub> represents the operation when it is in the "HIGH BEAM" position.
- (3) For inspection of the windshield wiper and washer switch, refer to GROUP 51–Windshield Wiper and Washer.
- (4) For inspection of the headlight washer switch, refer to GROUP 51–Headlight Washer.

# HORN

## SPECIFICATION

### GENERAL SPECIFICATIONS

Items	Specifications
Type	Flat type
Effective sounding voltage	V 11.5–15
Power consumption	A 3.0
Sound level	dB 100–112
Fundamental frequency	Hz
"Low" sound	350–390
"High" sound	359–435




## TROUBLESHOOTING

### OPERATION

- The battery voltage is constantly applied to the horn switch through the multi-purpose fuse No. ⑩.
- The (LO) and (HI) horns sounds when the horn switch is turned to "ON".

### TROUBLESHOOTING HINTS

1. The horns do not sound.
  - Check the horn switch.
  - Check the ground.
2. The either side hone only sounds.
  - Check the horn.





# CIGARETTE LIGHTER

## SPECIFICATION


### GENERAL SPECIFICATIONS

M54MB--

Items	Specifications
Max. input	W 120
Reset time	second Within 18
Thermal fuse fusion temperature	°C (°F) 180–250 (356–482)

## TROUBLESHOOTING

M54MHCE



### OPERATION

- When the plug is inserted into the socket, turn the cigarette lighter to "ON" with plug still inserted.
- Within 18 seconds after the plug element has started heating, the plug will automatically return and the cigarette lighter will switch "OFF".
- When the lighting switch is set to the "TAIL" or "HEAD" position, the tail light relay contact closes to turn the tail light relay "ON".
- Current flows via dedicated fuse No. ⑤ and the cigarette lighter illumination light and ashtray illumination light illuminate.


### TROUBLESHOOTING HINTS

1. The cigarette lighter does not illuminate.
  - Check the cigarette lighter. (Refer to P.54-66)
2. The cigarette lighter illumination light does not illuminate or does not dim.
  - (1) The tail lights illuminate.
    - Check the bulb.
    - Check the rheostat. (Refer to P.54-61)
  - (2) The tail lights also do not illuminate.
    - Check the dedicated fuse No. ⑤.
    - Check the tail light relay. (Refer to P.54-60)
    - Check the lighting switch. (Refer to P.54-63)
3. The ashtray illumination light does not illuminate.
  - (1) The tail lights illuminate.
    - Check the bulb.
  - (2) The tail lights also do not illuminate.
    - Refer to the item 2, step (2).

# CIGARETTE LIGHTER

## REMOVAL AND INSTALLATION

M54MJAP



### Removal steps

1. Front console box  
(Refer to GROUP 52 – Console Box)
2. Plug
3. Nut
4. Outer case
5. Washer
6. Socket
7. Protector

### INSPECTION

- Take out the plug, and check for a worn edge on the element spot connection, and for shreds of tobacco or other material on the element.
- Using an ohmmeter, check the continuity of the element.

### CAUTIONS FOR USE OF THE CIGARETTE LIGHTER SOCKET AS AUXILIARY POWER SOURCE

1. When using a "plug-in" type of accessory, do not use anything with a load of more than 120W.
2. It is recommended that only the lighter be inserted in the receptacle.  
Use of "plug-in" type accessories may damage the receptacle and result in poor retention of the lighter.


#### NOTE

The specified load should be strictly observed, because overloaded cord burns the ignition switch and harness.

# ACCESSORY SOCKET

## TROUBLESHOOTING

M54MHCF




### OPERATION

- When the ignition switch is turned to the "ACC" or "ON" position, current flows to the coil side of the accessory socket relay.
- The accessory socket relay contact closes to turn the accessory socket relay "ON".
- When an inspection light or plug-in type accessories are plugged into the accessory socket, the inspection light or accessories can be used.

### TROUBLESHOOTING HINTS


1. The inspection light or accessories cannot be used.
  - Check the accessory socket relay. (Refer to P.54-68)
  - Check the multi-purpose fuse No. ⑭.

# ACCESSORY SOCKET REMOVAL AND INSTALLATION




**Removal steps**

- Front console box (Refer to GROUP 52 – Console Box)
- Quarter trim (LH) (Refer to GROUP 52 – Trim)
- 1. Socket
- 2. Outer case



**INSPECTION**

(1) Remove the accessory socket relay from the junction block.



(2) Apply battery voltage to terminal (2), and check the continuity between the terminals when terminal (4) is grounded.

When power is supplied	Between terminals 1-3	Continuity
When power is not supplied	Between terminals 1-3	No continuity
	Between terminals 2-4	Continuity

# CLOCK

## SPECIFICATION


### GENERAL SPECIFICATIONS

M54MB--

Item	Specification
Type	Crystal oscillator
Display method	Fluorescent digital display
Standard error (seconds/day)	±2


## TROUBLESHOOTING

M54MHAG




# AUDIO SYSTEM TROUBLESHOOTING

<VEHICLES WITH WHIP ANTENNA>




<VEHICLES WITH MOTOR ANTENNA AND GLASS ANTENNA>



KX35-AC-01402-N

TSB Revision






**TROUBLESHOOTING CHART**

Item	Problem symptom	Relevant chart
Noise	Noise appears at certain places when traveling (AM).	A-1
	Noise appears at certain places when traveling (FM).	A-2
	Mixed with noise, only at night (AM).	A-3
	Broadcasts can be heard but both AM and FM have a lot of noise.	A-4
	There is more noise either on AM or on FM.	A-5
	There is noise when starting the engine.	A-6
	Some noise appears when there is vibration or shocks during traveling.	A-7
	Noise sometimes appears on FM during traveling.	A-8
	Ever-present noise.	A-9
Radio	When switch is set to ON, no power is available.	B-1
	No sound from one speaker.	B-2
	There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.	B-3
	Insufficient sensitivity.	B-4
	Distortion on AM or on both AM and FM.	B-5
	Distortion on FM only.	B-6
	Too few automatic select stations.	B-7
	Insufficient memory (preset stations are erased).	B-8
Cassette player	Cassette tape will not insert.	C-1
	No sound.	C-2
	No sound from one speaker.	C-3
	Sound quality is poor, or sound is weak.	C-4
	Cassette tape will not eject.	C-5
	Uneven revolution. Tape speed is fast or slow.	C-6
	Automatic search does not work	C-7
	Faulty auto reverse.	C-8
	Tape gets caught in mechanism.	C-9
CD player	CD will not be accepted.	D-1
	No sound.	D-2
	CD sound skips.	D-3
	Sound quality is poor.	D-4
	CD will not be ejected.	D-5
	No sound from one speaker.	D-6
Motor antenna	Motor antenna won't extend or retract.	E-1
	Motor antenna extends and retracts but does not receive.	E-2


CHART

A. NOISE

**A-1 Noise appears at certain places when traveling (AM).**



**A-2 Noise appears at certain places when traveling (FM).**



**NOTE**

About FM waves:

FM waves have the same properties as light, and can be deflected and blocked. Wave reception is not possible in the shadow of obstructions such as buildings or mountains.

1. The signal becomes weak as the distance from the station's transmission antenna increases. Although this may vary according to the signal strength of the transmitting station and intervening geographical formations or buildings, the area of good reception is approx. 20–25 km (12–16 miles) for stereo reception, and 30–40 km (19–25 miles) for monaural reception.
2. The signal becomes weak when an area of shadow from the transmitting antenna (places where there are obstructions such as mountains or buildings between the antenna and the car), and noise will appear. <This is called first fading, and gives a steady buzzing noise>
3. If a direct signal hits the antenna at the same time as a signal reflected by obstructions such as mountains or buildings, interference of the two signals will generate noise. During traveling,


noise will appear each time the vehicle's antenna passes through this kind of obstructed area. The strength and interval of the noise varies according to the signal strength and the conditions of deflection. <This is called multipath noise, and is a repetitious buzzing.>

4. Since FM stereo transmission and reception has a weaker field than monaural, it is often accompanied by a hissing noise.
5. Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user.

Diversity antenna system:


A system where two types of antenna (glass antenna and whip antenna or motor antenna) are equipped and the antenna that provides the best reception can be selected.

**FM Broadcast Good Reception Areas**



16A0663

**FM Signal Characteristics and Signal Interference**



16A0664

**A-3 Mixed with noise, only at night (AM).**


The following factors can be considered as possible causes of noise appearing at night.

1. Factors due to signal conditions: Due to the fact that long-distance signals are more easily received at night, even stations that are received without problem during the day may experience interference in a general worsening of reception conditions. The weaker a station is the more susceptible it is to interference, and a change to a different station or the appearance of a beating

sound\* may occur.

Beat sound\*: Two signals close in frequency interfere with each other, creating a repetitious high-pitched sound. This sound is generated not only by sound signals but by electrical waves as well.

2. Factors due to vehicle noise: Alternator noise may be a cause.



**A-4 Broadcast can be heard but both AM and FM have a lot of noise.**

(1)

Noise occurs when the engine is stopped.

Yes

Do the following measures eliminate the noise?

- Tune to a station with a strong signal.
- Extend the antenna completely. (Whip antenna)
- Adjust the sound quality to suppress high tones.

Yes

OK

No

Is the radio body ground mounted securely?

No

Securely tighten the nuts for the body ground

Yes

Is the antenna plug properly connected to the radio?

No

Correctly attach the antenna plug.

Yes

Is the antenna itself in good condition or is it properly mounted?

No

Clean the antenna plug and ground wire mounting area. Mount the antenna securely. On a vehicle with a motor antenna, check the antenna itself. (Refer to E-1, 2.)

Yes

Is the noise eliminated?

Yes

OK

No

If there is more noise than other radios, consult a service center.

(2)

Noise occurs when the engine is running.

Inspect the vehicle's noise suppressor. (refer to A-6.)


**NOTE**

- About noise encountered during FM reception only. Due to differences in FM and AM system, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics of FM waves of noise or distortion generated by typical noise interference (first fading and multipath). (Refer to A-2.)  
<Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

- Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user.  
Diversity antenna system:  
A system where two types of antenna (glass antenna and whip antenna or motor antenna) are equipped and the antenna that provides the best reception can be selected.

## A-5 There is more noise either on AM or on FM.

1. There is much noise only on AM  
Due to differences in AM and FM systems, AM is more susceptible to noise interference.



2. There is much noise only on FM
- Due to differences in FM and AM systems, FM is not as susceptible as AM to interference from engines, power lines, lightning, etc. On the other hand, there are cases due to the characteristics of FM waves of noise or distortion generated by typical noise interference (first fading and multipath). (Refer to A-2)  
<Noise (hissing) occurs in weak signal areas such as mountainous regions, but this is not due to a problem with the radio.>

- Furthermore, the amount of interference will be comparatively less for vehicles equipped with a diversity antenna system. If there is an equivalent amount of distortion in vehicles or radios of the same type, then differences will be because of differences in antenna systems, and this should be explained to the user.  
Diversity antenna system:  
A system where two types of antenna (glass antenna and whip antenna or motor antenna) are equipped and the antenna that provides the best reception can be selected.

**A-6 There is noise when starting the engine.**

Noise type Sounds are in parentheses ( ).	Conditions	Cause	Inspection or replacement	
			Noise-preventive part	Mounting place (next page)
AM, FM: Ignition noise (Popping, Snapping, Cracking, Buzzing)	<ul style="list-style-type: none"> <li>Increasing the engine speed causing the popping sound to speed up, and volume decreases.</li> <li>Disappears when the ignition switch is turned to ACC.</li> </ul>	<ul style="list-style-type: none"> <li>Mainly due to the spark plugs.</li> <li>Due to the engine noise.</li> </ul>	<ul style="list-style-type: none"> <li>Noise filter</li> <li>Ground cable</li> <li>Noise capacitor</li> </ul>	1 2, 3 1
Other electrical components	–	Noise may appear as electrical components become older.	Repair or replace electrical components.	
Static electricity (Cracking, Crinkling)	<ul style="list-style-type: none"> <li>Disappears when the vehicle is completely stopped.</li> <li>Severe when the clutch is engaged.</li> </ul>	Occurs when parts or wiring move for some reason and contact metal parts of the body.	Return parts or wiring to their proper position.	
	<ul style="list-style-type: none"> <li>Various noises are produced depending on the body part of the vehicle.</li> </ul>	Due to detachment from the body of the front hood, bumpers, exhaust pipe and muffler, suspension, etc.	Ground parts by bonding. Cases where the problem is not eliminated by a single response to one area are common, due to several body parts being imperfectly grounded.	

**Caution**

1. **Connecting a high tension cable to the noise filter may destroy the noise filter and should never be done.**
2. **Check that there is no external noise. Since failure due this may result in misdiagnosis due to inability to identify the noise source, this operation must be performed.**
3. **Noise prevention should be performed by suppressing strong sources of noise step by step.**

**NOTE**

1. Capacitor  
The capacitor does not pass D.C. current, but as the number of waves increases when it passes A.C. current, impedance (resistance


against A.C.) decreases, and current flow is facilitated. A noise suppressing capacitor which takes advantage of this property is inserted between the power line for the noise source and the ground. This suppressed noise by grounding the noise component (A.C. or pulse signal) to the body of the vehicle.

2. Coil




The coil passes D.C. current, but impedance rises as the number of waves increases relative to the A.C. current. A noise suppressing coil which takes advantage of this property is inserted into the power line for the noise source, and works by preventing the noise component from flowing or radiating out of the line.



NOISE SUPPRESSOR MOUNTING LOCATION




18E0003






**A-7** Some noise appears when there is vibration or shocks during traveling.



## A-8 Noise sometimes appears on FM during traveling.



\* About multipath noise and fading noise  
Because the frequency of FM waves is extremely high, it is highly susceptible to effects from geological formations and buildings. These effects disrupt the broadcast signal and obstruct reception in several ways.

- Multipath noise  
This describes the echo that occurs when the broadcast signal is reflected by a large obstruction

and enters the receiver with a slight time delay relative to the direct signal (repetitious buzzing).

- Fading noise  
This is a buzzing noise that occurs when the broadcast beam is disrupted by obstructing objects and the signal strength fluctuates intricately within a narrow range.

**A-9 Ever-present noise.**


Noise is often created by the following factors, and often the radio is OK when it is checked individually.

- Traveling conditions of the vehicle
- Terrain of area traveled through
- Surrounding buildings
- Signal conditions
- Time period


For this reason, if there are still problems with noise even after the measures described in steps A-1 to A-8 have been taken, get information on the factors listed above as well as determining whether the problem occurs with AM or FM, the station names, frequencies, etc., and contact a service center.

**B. RADIO**


**B-1 No power is supplied when the switch is set to ON.**




**B-2 No sound from one speaker.**



**B-3** There is noise but no reception for both AM and FM or no sound from AM, or no sound from FM.




**B-4** **Unsufficient sensitivity.**




\* For multipath noise and fading noise problems, refer to P.54-82.


**B-5 Distortion on AM or on both AM and FM.**




**B-6 Distortion on FM only.**



**B-7 Too few automatic select stations.**




**B-8 Insufficient memory (preset stations are erased).**




## C. CASSETTE PLAYER

## C-1 Cassette tape will not be inserted.





## C-2 No sound (even after a tape has been inserted).





**C-3 No sound from one speaker.**




**C-4 Sound quality is poor, or sound is weak.****C-5 Cassette tape will not eject.**

The problems covered here are all the result of the use of a bad tape (deformed or not properly tightened) or of a malfunction of the cassette player itself. Malfunctions involving the tape becoming caught in the mechanism and ruining

the case are also possible, and attempting to force the tape out of the player can cause damage to the mechanism. The player should be taken to a service dealer for repair.


**C-6 Uneven revolution. Tape speed is fast or slow.**



\*1  
Ensure that the tape label is not loose, that the tape itself is not deformed and that the tape is tightly wound. Also, tape of C-120 or greater length often get caught in the mechanism and should not be used.

\*2  
Attempting to force a foreign object (e.g., a coin or clip, etc.) out of the cassette player may damage the mechanism. The player should be taken to a service dealer for repair.


**C-7 Automatic search does not work.**



\*1  
● When the time between songs on a tape is less than three seconds, or when there is a three second period in the middle of a song in which the volume level is extremely low, the automatic search function may not work properly.


\*2  
● Ensure that the tape label is not loose, that the tape itself is not deformed and that the tape is tightly wound. Also, tapes of C-120 or greater length often get caught in the mechanism and should not be used.

**C-8** Faulty auto reverse.




**C-9** Tape gets caught in mechanism\*<sup>1</sup>.

**\*1**  
When the tape is caught in the mechanism, the case may not eject. When this occurs, do not try to force the tape out as this may damage the tape player mechanism. Take the cassette to a service dealer for repair.



D. CD PLAYER




\*1 If the CD is already loaded, doesn't the shutter open to allow insertion when another CD is inserted?

\*2 If the key switch is not at ACC or ON, the CD stops at depth of 15 mm below the panel surface even when it is inserted, and it will be rejected when pushed farther?


\*3 Even though the CD is loaded, E (error) is sometimes displayed with the CD rejected because of vibration/shock or dew on the CD face or optical lens.

**D-2 No sound.**




**D-3 CD sound skips.**


1. Sound sometimes skips during parking.




2. Sound sometimes skips during driving.  
 (Stop vehicle, and check it.)  
 (Check it by using a proper CD which is free of scratch, dirt or other abnormality.)




**D-4 Sound quality is poor.**



**D-5 CD will not be ejected.**




**D-6 No sound from one speaker.**



## E. MOTOR ANTENNA



## E-1 Motor antenna won't extend or retract.

Clean and polish the surface of the antenna pole.





**E-2 Motor antenna extends and retracts but does not receive.**




Checking the antenna\*

Ohmmeter measurement locations	Result
Circuits from F to A, B, C, D and E	Continuity
Circuit between G and H	Continuity
Circuits from H to A, B, C, D and E	No continuity

# RADIO WITH CASSETTE PLAYER AND CD PLAYER

M54NJAT


## REMOVAL AND INSTALLATION



## SPEAKER

### REMOVAL AND INSTALLATION

M54NMAN



#### Removal steps of front speaker

1. Instrument corner cover <RH speaker>
2. Instrument under cover <LH speaker>  
(Refer to GROUP 52 – Instrument Panel)
3. Speaker

#### Removal steps of door speaker

- Door trim (Refer to GROUP 42 – Door Trim and Waterproof Film)
- 3. Speaker
- 4. Speaker cover

#### Removal steps of rear speaker

- Quarter trim (Refer to GROUP 52 – Trim)
- 3. Speaker
- 4. Speaker cover


NOTE \* indicates that the speakers are installed on the right side also.

16E0044

# ANTENNA AND ANTENNA FEEDER CABLE <WHIP ANTENNA AND ANTENNA FEEDER CABLE>

M54NPAL


## REMOVAL AND INSTALLATION



### Removal steps

- Radio with cassette player and CD player  
(Refer to P.54-98)
- 1. Foot shower duct
- 2. Glove box stopper
- 3. Glove box assembly
- 4. Cable band or tape
- 5. Antenna pole
- 6. Mounting nut
- 7. Mounting insulator and packing
- Splash shield  
(Refer to GROUP 42-Fender)
- 8. Antenna base and feeder cable

16E0442



16E0076


### SERVICE POINT OF REMOVAL

#### 8. REMOVAL OF ANTENNA BASE AND FEEDER CABLE

For ease of the installation, tie a [approx. 3 m (9.84 ft. length)] to the feeder cable. Pull out the feeder cable together with antenna base.

**<MOTOR ANTENNA AND ANTENNA FEEDER CABLE>**

M54NPBK

**REMOVAL AND INSTALLATION**

16E0441

**Removal steps of motor antenna and antenna feeder cable**

- Radio with cassette player and CD player (Refer to P.54-98)
- 2. Foot shower duct
- 3. Glove box stopper
- 4. Glove box assembly
- 5. Cable band or tape
- 6. Ring nut
- 7. Base
- 8. Motor antenna and antenna feeder cable

**NOTE**

The antenna feeder cable marked "\*" is co-binded with back door wiring harness.

**Removal steps of antenna feeder cable**


- Radio with cassette player and CD player (Refer to P.54-98)
- Front console assembly } (Refer to GROUP
- Rear console assembly } 52-Floor Console
- Front seat } (Refer to GROUP 52-
- (Passenger's side) } Front Seat, Rear Seat
- Rear seat
- Cowl side trim (RH),
- Center pillar trim lower (RH) } (Refer to GROUP
- Quarter trim lower (RH) } 52-Trim
- 9. Antenna feeder cable

**Removal steps of motor antenna control unit**


- Radio with cassette player and CD player (Refer to P.54-98)
- 1. Motor antenna control unit

**SERVICE POINT OF REMOVAL****8. REMOVAL OF MOTOR ANTENNA AND ANTENNA FEEDER CABLE**

For ease of the installation, tie a [approx. 3 m (9.84 ft. length)] to the feeder cable. Pull out the feeder cable together with motor antenna.




16E0077



**INSPECTION**

**MOTOR ANTENNA INSPECTION**


- (1) Remove the radio with cassette player (Refer to P.54-98.)
- (2) Remove the motor antenna control unit connector and check if the antenna goes up when the battery (+) side is connected to terminal (1), and the battery (-) side to terminal (4), and check if it goes down when the connections are reversed.



**MOTOR ANTENNA CONTROL UNIT INSPECTION**



- (1) Remove the radio with cassette player (Refer to P.54-98.)
- (2) Remove the motor antenna control unit mounting bolt.
- (3) With the ignition switch turned to ACC or ON, operate the radio switch and check the voltage between the terminals while raising and lowering the antenna.




Antenna operation direction	Measurement terminals	Voltage (V)
Lowering	1-3	10-13
Raising	4-3	10-13



**ANTENNA POLE REPLACEMENT**

- (1) Remove the ring nut.
- (2) After turning the ignition switch to ACC or ON, turn the radio switch to ON to raise the antenna pole, and remove it, together with the rack cable.





(3) Draw out the antenna pole to the maximum extension.

**NOTE**

If there is a bend in the motor end of the rack cable remove the bend.

(4) Insert the rack cable into the motor assembly with the rack cable teeth facing the engine compartment side.

(5) Turn the rack cable teeth towards the front of the vehicle (90° to right) so that the rack cable meshes with the motor gear.


(6) If the rack cable pulls out with no resistance when it is lightly pulled, then the cable is not meshed with the motor gear, so check that there are no bends in the end of the rack cable, and then repeat steps (3) and (4) above.


(7) Set the antenna pole vertically and turn the radio switch OFF to wind up the rack cable. Insert the antenna to the motor antenna side to align it with the wound-up rack cable.

(8) After tightening the ring nut, check the movement of the antenna by turning the radio switch ON and OFF.

# BACK DOOR WINDOW DEFOGGER TROUBLESHOOTING

## BACK DOOR WINDOW DEFOGGER CIRCUIT







**OPERATION**


- When the ignition switch is at the "ON" position and the defogger switch is set to the "ON" (automatic return switch) position, current flows from the defogger timer to the coil side of the defogger relay for a period of 9 to 11 minutes.
- When the defogger relay contact closes to turn the defogger relay "ON" and the defogger has operated for 9 to 11 seconds, the indicator light of the defogger switch illuminates at the same time to inform the driver that the defogger is operating.


**NOTE**

- After the defogger has operated for 9 to 11 minutes, it will automatically stop. Also, if the defogger switch is pressed again while the defogger is operating or if there is no alternator current (terminal L drops to 3.5V or below), the defogger will stop operating.
- When the lighting switch is set to the "TAIL" or "HEAD" position, the tail light relay contact closes to turn the tail light relay "ON", and the defogger switch illumination light will illuminate.

**TROUBLESHOOTING HINTS**

1. The defogger does not operate.
  - (1) The indication light illuminates.
    - Check the ground circuit.
  - (2) The indicator light also does not illuminate.
    - Check the fusible link No. ⑨.
    - Check the defogger relay. (Refer to P.54-107)
    - Check the defogger switch. (Refer to P.54-106)
    - Check the defogger timer. (Refer to P. 54-107)
2. The defogger switch illumination light does not illuminate or does not dim.
  - (1) The tail lights illuminate.
    - Check the defogger switch. (Refer to P.54-106)
    - Check the rheostat. (Refer to P.54-61)
  - (2) The tail lights also do not illuminate.
    - Check the dedicated fuse No. ⑤.
    - Check the defogger relay. (Refer to P.54-107)
    - Check the lighting switch. (Refer to P.54-63)





## SERVICE ADJUSTMENT PROCEDURES

M54POAD

### THE PRINTED-HEATER LINES CHECK

- (1) Run engine at 2,000 r/min. Check heater element with battery at full.
- (2) Turn ON rear window defogger switch. Measure heater element voltage with circuit tester at rear window glass center A.  
Condition good if indicating about 6V.
- (3) If 12 V is indicated at A, there is a break in the negative terminals from A.  
Move test bar slowly to negative terminal to detect where voltage changes suddenly (0 V).
- (4) If 0 V is indicated at A, there is a break in the positive terminals from A. Detect where the voltage changes suddenly (12 V) with the same method described.

### THE PRINTED-HEATER LINES REPAIR


#### REQUIRED MATERIALS

- Thinner
- Tape
- Conductive paint
- Lead-free gasoline
- Fine brush

- (1) Clean disconnected area with lead-free gasoline. Tape along both sides of heater element.
- (2) Mix conductive paint thoroughly. Thin the required amount of paint in a separate container with a small amount of thinner and paint break three times at 15 minute intervals.
- (3) Remove tape and leave for a while before use (circuit complete).
- (4) When completely dry (after 24 hours) finish exterior with a knife.

#### Caution

**Clean glass with a soft cloth (dry or damp) along defogger heater element.**





### DEFOGGER SWITCH

M54PJBO

#### INSPECTION

- (1) Remove rear window defogger switch from the meter bezel.






- (2) Operate the switch and check the continuity between the terminals.

Terminal	1	3	4	5	2	6
Switch position						
OFF	○—○		○—○			
ON		ILL		IND	○—○	

NOTE

○—○ indicates that there is continuity between the terminals.




## DEFOGGER RELAY

M54PLAH


### INSPECTION

- (1) Remove the instrument under cover. (Refer to GROUP 52—Instrument Panel.)  
 (2) Remove the defogger relay from the relay bracket.



- (3) Connect battery power source to terminal 5. Check circuit between terminals with terminal 3 grounded.

Power is supplied	1-2 terminals	Continuity
Power is not supplied	1-2 terminals	No continuity
	3-5 terminals	Continuity




## DEFOGGER TIMER

M54PPAE


### INSPECTION

- (1) Remove the instrument under cover. (Refer to GROUP 52—Instrument Panel)  
 (2) Remove the defogger timer from the relay bracket.



- (3) Connect the battery and the test light to the timer as shown in the figure.  
 (4) Check to be sure that the test light illuminates for approximately eleven seconds when battery voltage is applied to terminal 3 for a few seconds.  
 (5) Check to be sure that the test light switches OFF when battery voltage is again applied, during the test described above, to terminal 3.

# NOTES



NOTE

○—○ indicates that there is continuity between the terminals.

## DEFROGGER RELAY

### INSPECTION

- (1) Remove the instrument under cover (Refer to DR017, 52-Instrument Panel).
- (2) Remove the defogger relay from the relay bracket.

- (3) Connect battery power source to terminal 2 (check out between terminals with terminal 3 grounded).

Terminal	Power is supplied	Terminal	Power is not supplied
1-2 terminals	Yes	1-3 terminals	No
2-3 terminals	No	2-4 terminals	Yes

## DEFROGGER TIMER






### INSPECTION

- (1) Remove the instrument under cover (Refer to DR017, 52-Instrument Panel).
- (2) Remove the defogger timer from the relay bracket.

- (3) Connect the battery and the test light to the timer as shown in the figure.

- (4) Check to be sure that the test light illuminates as the defogger timer is energized. If the test light does not illuminate, check to terminal 2 for a bad contact.

- (5) Check to be sure that the test light switches OFF when battery voltage is again applied during the test procedure. If the test light does not switch OFF, check to terminal 2.



## A

ABS, Troubleshooting .....	35-6-I
ABS POWER RELAY, Check .....	35-52-I
ACCELERATOR CABLE .....	13-104-I
ACCELERATOR CABLE	
Free Play Adjustment .....	13-103-I
Inspection and Adjustment .....	13-14-I
ACCELERATOR PEDAL .....	13-104-I
ACCESSORY SOCKET .....	54-67-II
AIR BLEEDING .....	37-12-I
AIR CLEANER ELEMENT, Maintenance .....	00-35-I
AIR CONDITIONER .....	55-12-I
AIR CONDITIONER CONTROL UNIT .....	55-31-I
AIR CONDITIONER POWER RELAY, On-vehicle Inspection .....	13-70-I
AIR CONDITIONER SWITCH .....	55-28-I
AIR CONDITIONER SWITCH, On-vehicle Inspection .....	13-70-I
AIR FLOW SENSOR, On-vehicle Inspection .....	13-42-I
AIR LEAKAGE, Rear Differential Lock System, Check .....	27-14-I
ALIGNMENT	
Front Wheel, Inspection and Adjustment .....	33-11-I
Rear Wheel, Adjustment .....	34-3-I
ALTERNATOR .....	16-11-II
ALTERNATOR OUTPUT WIRE, Voltage Drop Test .....	16-5-II
ANTENNA .....	54-99-II
ANTENNA FEEDER CABLE .....	54-99-II
ANTI-LOCK BRAKING SIGNAL, On-vehicle Inspection .....	13-90-I
ANTI-LOCK BRAKING SYSTEM, Troubleshooting .....	35-6-I
ARM	
Lower <Front Suspension> .....	33-15-I
Lower <Rear Suspension> .....	34-4-I
Upper <Front Suspension> .....	33-13-I
AUDIO SYSTEM .....	54-70-II
AUTO-CRUISE CONTROL CABLES, Inspection and	
Adjustment .....	13-126-I
AUTO-CRUISE CONTROL INDIVIDUAL PARTS, Inspection .....	13-129-I
AUTO-CRUISE CONTROL MAIN SWITCH, Inspection .....	13-127-I
AUTO-CRUISE CONTROL SWITCH, Inspection .....	13-128-I
AUTO-CRUISE CONTROL SYSTEM .....	13-105-I
AUTOMATIC TRANSMISSION, Maintenance .....	00-40-I
AUTOMATIC TRANSMISSION FLUID	
Change .....	23-29-I
Inspection .....	23-28-I
AXLE BUMPER .....	34-8-I
AXLE HOUSING OIL SEAL, Replacement .....	27-13-I
AXLE HUB (Front Axle) .....	26-11-I
AXLE SHAFT .....	27-17-I
AXLE SHAFT, End Play Check .....	27-12-I
AXLE .....	27-15-I
AXLE	
Front, Maintenance .....	00-44-I
Front, Total Backlash Check .....	26-8-I
Rear, Maintenance .....	00-44-I

## B

BACK DOOR .....	42-43-I
BACK DOOR, Adjustment .....	42-17-I
BACK DOOR HANDLE .....	42-45-I
BACK DOOR LATCH .....	42-45-I
BACK DOOR TRIM .....	42-44-I
BACK DOOR WATERPROOF FILM .....	42-44-I
BACK DOOR WINDOW DEFOGGER .....	54-103-II
BACK DOOR WINDOW DEFOGGER, Adjustment .....	54-106-II
BACK DOOR WINDOW GLASS .....	42-29-I

BACKLASH, Total, Rear Axle, Check .....	27-11-I
BALL JOINT	
End Play Check .....	37-7-I
Tie Rod End, Starting Torque Check .....	37-8-I
BALL JOINT DUST COVER, Replacement .....	33-14-I
BALL JOINT SEALS, Maintenance .....	00-43-I
BALL JOINT WITH GREASE FITTING, Maintenance .....	00-43-I
BAR	
Stabilizer <Front Suspension> .....	33-20-I
Stabilizer <Rear Suspension> .....	34-9-I
Torsion .....	33-18-I
BAROMETRIC PRESSURE SENSOR, On-vehicle Inspection .....	13-48-I
BASIC IDLE SPEED, Adjustment .....	13-26-I
BATTERY .....	54-2-II
BATTERY, Adjustment .....	54-3-II
BELT	
Drive, Compressor, Adjustment .....	55-22-I
Drive, Deflection Adjustment .....	14-5-I
Drive, Deflection Check .....	14-5-I
Drive, Maintenance .....	00-38-I
Drive, Tension Inspection and Adjustment .....	11-11-I
Timing .....	11-23-I
Timing, Maintenance .....	00-38-I
Timing, Tension Adjustment .....	11-8-I
BLEEDING	
Clutch .....	21-4-I
Brake .....	35-41-I
Steering .....	37-12-I
BLOWER .....	55-8-I
BODY MOUNTING .....	42-19-I
BOOSTER	
Brake .....	35-56-I
Brake, Operating Test .....	35-38-I
BOOTS, Drive Shaft, Maintenance .....	00-43-I
BRAKE	
Disc, Front .....	35-63-I
Disc, Rear .....	35-68-I
BRAKE BOOSTER .....	35-56-I
BRAKE BOOSTER, Operating Test .....	35-38-I
BRAKE CABLE, Parking .....	36-5-I
BRAKE DISC	
Front, Run-out Check .....	35-44-I
Front, Thickness Check .....	35-44-I
Rear, Run-out Check .....	35-46-I
Rear, Run-out Correction .....	35-46-I
Rear, Thickness Check .....	35-46-I
BRAKE DRAG, Check .....	35-42-I
BRAKE DRUM	
Connection Check with Brake Lining .....	35-47-I
Inside Diameter Check .....	35-47-I
Parking .....	36-7-I
BRAKE FLUID LEVEL SENSOR, Check .....	35-39-I
BRAKE HOSES, Maintenance .....	00-43-I
BRAKE LEVER	
Parking .....	36-4-I
Parking, Stroke Inspection and Adjustment .....	36-3-I
BRAKE LINE .....	35-61-I
BRAKE LINING	
Connection Check with Brake Drum .....	35-47-I
Thickness Check .....	35-47-I
BRAKE PAD	
Disc, Check .....	35-42-I
Disc, Front, Replacement .....	35-42-I
Disc, Rear, Check and Replacement .....	35-44-I
BRAKE PEDAL .....	35-54-I

BRAKE PEDAL, Inspection and Adjustment .....	35-38-I
BUMPER	
Axle .....	34-8-I
Front .....	51-11-I
Rear .....	51-12-I
BUSHING	
Lateral Rod, Replacement .....	34-7-I
Lower Arm, Rear, Replacement .....	34-4-I
Lower Arm, Replacement .....	33-16-I
<b>C</b>	
CABLE	
Accelerator, Free Play Adjustment .....	13-103-I
Accelerator, Inspection and Adjustment .....	13-14-I
Accelerator .....	13-104-I
Antenna Feeder .....	54-99-II
Auto-cruise Control, Inspection and Adjustment .....	13-126-I
High Tension, Spark Test .....	16-29-II
Ignition, Maintenance .....	00-37-I
Parking Brake .....	36-5-I
Spark Plug, Test .....	16-29-II
Speedometer, Replacement .....	22-8-I
Speedometer, Replacement .....	23-34-I
Throttle, Check and Adjustment .....	23-29-I
CAMSHAFT OIL SEAL .....	11-15-I
CANISTER, Maintenance .....	00-36-I
CAP, Distributor, Maintenance .....	00-37-I
CASSETTE PLAYER .....	54-98-II
CATALYTIC CONVERTER .....	15-4-I
CD PLAYER .....	54-98-II
CENTER DIFFERENTIAL LOCK DETECTION SWITCH	
Check <A/T> .....	23-30-I
Check <M/T> .....	22-6-I
CENTER DIFFERENTIAL LOCK OPERATION DETECTION SWITCH	
Check <A/T> .....	23-30-I
Check <M/T> .....	22-6-I
CHARGING .....	55-22-I
CHARGING SYSTEM .....	16-2-II
CHARGING SYSTEM	
Check with Analyzer .....	16-9-II
Inspection .....	16-5-II
Output Current Test .....	16-6-II
Regulated Voltage Test .....	16-7-II
CHECK VALVE, Operation Check .....	35-39-I
CIGARETTE LIGHTER .....	54-65-II
CLOCK .....	54-69-II
CLUTCH, Free-wheeling .....	26-32-I
CLUTCH CONTROL .....	21-6-I
CLUTCH MASTER CYLINDER .....	21-8-I
CLUTCH PEDAL .....	21-5-I
CLUTCH PEDAL, Inspection and Adjustment .....	21-3-I
COIL, Ignition, On-vehicle Inspection .....	13-84-I
COIL SPRING .....	34-8-I
COLUMN SWITCH .....	54-62-II
COMBINATION LIGHT	
Front .....	54-58-II
Rear .....	54-59-II
COMBINATION METER .....	54-34-II
COMPRESSION PRESSURE, Check .....	11-7-I
COMPRESSOR .....	55-34-I
COMPRESSOR, Noise Adjustment .....	55-27-I
COMPRESSOR DRIVE BELT, Adjustment .....	55-22-I
CONDENSER .....	55-32-I
CONDENSER FAN MOTOR .....	55-32-I

CONSOLE, Floor .....	52-6-I
CONTROL CABLE, Adjustment .....	23-31-I
CONTROL LEVER .....	22-9-I
CONTROL SWITCH <Front Suspension> .....	33-20-I
CONTROL SYSTEM	
Crankcase Emission .....	17-4-I
Evaporative Emission .....	17-5-I
Exhaust Emission .....	17-8-I
CONTROL UNIT	
Air Conditioner .....	55-31-I
4WD Indicator, Check .....	23-34-I
4WD Indicator, Inspection .....	22-7-I
Front Suspension .....	33-21-I
Electronic <ABS> .....	35-77-I
COOLANT	
Engine, Concentration Test .....	14-5-I
Engine, Leak Check .....	14-4-I
Engine, Maintenance .....	00-41-I
Engine, Replacement .....	14-5-I
COOLING FAN .....	14-7-I
CRANK ANGLE SENSOR, On-vehicle Inspection .....	13-60-I
CRANKCASE EMISSION CONTROL SYSTEM .....	17-4-I
CRANKCASE EMISSION CONTROL SYSTEM, Maintenance .....	00-35-I
CRANKSHAFT OIL SEAL	
Front .....	11-16-I
Rear .....	11-17-I
CURB IDLE SPEED, Inspection .....	11-6-I
CYLINDER, Master .....	35-56-I
CYLINDER HEAD GASKET .....	11-20-I

**D**

DEFOGGER, Back Door Window .....	54-103-II
DEFOGGER, Back Door Window, Adjustment .....	54-106-II
DEFOGGER RELAY .....	54-107-II
DEFOGGER SWITCH .....	54-106-II
DEFOGGER TIMER .....	54-107-II
DIFFERENTIAL, Limited Slip, Preload Measurement .....	27-12-I
DIFFERENTIAL CARRIER	
Front Axle .....	26-34-I
Rear Axle .....	27-25-I
DIFFERENTIAL CARRIER AND FREE-WHEELING CLUTCH .....	26-30-I
DIFFERENTIAL CARRIER OIL SEAL, Replacement .....	26-8-I
DIFFERENTIAL LOCK, Rear .....	27-22-I
DIFFERENTIAL LOCK SYSTEM, Rear, Air Leakage Check .....	27-14-I
DIFFERENTIAL MOUNTING, Front .....	32-3-I
DISC	
Brake, Front, Run-out Check .....	35-44-I
Brake, Front, Thickness Check .....	35-44-I
Brake, Rear, Run-out Check .....	35-46-I
Brake, Rear, Run-out Correction .....	35-46-I
Brake, Rear, Thickness Check .....	35-46-I
DISC BRAKE	
Front .....	35-63-I
Rear .....	35-68-I
DISC BRAKE PAD	
Check .....	35-42-I
Maintenance .....	00-42-I
DISTRIBUTOR .....	16-40-II
DISTRIBUTOR CAP, Maintenance .....	00-37-I
DISTRIBUTOR ROTOR, Maintenance .....	00-37-I
DOOR .....	42-32-I
DOOR	
Back .....	42-43-I
Back, Adjustment .....	42-17-I

- Front, Adjustment ..... 42-16-I  
 Fuel Filler, Adjustment ..... 42-16-I  
 Rear, Adjustment ..... 42-16-I  
 DOOR GLASS ..... 42-36-I  
 DOOR HANDLE ..... 42-39-I  
 DOOR HANDLE, Back ..... 42-45-I  
 DOOR INSIDE HANDLE, Play Adjustment ..... 42-17-I  
 DOOR LATCH ..... 42-39-I  
 DOOR LATCH, Back ..... 42-45-I  
 DOOR MIRROR ..... 51-27-I  
 DOOR OPENING WEATHERSTRIP ..... 42-42-I  
 DOOR OUTSIDE HANDLE, Play Check ..... 42-17-I  
 DOOR REGULATOR ..... 42-36-I  
 DOOR TRIM ..... 42-34-I  
 DOOR TRIM, Back ..... 42-44-I  
 DOOR WATERPROOF FILM ..... 42-34-I  
 DOOR WATERPROOF FILM, Back ..... 42-44-I  
 DOOR WINDOW GLASS, Adjustment ..... 42-17-I  
 DRIVE BELT  
 Compressor, Adjustment ..... 55-22-I  
 Deflection Adjustment ..... 14-5-I  
 Deflection Check ..... 14-5-I  
 Maintenance ..... 00-38-I  
 Tension Check ..... 37-11-I  
 Tension Inspection and Adjustment ..... 11-11-I  
 DRIVE SHAFT  
 Front Axle ..... 26-19-I  
 End Play Check ..... 26-8-I  
 DRIVE SHAFT BOOTS, Maintenance ..... 00-43-I  
 DRUM  
 Brake, Inside Diameter Check ..... 35-47-I  
 Parking Brake ..... 36-7-I  
 DUST COVER  
 Ball Joint, Replacement ..... 33-14-I  
 Lower Ball Joint, Replacement ..... 33-17-I
- ## E
- ELECTRONIC CONTROL UNIT <ABS> ..... 35-77-I  
 ELEMENT, Air Cleaner, Maintenance ..... 00-35-I  
 EMISSION CONTROL SYSTEM  
 Crankcase, Maintenance ..... 00-35-I  
 Evaporative, Maintenance ..... 00-36-I  
 END PLAY, Axle Shaft, Check ..... 27-12-I  
 ENGINE ..... 11-12-I  
 ENGINE CONTROL ..... 13-103-I  
 ENGINE CONTROL UNIT POWER GROUND, On-vehicle  
 Inspection ..... 13-38-I  
 ENGINE CONTROL UNIT TERMINAL VOLTAGE, On-vehicle  
 Inspection ..... 13-94-I  
 ENGINE COOLANT  
 Concentration Test ..... 14-5-I  
 Leak Check ..... 14-4-I  
 Maintenance ..... 00-41-I  
 Replacement ..... 14-5-I  
 ENGINE COOLANT TEMPERATURE GAUGE UNIT ..... 14-10-I  
 ENGINE COOLANT TEMPERATURE SENSOR ..... 14-10-I  
 ENGINE COOLANT TEMPERATURE SENSOR, On-vehicle  
 Inspection ..... 13-50-I  
 ENGINE COOLANT TEMPERATURE SWITCH  
 Cooling ..... 14-10-I  
 Air Conditioner ..... 55-31-I  
 ENGINE MOUNTING ..... 32-2-I  
 ENGINE OIL, Maintenance ..... 00-38-I  
 ENGINE OIL COOLER ..... 11-27-I  
 ENGINE OIL FILTER, Maintenance ..... 00-39-I  
 EVAPORATIVE EMISSION CONTROL SYSTEM ..... 17-5-I  
 EVAPORATIVE EMISSION CONTROL SYSTEM,  
 Maintenance ..... 00-36-I  
 EVAPORATOR ..... 55-29-I  
 EXHAUST EMISSION CONTROL SYSTEM ..... 17-8-I  
 EXHAUST MANIFOLD ..... 15-3-I  
 EXHAUST PIPE ..... 15-4-I  
 EXHAUST SYSTEM, Maintenance ..... 00-44-I
- ## F
- FAN, Cooling ..... 14-7-I  
 FAN MOTOR, Condenser ..... 55-32-I  
 FEEDER CABLE, Antenna ..... 54-99-II  
 FENDER ..... 42-22-I  
 FILLER DOOR  
 Fuel ..... 42-21-I  
 Fuel, Adjustment ..... 42-16-I  
 FILTER  
 Engine Oil, Maintenance ..... 00-39-I  
 Fuel, Replacement ..... 13-30-I  
 FIXED SAS, Adjustment ..... 13-30-I  
 FLOOR CONSOLE ..... 52-6-I  
 FLUID  
 Automatic Transmission, Change ..... 23-29-I  
 Automatic Transmission, Inspection ..... 23-28-I  
 Power Steering, Level Check ..... 37-11-I  
 Power Steering, Replacement ..... 37-11-I  
 FLUID COOLER, Transmission ..... 23-41-I  
 FLUID HOSES, Transmission ..... 23-41-I  
 FLUID PIPES, Transmission ..... 23-41-I  
 4WD INDICATOR CONTROL UNIT  
 Check ..... 23-34-I  
 Inspection ..... 22-7-I  
 4WD OPERATION DETECTION SWITCH  
 Check <A/T> ..... 23-30-I  
 Check <M/T> ..... 22-6-I  
 FREE-WHEELING CLUTCH ..... 26-32-I  
 FRONR DISC BRAKE PAD, Replacement ..... 35-42-I  
 FRONT AXLE  
 Maintenance ..... 00-44-I  
 Total Backlash Check ..... 26-8-I  
 FRONT AXLE GEAR OIL, Level Check ..... 26-8-I  
 FRONT BRAKE DISC  
 Run-out Check ..... 35-44-I  
 Thickness Check ..... 35-44-I  
 FRONT BUMPER ..... 51-11-I  
 FRONT COMBINATION LIGHT ..... 54-58-II  
 FRONT DIFFERENTIAL MOUNTING ..... 32-3-I  
 FRONT DISC BRAKE ..... 35-63-I  
 FRONT DOOR, Adjustment ..... 42-16-I  
 FRONT SEAT ..... 52-12-I  
 FRONT SEAT BELT ..... 52-16-I  
 FRONT WHEEL ALIGNMENT, Inspection and Adjustment ..... 33-11-I  
 FUEL FILLER DOOR ..... 42-21-I  
 FUEL FILLER DOOR, Adjustment ..... 42-16-I  
 FUEL FILTER, Replacement ..... 13-30-I  
 FUEL GAUGE UNIT, Replacement ..... 13-31-I  
 FUEL HOSES, Maintenance ..... 00-35-I  
 FUEL LINE ..... 13-101-I  
 FUEL LINE, Internal Pressure Reducing ..... 13-16-I  
 FUEL PRESSURE  
 On-vehicle Inspection ..... 13-91-I  
 Test ..... 13-91-I

FUEL PUMP .....	13-97-I
FUEL PUMP	
On-vehicle Inspection .....	13-39-I
Operation Check .....	13-15-I
Operation Check .....	13-91-I
FUEL SYSTEM .....	13-3-I
FUEL SYSTEM, Maintenance .....	00-35-I
FUEL TANK .....	13-98-I

**G**

GARNISHES .....	51-13-I
GASKET, Cylinder Head .....	11-20-I
GAUGES .....	54-7-II
GAUGES, Adjustment .....	54-30-II
GAUGE UNIT	
Fuel, Replacement .....	13-31-I
Engine Coolant Temperature .....	14-10-I
GEAR BOX, Power Steering .....	37-21-I
GEAR OIL	
Front Axle, Level Check .....	26-8-I
Level Check .....	27-12-I
GEOMAGNETIC SENSOR .....	54-38-II
GLASS	
Back Door Window .....	42-29-I
Door .....	42-36-I
Door Window, Adjustment .....	42-17-I
Quarter Window .....	42-28-I
Window .....	42-23-I
G-SENSOR	
AWD-ABS .....	35-73-I
Output Voltage Check <ABS> .....	35-52-I

**H**

HANDLE	
Back Door .....	42-45-I
Door .....	42-39-I
Door Inside, Play Adjustment .....	42-17-I
Door Outside, Play Check .....	42-17-I
HAZARD LIGHT SWITCH .....	54-60-II
HEADLIGHT .....	54-58-II
HEADLIGHT WASHER .....	51-25-I
HEADLINING .....	52-11-I
HEATER .....	55-2-I
HEATER CONTROL .....	55-4-I
HEATER UNIT .....	55-7-I
HI/LO DETECTION SWITCH	
Check <A/T> .....	23-30-I
Check <M/T> .....	22-6-I
HIGH MOUNTED STOP LIGHT .....	54-60-II
HIGH TENSION CABLE, Spark Test .....	16-29-II
HOOD .....	42-20-I
HOOD, Adjustment .....	42-16-I
HORN .....	54-64-II
HOSE	
Brake, Maintenance .....	00-43-I
Fuel, Maintenance .....	00-35-I
Steering .....	37-36-I
Transmission Fluid .....	23-41-I
Vacuum (Emission Control) .....	17-3-I
Vacuum (Front Axle) .....	26-29-I
HYDRAULIC UNIT	
ABS .....	35-72-I
Check <ABS> .....	35-50-I

**I**

IDLE POSITION SWITCH	
Adjustment .....	13-28-I
On-vehicle Inspection .....	13-54-I
IDLE SPEED	
Basic, Adjustment .....	13-26-I
Curb, Inspection .....	11-6-I
IDLE SPEED CONTROL SERVO, On-vehicle Inspection .....	13-79-I
IDLE-UP OPERATION, Check .....	55-28-I
IGNITION CABLES, Maintenance .....	00-37-I
IGNITION COIL, On-vehicle Inspection .....	13-84-I
IGNITION SWITCH .....	54-5-II
IGNITION SWITCH	
IG, On-vehicle Inspection .....	13-35-I
ST (A/T), On-vehicle Inspection .....	13-64-I
ST (M/T), On-vehicle Inspection .....	13-62-I
IGNITION SYSTEM .....	16-26-II
IGNITION SYSTEM	
Inspection with Analyzer .....	16-30-I
Primary Ignition Voltage Inspection .....	16-34-I
Secondary Ignition Voltage Inspection .....	16-30-I
IGNITION TIMING, Inspection and Adjustment .....	11-5-I
INDICATORS .....	54-39-II
INDIVIDUAL PARTS, Auto-cruise Control, Inspection .....	13-129-I
INFLATION PRESSURE, Tire, Check .....	31-4-I
INHIBITOR SWITCH	
Adjustment .....	23-31-I
Check .....	23-31-I
On-vehicle Inspection .....	13-64-I
INJECTORS, On-vehicle Inspection .....	13-75-I
INNER SHAFT .....	26-26-I
INSIDE TEMPERATURE SENSOR .....	54-38-II
INSTRUMENT PANEL .....	52-2-I
INTAKE AIR TEMPERATURE SENSOR, On-vehicle	
Inspection .....	13-46-I
INTAKE MANIFOLD, Vacuum Inspection .....	15-2-I
INTER-LOCK SWITCH, Inspection and Adjustment .....	21-4-I

**J**

JOINTS, Propeller Shaft, Maintenance .....	00-44-I
--	---------

**K**

KEY INTERLOCK MECHANISM, Check .....	23-32-I
KNUCKLE .....	26-16-I

**L**

LASH ADJUSTER, Check .....	11-9-I
LATCH	
Back Door .....	42-45-I
Door .....	42-39-I
LATERAL ROD .....	34-6-I
LATERAL ROD BUSHING, Replacement .....	34-7-I
LEAK, Refrigerant, Repair Procedure .....	55-26-I
LEVER	
Control .....	22-9-I
Parking Brake .....	36-4-I
Parking Brake, Stroke Inspection and Adjustment .....	36-3-I
Selector .....	23-39-I
Selector, Operation Check .....	23-32-I
LICENSE PLATE LIGHT .....	54-59-II
LIGHT	



Front Combination .....	54-58-II
License Plate .....	54-59-II
Rear Combination .....	54-59-II
Stop, High Mounted .....	54-60-II
Warning .....	54-39-II
LIGHTER, Cigarette .....	54-65-II
LIGHTING SYSTEM .....	54-41-II
LIGHTING SYSTEM, Adjustment .....	54-56-II
LIGHT SWITCH, Hazard .....	54-60-II
LIMITED SLIP DIFFERENTIAL, Preload Measurement .....	27-12-I
LINE	
Brake .....	35-61-I
Fuel .....	13-101-I
Fuel, Internal Pressure Reducing .....	13-16-I
Refrigerant .....	55-33-I
Vapor .....	13-101-I
LINKAGE, Steering .....	37-37-I
LOAD SENSING PROPORTIONING VALVE, Function Test .....	35-40-I
LOAD SENSING SPRING, Length Check and Adjustment .....	35-40-I
LOWER ARM	
Front Suspension .....	33-15-I
Rear Suspension .....	34-4-I
LOWER ARM BUSHING, Replacement .....	33-16-I
LOWER ARM REAR BUSHING, Replacement .....	34-4-I
LOWER BALL JOINT DUST COVER, Replacement .....	33-17-I

**M**

MANIFOLD	
Exhaust .....	15-3-I
Intake, Vacuum Inspection .....	15-2-I
MANIFOLD VACUUM, Inspection .....	11-8-I
MANUAL TRANSMISSION, Maintenance .....	00-39-I
MASTER CYLINDER .....	35-56-I
MASTER CYLINDER, Clutch .....	21-8-I
METERS .....	54-7-II
METERS	
Adjustment .....	54-30-II
Combination .....	54-34-II
MIRROR, Door .....	51-27-I
MOTOR RELAY, Check <ABS> .....	35-52-I
MOULDINGS .....	51-13-I
MOUNTING	
Body .....	42-19-I
Engine .....	32-2-I
Front Differential .....	32-3-I
MUFFLER .....	15-4-I
MULTI-METER .....	54-36-II

**O**

OIL	
Engine, Maintenance .....	00-38-I
Front Axle Gear, Level Check .....	26-8-I
Rear Axle (LSD), Maintenance .....	00-44-I
Transfer, Inspection and Change .....	23-29-I
Transmission, Replacement .....	22-5-I
OIL COOLER, Engine .....	11-27-I
OIL FILTER, Engine, Maintenance .....	00-39-I
OIL LEVEL	
Gear, Check .....	27-12-I
Transmission, Check .....	22-5-I
OIL PAN .....	11-18-I
OIL PRESSURE SWITCH, Power Steering, Check .....	37-14-I
OIL PUMP	

Power Steering .....	37-21-I
Power Steering, Pressure Test .....	37-13-I
OIL SCREEN .....	11-18-I
OIL SEAL	
Axle Housing, Replacement .....	27-13-I
Camshaft .....	11-15-I
Crankshaft <Front> .....	11-16-I
Crankshaft <Rear> .....	11-17-I
Differential Carrier, Replacement .....	26-8-I
Transfer, Replacement .....	22-5-I
Transfer, Replacement .....	23-34-I
OUTSIDE TEMPERATURE SENSOR .....	54-38-II
OVERFILL LIMITTER (2-WAY) VALVE, Replacement .....	13-31-I
OXYGEN SENSOR	
Maintenance .....	00-37-I
On-vehicle Inspection .....	13-92-I

**P**

PAD	
Disc Brake, Check .....	35-42-I
Disc Brake, Front, Replacement .....	35-42-I
Disc Brake, Maintenance .....	00-42-I
Disc Brake, Rear, Check and Replacement .....	35-44-I
PARKING BRAKE CABLE .....	36-5-I
PARKING BRAKE DRUM .....	36-7-I
PARKING BRAKE LEVER .....	36-4-I
PARKING BRAKE LEVER, Stroke Inspection and Adjustment .....	36-3-I
PARKING BRAKE SWITCH, Check .....	36-3-I
PEDAL	
Accelerator .....	13-104-I
Brake .....	35-54-I
Brake, Inspection and Adjustment .....	35-38-I
Clutch .....	21-5-I
Clutch, Inspection and Adjustment .....	21-3-I
PERFORMANCE TEST .....	55-25-I
PIPE	
Exhaust .....	15-4-I
Transmission Fluid .....	23-41-I
PLUG	
Spark, Maintenance .....	00-37-I
Spark, Test .....	16-29-II
POSITIVE CRANKCASE VENTILATION VALVE, Maintenance .....	00-35-I
POWER GROUND, Engine Control Unit, On-vehicle	
Inspection .....	13-38-I
POWER RELAY	
ABS, Check .....	35-52-I
Air Conditioner, On-vehicle Inspection .....	13-70-I
Check <Air Conditioner> .....	55-28-I
Check <Heater> .....	55-4-I
POWER STEERING FLUID	
Level Check .....	37-11-I
Replacement .....	37-11-I
POWER STEERING FLUID PRESSURE SWITCH, On-vehicle	
Inspection .....	13-68-I
POWER STEERING GEAR BOX .....	37-21-I
POWER STEERING OIL PRESSURE SWITCH, Check .....	37-14-I
POWER STEERING OIL PUMP .....	37-21-I
POWER STEERING OIL PUMP, Pressure Test .....	37-13-I
POWER SUPPLY, On-vehicle Inspection .....	13-35-I
POWER TRANSISTOR, On-vehicle Inspection .....	13-84-I
PRESSURE	
Fuel, On-vehicle Inspection .....	13-91-I
Inflation, Tire, Check .....	31-4-I
Compression, Check .....	11-7-I

PROPELLER SHAFT .....	25-3-I
PROPELLER SHAFT JOINTS, Maintenance .....	00-44-I
PULLEY, Tension .....	55-34-I
PUMP	
Fuel .....	13-97-I
Fuel, On-vehicle Inspection .....	13-39-I
Fuel, Operation Check .....	13-15-I
Water .....	14-9-I
PURGE CONTROL SOLENOID VALVE, On-vehicle	
Inspection .....	13-88-I

## Q

QUARTER WINDOW GLASS .....	42-28-I
----------------------------	---------

## R

RADIATOR .....	14-6-I
RADIATOR CAP, Pressure Test .....	14-5-I
RADIO .....	54-98-II
REAR AXLE	
Maintenance .....	00-44-I
Total Backlash Check .....	27-11-I
REAR AXLE OIL (LSD), Maintenance .....	00-44-I
REAR BRAKE DISC	
Run-out Check .....	35-46-I
Run-out Correction .....	35-46-I
Thickness Check .....	35-46-I
REAR BUMPER .....	51-12-I
REAR COMBINATION LIGHT .....	54-59-II
REAR DIFFERENTIAL LOCK .....	27-22-I
REAR DIFFERENTIAL LOCK DETECTION SWITCH, Check .....	27-14-I
REAR DIFFERENTIAL LOCK SYSTEM, Air Leakage Check .....	27-14-I
REAR DISC BRAKE .....	35-68-I
REAR DISC BRAKE PAD, Check and Replacement .....	35-44-I
REAR DOOR, Adjustment .....	42-16-I
REAR SEAT .....	52-15-I
REAR SEAT BELT .....	52-18-I
REAR WASHER .....	51-22-I
REAR WHEEL ALIGNMENT, Adjustment .....	34-3-I
REAR WIPER .....	51-22-I
REFRIGERANT, Leak Repair Procedure .....	55-26-I
REFRIGERANT LINE .....	55-33-I
REGULATOR, Door .....	42-36-I
RELAY	
Defogger .....	54-107-II
Lighting System .....	54-60-II
Motor, Check <ABS> .....	35-52-I
Power, Check <Air Conditioner> .....	55-28-I
Power, Check <Heater> .....	55-4-I
Valve, Check <ABS> .....	35-52-I
RHEOSTAT .....	54-61-II
ROD, Lateral .....	34-6-I
ROTOR, Distributor, Maintenance .....	00-37-I
RUN-OUT	
Front Brake Disc, Check .....	35-44-I
Rear Brake Disc, Check .....	35-46-I
Rear Brake Disc, Correction .....	35-46-I
Wheel, Check .....	31-4-I
RUNCHANNEL, Window Glass .....	42-42-I

## S

SAFETY PRECAUTIONS .....	55-19-I
SEALS	

Ball Joint, Maintenance .....	00-43-I
Steering Linkage, Maintenance .....	00-43-I
SEAT	
Front .....	52-12-I
Rear .....	52-15-I
SEAT BELT	
Front .....	52-16-I
Rear .....	52-18-I
SELECTOR LEVER .....	23-39-I
SELECTOR LEVER, Operation Check .....	23-32-I
SENSOR	
Air Flow, On-vehicle Inspection .....	13-42-I
Barometric Pressure, On-vehicle Inspection .....	13-48-I
Brake Fluid Level, Check .....	35-39-I
Crank Angle, On-vehicle Inspection .....	13-60-I
Engine Coolant Temperature .....	14-10-I
Engine Coolant Temperature, On-vehicle Inspection .....	13-50-I
Outside Temperature .....	54-38-II
G <AWD-ABS> .....	35-73-I
G, Output Voltage Check <ABS> .....	35-52-I
Geomagnetic .....	54-38-II
Intake Air Temperature, On-vehicle Inspection .....	13-46-I
Inside Temperature .....	54-38-II
Oxygen, Maintenance .....	00-37-I
Oxygen, On-vehicle Inspection .....	13-92-I
Throttle Position, Adjustment .....	13-28-I
Throttle Position, On-vehicle Inspection .....	13-52-I
Top Dead Center, On-vehicle Inspection .....	13-56-I
Vehicle Speed, On-vehicle Inspection .....	13-66-I
Wheel Speed <ABS> .....	35-74-I
Wheel Speed, Output Voltage Measurement <ABS> .....	35-48-I
SERVO, Idle Speed Control, On-vehicle Inspection .....	13-79-I
SHAFT	
Axle .....	27-17-I
Drive (Front Axle) .....	26-19-I
Drive, End Play Check .....	26-8-I
Inner .....	26-26-I
Propeller .....	25-3-I
SHIFT LOCK MECHANISM, Check .....	23-33-I
SHOCK ABSORBER	
Front Suspension .....	33-13-I
Rear Suspension .....	34-6-I
SOCKET, Accessory .....	54-67-II
SOLENOID VALVE	
Front Axle .....	26-29-I
Front Axle, Operation Check .....	26-10-I
Purge Control, On-vehicle Inspection .....	13-88-I
SPARK PLUG	
Test .....	16-29-II
Maintenance .....	00-37-I
SPARK PLUG CABLE, Test .....	16-29-II
SPEAKER .....	54-98-II
SPEED SENSOR	
Wheel <ABS> .....	35-74-I
Wheel, Output Voltage Measurement <ABS> .....	35-48-I
SPEEDOMETER CABLE	
Replacement <A/T> .....	23-34-I
Replacement <M/T> .....	22-8-I
SPRING	
Coil .....	34-8-I
Load Sensing, Length Check and Adjustment .....	35-40-I
STABILIZER BAR	
Front Suspension .....	33-20-I
Rear Suspension .....	34-9-I
STARTER MOTOR .....	16-19-II

- STARTING SYSTEM ..... 16-16-I
- STEERING
- Angle Check ..... 37-9-I
  - Stationary Steering Effort Check ..... 37-10-I
- STEERING COLUMN ..... 37-15-I
- STEERING GEAR, Backlash Check ..... 37-7-I
- STEERING HOSES ..... 37-36-I
- STEERING LINKAGE ..... 37-37-I
- STEERING LINKAGE SEALS, Maintenance ..... 00-43-I
- STEERING SHAFT ..... 37-15-I
- STEERING WHEEL
- Centering Adjustment ..... 37-8-I
  - Free Play Check ..... 37-7-I
  - Return to Center Check ..... 37-10-I
- STOP LIGHT, High Mounted ..... 54-60-II
- SUNROOF ..... 42-46-I
- SWITCH
- Air Conditioner ..... 55-28-I
  - Air Conditioner, On-vehicle Inspection ..... 13-70-I
  - Auto-cruise Control, Inspection ..... 13-128-I
  - Center Differential Lock Detection, Check <A/T> ..... 23-30-I
  - Center Differential Lock Detection, Check <M/T> ..... 22-6-I
  - Center Differential Lock Operation Detection, Check <A/T> ..... 23-30-I
  - Center Differential Lock Operation Detection, Check <M/T> ..... 22-6-I
  - Column ..... 54-62-II
  - Control <Front Suspension> ..... 33-20-I
  - Defogger ..... 54-106-II
  - Engine Coolant Temperature <A/C> ..... 55-31-I
  - Engine Coolant Temperature <Cooling> ..... 14-10-I
  - 4WD Operation Detection, Check <A/T> ..... 23-30-I
  - 4WD Operation Detection, Check <M/T> ..... 22-6-I
  - HI/LO Detection, Check <A/T> ..... 23-30-I
  - HI/LO Detection, Check <M/T> ..... 22-6-I
  - Hazard Light ..... 54-60-II
  - Idle Position, Adjustment ..... 13-28-I
  - Idle Position, On-vehicle Inspection ..... 13-54-I
  - Ignition ..... 54-5-II
  - Ignition-IG, On-vehicle Inspection ..... 13-35-I
  - Ignition-ST (A/T), On-vehicle Inspection ..... 13-64-I
  - Ignition-ST (M/T), On-vehicle Inspection ..... 13-62-I
  - Inhibitor, Adjustment ..... 23-31-I
  - Inhibitor, Check ..... 23-31-I
  - Inhibitor, On-vehicle Inspection ..... 13-64-I
  - Inter-lock, Inspection and Adjustment ..... 21-4-I
  - Main, Auto-cruise Control, Inspection ..... 13-127-I
  - Parking Brake, Check ..... 36-3-I
  - Power Steering Fluid Pressure, On-vehicle Inspection ..... 13-68-I
  - Power Steering Oil Pressure, Check ..... 37-14-I
  - Rear Differential Lock Detection, Check ..... 27-14-I
  - 2WD/4WD Detection, Check <A/T> ..... 23-30-I
  - 2WD/4WD Detection, Check <M/T> ..... 22-6-I
- T**
- TANK, Fuel ..... 13-98-I
- TENSION PULLEY ..... 55-34-I
- TERMINAL VOLTAGE, Engine Control Unit, On-vehicle Inspection ..... 13-94-I
- TEST PROCEDURES ..... 55-20-I
- THERMOSTAT ..... 14-8-I
- THERMOSWITCH ..... 14-10-I
- THICKNESS
- Front Brake Disc, Check ..... 35-44-I
  - Rear Brake Disc, Check ..... 35-46-I
- THROTTLE BODY (THROTTLE VALVE AREA), Cleaning ..... 13-28-I
- THROTTLE CABLE, Check and Adjustment ..... 23-29-I
- THROTTLE POSITION SENSOR
- Adjustment ..... 13-28-I
  - On-vehicle Inspection ..... 13-52-I
- TIE ROD END BALL JOINT, Starting Torque Check ..... 37-8-I
- TIMER, Defogger ..... 54-107-II
- TIMING BELT
- Engine ..... 11-23-I
  - Maintenance ..... 00-38-I
  - Tension Adjustment ..... 11-8-I
- TIRE, Wear Check ..... 31-4-I
- TIRE INFLATION PRESSURE, Check ..... 31-4-I
- TOP DEAD CENTER SENSOR, On-vehicle Inspection ..... 13-56-I
- TORSION BAR ..... 33-18-I
- TOTAL BACKLASH, Rear Axle, Check ..... 27-11-I
- TRANSFER
- M/T ..... 22-11-I
  - A/T ..... 23-43-I
  - Maintenance ..... 00-41-I
- TRANSFER OIL SEALS
- Inspection and Change ..... 23-29-I
  - Replacement <A/T> ..... 23-34-I
  - Replacement <M/T> ..... 22-5-I
- TRANSISTOR, Power, On-vehicle Inspection ..... 13-84-I
- TRANSMISSION CONTROL ..... 23-35-I
- TRANSMISSION FLUID COOLER ..... 23-41-I
- TRANSMISSION FLUID HOSES ..... 23-41-I
- TRANSMISSION FLUID PIPES ..... 23-41-I
- TRANSMISSION OIL, Replacement ..... 22-5-I
- TRANSMISSION OIL LEVEL, Check ..... 22-5-I
- TRANSMISSION
- A/T ..... 23-43-I
  - A/T, Maintenance ..... 00-40-I
  - M/T ..... 22-11-I
  - M/T, Maintenance ..... 00-39-I
- TRIM
- Back Door ..... 42-44-I
  - Door ..... 42-34-I
  - Interior ..... 52-8-I
- TUBING AND FITTINGS, Handling ..... 55-26-I
- 2WD/4WD DETECTION SWITCH
- Check <A/T> ..... 23-30-I
  - Check <M/T> ..... 22-6-I
- U**
- UPPER ARM ..... 33-13-I
- V**
- VACUUM, Manifold, Inspection ..... 11-8-I
- VACUUM HOSE
- Emission Control ..... 17-3-I
  - Front Axle ..... 26-29-I
- VALVE
- Check, Operation Check ..... 35-39-I
  - Load Sensing Proportioning, Function Test ..... 35-40-I
  - Overfill Limiter (2-way), Replacement ..... 13-31-I
  - Positive Crankcase Ventilation, Maintenance ..... 00-35-I
- VALVE RELAY, Check <ABS> ..... 35-52-I
- VAPOR LINE ..... 13-101-I
- VEHICLE SPEED SENSOR, On-vehicle Inspection ..... 13-66-I
- VENTILATORS

Air Outlet ..... 55-11-I  
 Instrument Panel and Floor ..... 55-10-I

**W**

WARNING LIGHTS ..... 54-39-II  
 WASHER  
 Headlight ..... 51-25-I  
 Rear ..... 51-22-I  
 Windshield ..... 51-19-I  
 WATER PUMP ..... 14-9-I  
 WATER TEST ..... 42-18-I  
 WATERPROOF FILM  
 Back Door ..... 42-44-I  
 Door ..... 42-34-I  
 WEAR, Tire, Check ..... 31-4-I  
 WEATHERSTRIP, Door Opening ..... 42-42-I  
 WHEEL, Runout Check ..... 31-4-I  
 WHEEL ALIGNMENT  
 Front, Inspection and Adjustment ..... 33-11-I  
 Rear, Adjustment ..... 34-3-I  
 WHEEL SPEED SENSOR  
 ABS ..... 35-74-I  
 Output Voltage Measurement <ABS> ..... 35-48-I  
 WINDOW DEFOGGER  
 Back Door ..... 54-103-II  
 Back Door, Adjustment ..... 54-106-II  
 WINDOW GLASS ..... 42-23-I  
 WINDOW GLASS  
 Back Door ..... 42-29-I  
 Door, Adjustment ..... 42-17-I  
 Quarter ..... 42-28-I  
 WINDOW GLASS RUNCHANNEL ..... 42-42-I  
 WINDSHIELD ..... 42-25-I  
 WINDSHIELD WASHER ..... 51-19-I  
 WINDSHIELD WIPER ..... 51-19-I  
 WIPER  
 Rear ..... 51-22-I  
 Windshield ..... 51-19-I



# MONTERO Specs-At-A-Glance

1992

<b>General</b>	Engine code		6G72
	Engine size	cm <sup>3</sup> (cu.in.)	2972 (181.3)
	Engine oil capacity, w/ filter & oil cooler	dm <sup>3</sup> (qts.)	6.6 (7.0)
	Cooling system capacity	dm <sup>3</sup> (qts.)	8.0 (8.5)
	A/T capacity	dm <sup>3</sup> (qts.)	7.2 (7.6)
	Power steering capacity	dm <sup>3</sup> (qts.)	1.06 (1.12)
<b>Engine</b>	Firing order		1-2-3-4-5-6
	Compression pressure	kPa (psi)	1,200 (171)
	Difference between cylinders	kPa (psi)	100 (14)
<b>Fuel</b>	Fuel tank capacity	dm <sup>3</sup> (gals.)	92 (24.3)
	Fuel pressure		
	<When vacuum hose disconnected>	kPa (psi)	330-370 (47-53)
	<When vacuum hose connected>	kPa (psi)	Approx. 270 (38)
	Basic ignition timing		5° ± 2° BTDC
	Curb idle speed	rpm	700 ± 100
	TPS voltage	V	0.40-1.00
	TPS resistance	kΩ	3.5-6.5
	Intake air temp. sensor resistance	kΩ [at 20°C (68°F)]	2.7
	Engine coolant temp. sensor resistance	kΩ	
	[at 20°C (68°F)]		2.4
[at 80°C (176°F)]		0.3	
<b>Cooling</b>	Radiator pressure cap opens	kPa (psi)	75-105 (11-15)
<b>A/T</b>	Fluid capacity	dm <sup>3</sup> (qts.)	7.2 (7.6)
<b>Front Axle</b>	Drive shaft nut torque	Nm (ft.lbs.)	50-60 (36-43)
	Caliper assembly mounting bolt torque	Nm (ft.lbs.)	90 (65)
<b>Rear Axle</b>	Axle shaft nut torque	Nm (ft.lbs.)	50-60 (36-43)
<b>Wheel and Tire</b>	Tire inflation pressure	kPa (psi)	
	Vehicles with wide fender		
	<Front>		210 (29)
	<Rear>		275 (40)
	Others		
<Front>		180 (26)	
<Rear>		240 (35)	
<b>Front Suspension</b>	Front wheel alignment		
	<Camber>		0°40' ± 30'
	<Caster>		3°00' ± 1°00'
	<Toe-in>	mm (in.)	3.5 ± 3.5 (.14 ± .14)
<b>Rear Suspension</b>	Axle shaft nut torque	Nmm (ft.lbs.)	50-60 (36-43)
<b>Brakes</b>	Front disc runout	mm (in.)	0.08 (.0031) or less
	Front disc minimum thickness	mm (in.)	22.4 (.882)
	Rear disc runout	mm (in.)	0.08 (.0031) or less
	Rear disc minimum thickness	mm (in.)	16.4 (.646)
	Rear drum inside diameter, max.	mm (in.)	198 (7.795)
	Parking brake lever stroke		4-6 notches
<b>Exterior</b>	Wiper blade length	mm (in.)	
	Windshield wiper		475 (18.7)
	Rear window		375 (14.8)
<b>Heater, A/C, Ventilation</b>	Refrigerant quantity R-12	g (oz.)	800 (28)